

FASTWD M820

FASTWD Android 13 Touch Tablet User Manual

Model: M820

Comprehensive guide for your FASTWD Android 13 Touch Tablet, covering setup, operation, maintenance, and troubleshooting.

1. PRODUCT OVERVIEW

The FASTWD Android 13 Touch Tablet is a versatile device designed for entertainment, productivity, and communication. Featuring a 10.1-inch Incell display, powerful octa-core processor, and ample storage, it offers a smooth and responsive user experience. This manual provides essential information to help you get the most out of your tablet.



Image: The FASTWD Android 13 Touch Tablet shown with its accompanying keyboard, mouse, and stylus, highlighting its versatility.

2. SETUP GUIDE

2.1 Package Contents

Before you begin, please verify that all items are present in your package:

- FASTWD Tablet
- Protective Sleeve
- User Manual
- Charger
- Data Cable (USB-C)
- OTG Adapter
- Mouse
- Keyboard

- Stylus Pen




Image: A visual representation of the tablet and all included accessories, such as the protective sleeve, charger, cables, mouse, keyboard, and stylus.

2.2 Initial Charging

For optimal performance, fully charge your tablet before first use. Connect the provided charger to the Type-C port on the tablet and plug it into a power outlet. The tablet supports 12W fast charging.



Image: The tablet connected to its charger, illustrating the 12W fast charging capability and the 8000mAh battery capacity.

2.3 Power On/Off

- **To Power On:** Press and hold the Power Button located on the side of the tablet until the FASTWD logo appears.
- **To Power Off:** Press and hold the Power Button, then select "Power Off" from the options that appear on the screen.
- **To Restart:** Press and hold the Power Button, then select "Restart" from the options.

2.4 Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup process. Follow the on-screen prompts to:

- Select your language.
- Connect to a Wi-Fi network.
- Sign in with your Google account or create a new one.
- Set up screen lock (PIN, Pattern, Password, Face ID).

3. OPERATING YOUR TABLET

3.1 Android 13 Operating System

Your FASTWD tablet runs on Android 13, offering a new user interface, enhanced app widgets, dynamic response, improved accessibility, and robust privacy controls. The tablet is GMS certified, ensuring full access to Google services and the Play Store.




Image: A visual representation of the Android 13 operating system interface, showcasing new features like app widgets and privacy settings.

3.2 Display and Visuals

The tablet features a 10.1-inch Incell high-definition eye protection screen with a resolution of 1920x1200 pixels, providing clear and vibrant visuals. It supports various screen magnification functions for enhanced viewing comfort.

- **Eye Protection:** Designed to reduce eye strain during prolonged use.
- **Dark Mode:** Switch to dark mode for comfortable viewing in low-light conditions.
- **Read Mode:** Optimize the display for reading text.




Image: A detailed view of the 10.1-inch Incell display, emphasizing its high-definition quality and eye protection features.

3.3 Performance and Storage

Equipped with an octa-core processor, 19GB RAM, and 128GB ROM, the tablet ensures smooth multitasking and ample space for your applications and media. Storage can be expanded up to 1TB using a TF (microSD) card.

The latest upgraded processor version, combined with excellent energy efficiency, supports a wide range of usage scenarios from entertainment to office.



Image: A graphic detailing the tablet's internal specifications, including the octa-core processor, 19GB RAM, 128GB ROM, and support for up to 1TB TF card expansion.

3.4 Camera Functionality

Capture moments with the tablet's dual cameras:


- **Rear Camera:** 13 Megapixels
- **Front Camera:** 8 Megapixels

Use the camera app to take photos, record videos, and make video calls.

3.5 Connectivity

- **Wi-Fi:** Supports 2.4G+5G dual-band Wi-Fi (802.11ac) for high-speed internet access.
- **Bluetooth:** Bluetooth 5.0 for connecting wireless accessories like headphones, speakers, keyboard, and mouse.
- **GPS:** Integrated GPS for navigation and location-based services.
- **Wireless Projection:** Cast your tablet screen to compatible displays.
- **Network Sharing:** Supports Wi-Fi hotspot, USB network share, Bluetooth share, and Ethernet network share.

Wireless projection and dual stereo speakers
Enjoy visual and auditory feast at home



2.4G+5G Dual-band WiFi Ultra high-speed connection response with Bluetooth 5.0 allows you to connect anytime and browse the web faster.





Image: The tablet wirelessly projecting its screen to a larger display, demonstrating its multimedia capabilities and dual-band Wi-Fi and Bluetooth 5.0 connectivity.

3.6 Unlocking Methods

The tablet offers secure unlocking options:

- **Face ID:** Use facial recognition for quick and secure access.
- **Gesture Unlocking:** Set a pattern for unlocking.
- **PIN/Password:** Standard numerical or alphanumeric password protection.



Image: A user demonstrating the Face ID unlocking feature on the tablet, highlighting its secure and convenient access.

3.7 Accessories Usage

- **Keyboard:** Connect the keyboard via Bluetooth for comfortable typing.
- **Mouse:** Connect the mouse via Bluetooth for precise navigation.
- **Stylus Pen:** Use the stylus for drawing, writing, and precise touch input.

FASTWD Tablet 5 Principles

- **Advanced R&D team**
- **Focused on better quality**
- **Easy to use and lasting experience**
- **Meet different customer needs**
- **24-Hour after-sales service**

Image: A person interacting with the tablet using the provided stylus pen, demonstrating its utility for various tasks.

4. MAINTENANCE

4.1 Battery Care

- Avoid exposing the tablet to extreme temperatures (hot or cold).
- Do not let the battery completely drain frequently.
- Use only the provided charger or a certified compatible charger.

4.2 Cleaning Your Tablet

- Use a soft, lint-free cloth to clean the screen and body.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner.
- Avoid using harsh chemicals, abrasive cleaners, or aerosol sprays.

4.3 Software Updates

Regularly check for and install system updates to ensure optimal performance, security, and access to new features. Go to Settings > System > System update to check for available updates.

5. TROUBLESHOOTING

5.1 Common Issues and Solutions

| Problem | Possible Solution |
|------------------------------|--|
| Tablet does not power on. | Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. |
| Cannot connect to Wi-Fi. | Check if Wi-Fi is enabled in settings. Restart your router. Forget the network and reconnect. |
| Apps are running slowly. | Close unused apps. Clear app cache. Restart the tablet. Ensure sufficient storage space. |
| Touchscreen is unresponsive. | Restart the tablet. If the issue persists, perform a factory reset (backup data first). |
| Battery drains quickly. | Reduce screen brightness. Close background apps. Disable unused connectivity features (Bluetooth, GPS). |

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact customer support.

6. SPECIFICATIONS

| Feature | Detail |
|-------------------------|---------------------------------|
| Brand | FASTWD |
| Model Name | M820 |
| Operating System | Android 13 |
| Screen Size | 10.1 Inches |
| Screen Resolution | 1920 x 1200 pixels (FHD Incell) |
| Processor | Octa-Core (Allwinner) |
| RAM Size | 19 GB (DDR3 SDRAM) |
| Memory Storage Capacity | 128 GB |
| Expandable Storage | Up to 1TB (TF Card) |
| Rear Webcam Resolution | 13 MP |
| Front Webcam Resolution | 8 MP |
| Battery Capacity | 8000mAh (12 Watt Hours) |
| Charging | 12W Fast Charging (Type-C) |

| Feature | Detail |
|--------------|---|
| Connectivity | 5G WiFi (802.11ac), Bluetooth 5.0, Cellular (implied by Connectivity Type: Cellular), GPS |
| Colour | Grey |
| Item Weight | 620 g |
| Dimensions | 33.5 x 19.7 x 4.2 cm (Package) |

7. WARRANTY AND SUPPORT

FASTWD is committed to providing high-quality products and excellent customer service.

- **Return Policy:** Enjoy a 30-day no-reason return period for your purchase.
- **Technical Support:** Benefit from 2 years of dedicated technical support.
- **After-Sales Service:** We offer 24-hour after-sales service to address any concerns or issues you may have.



Image: An illustration highlighting FASTWD's commitment to customer satisfaction, including return policy, technical support, and after-sales service.

For support, please refer to the contact information provided on the product packaging or the official FASTWD website.

English

Installation method

1. Clean your tablet screen
2. If necessary, use a dust sticker to remove dust.
3. Align the cutout of the screen film and the corner on the screen, use the adhesive guide to attach the screen protector to one side of the device.
Remove the film on the protection and slowly press the screen.

**Note: If a bubble is seen, check for dust on the screen. If so, remove the dust; otherwise, just remove the air bubbles.

Deutsch

Installationsmethode

1. Reinigen Sie den Bildschirm Ihres Tablets
2. Verwenden Sie bei Bedarf einen Staubabstreifer, um Staub zu entfernen
3. Richten Sie den Ausschnitt des Displayfilms und die Ecke des Displays aus und befestigen Sie die Displayschutzfolie mithilfe der Hebeführung an einer Seite des Geräts.
Entfernen Sie die Schutzfolie und drücken Sie langsam auf den Bildschirm.

**Hinweis: Wenn sich eine Blase befindet, prüfen Sie, ob sich Staub auf dem Bildschirm befindet. Wenn ja, entfernen Sie den Staub; Andernfalls entfernen Sie einfach die Luftblasen.

Italiano

Metodo di installazione

1. Pulisci lo schermo del tablet
2. Se necessario, utilizza un adesivo antipolvere per rimuovere la polvere
3. Allineare il taglio della pellicola dello schermo e l'angolo dello schermo, utilizzare la guida adesiva per fissare la protezione dello schermo su un lato del dispositivo
Rimuovere la pellicola di protezione e premere lentamente sullo schermo.

**Nota: se la bolla è formata, controlla la presenza di polvere sullo schermo. In tal caso, rimuoverla e la polvere; altrimenti basta eliminare le bolle d'aria.

Français

Méthode d'installation

1. Nettoyez l'écran de votre tablette
2. Si nécessaire, utilisez un autocollant anti-poussière pour enlever la poussière
3. Alignez la découpe du film de l'écran et l'angle de l'écran, utilisez l'adhésif guide pour fixer le protecteur d'écran sur un côté de l'appareil.
Retirez le film sur la protection et appuyez lentement sur l'écran.

[How to Install a Tablet Screen Protector: Step-by-Step Guide](#)

Concise guide on installing a screen protector on your tablet, covering cleaning, alignment, and bubble removal. Suitable for TOSCIDO, YUMKEM, HEASUR, and other compatible tablets.

lang:it score:12 filesize: 38.32 K page_count: 2 document date: 0000-00-00