

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Homall](#) /

› [Homall Electric Sit-Stand Desk 200x80 cm Instruction Manual](#)

Homall 0496

Homall Electric Sit-Stand Desk 200x80 cm Instruction Manual

Model: 0496 | Brand: Homall

[Introduction](#)

[Safety Information](#)

[Package Contents](#)

[Setup & Assembly](#)

[Operating Instructions](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Support](#)

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Homall Electric Sit-Stand Desk. Please read this manual thoroughly before use to ensure safe and efficient operation. This desk is designed to allow users to alternate between sitting and standing positions, promoting a healthier work environment.

The desk features a spacious 200x80 cm walnut-colored desktop, constructed from four individual parts, and an electric height adjustment system.



Figure 1.1: Homall Electric Sit-Stand Desk in a typical office setup.

2. SAFETY INFORMATION

- Ensure all components are securely fastened before use.
- Keep children and pets away from the desk during height adjustment.
- Do not place objects exceeding the maximum weight capacity (80 kg) on the desk.
- Avoid placing liquids directly on the control panel or near electrical components.
- Disconnect power before cleaning or performing any maintenance.
- The desk frame is constructed from all-steel for stability and durability.

3. PACKAGE CONTENTS

Your Homall Electric Sit-Stand Desk package includes the following components. Please verify all parts are present and undamaged upon receipt.

- Electric Desk Frame (Steel)
- Desktop (4-part, Walnut finish)
- Control Panel with LED Display
- Power Adapter and Cable
- Assembly Hardware (screws, bolts, etc.)
- Cable Management Tray
- Headphone Hooks
- Instruction Manual

► Herausragende Details

Zwei Pakete Tischgestellteile
und zusammengebaute
Tischplatte



austauschbare Rollen
für Tischbeine



Bequeme Haken



Kabelmanagement



Figure 3.1: Key components and accessories included with the desk, such as cable management and hooks.

4. SETUP & ASSEMBLY

Assembly is required for this desk. A detailed instruction manual and all necessary accessories are provided to facilitate the process. The desktop consists of four parts that need to be joined together.

4.1 Assembly Steps

- 1. Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.

2. **Assemble Desktop:** Join the four desktop sections together using the provided connectors and screws. Ensure they are aligned properly to form a flat surface.
3. **Attach Desk Legs:** Secure the desk legs to the assembled desktop using the designated screws.
4. **Install Crossbar and Motor:** Attach the crossbar between the legs and connect the electric motor according to the diagrams in the included manual.
5. **Mount Control Panel:** Secure the control panel to the underside of the desktop in an easily accessible location.
6. **Connect Cables:** Connect all electrical cables from the motor and control panel to the power adapter. Ensure all connections are firm.
7. **Install Accessories:** Attach the cable management tray and headphone hooks as desired.
8. **Power On:** Plug the power adapter into a wall outlet.

Maße und Parameter des Höhenverstellbaren Schreibtischs



Figure 4.1: Desk dimensions and a visual representation of the four-part desktop construction.



**S'asseoir et se lever
alternativement**

**Une colonne cervicale
plus saine**



Figure 4.2: The desktop is composed of four individual panels.

5. OPERATING INSTRUCTIONS

5.1 Control Panel Functions

The desk is operated via an intelligent control panel, allowing for easy height adjustments and memory presets.



Figure 5.1: The intelligent control panel features an LED display, height adjustment buttons, memory presets, and a USB-C port.

- **Up/Down Buttons (▲/▼):** Press and hold to adjust the desk height manually. The LED display will show the current height.
- **Memory Presets (1, 2, 3):**
 - To save a height: Adjust the desk to your desired height, then press the 'M' button followed by the desired preset number (1, 2, or 3). The height is now saved.
 - To recall a height: Press the corresponding preset number (1, 2, or 3) to automatically move the desk to the saved height.

- **Sit-Stand Reminder:** The control panel may include a feature to remind you to change positions. Refer to the specific manual for activation and settings.
- **Child Lock:** A child lock function may be available to prevent accidental adjustments. Consult the detailed manual for instructions on activating/deactivating.
- **USB-C Port:** Use the integrated USB-C port for charging compatible devices.

5.2 Height Adjustment Range

The desk offers a height adjustment range from 72 cm to 140 cm, allowing for comfortable use in both sitting and standing positions.



Figure 5.2: The desk can be adjusted to various heights for ergonomic comfort.

6. MAINTENANCE

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Cable Management:** Regularly check and organize cables to prevent tangles and damage. Utilize the provided cable management tray.
- **Inspections:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Motor Care:** The electric motor is designed for long-term use. Avoid overloading the desk or forcing adjustments if an obstruction is present.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected; motor error; overload.	Check power connections. Unplug and replug the power cable. Reduce weight on the desk. Refer to the full manual for error codes.
Desk moves unevenly or makes unusual noises.	Loose connections; obstruction; uneven weight distribution.	Check all assembly screws. Ensure no objects are obstructing the legs. Redistribute weight evenly on the desktop.
Height presets are not working.	Presets not saved correctly.	Re-save the desired heights using the 'M' button and preset numbers.

8. SPECIFICATIONS

Feature	Detail
Brand	Homall
Model Number	0496
Color	Walnut
Product Dimensions (L x W x H)	200 x 80 x 72-140 cm
Material	Metal (Alloy Steel base), Wood (Walnut top)
Special Features	Electric height adjustment, Memory presets, USB-C port
Item Weight	19 Kilograms
Maximum Load Capacity	80 kg
Desktop Construction	4-part panel



Figure 8.1: Homall desk legs are 33% thicker (8x5 cm) compared to standard designs (6x4 cm), enhancing stability.

↗ Strukturelle Stabilität



Figure 8.2: Structural components highlighting steel support rods and stable 80x50mm table legs, designed for a load capacity of up to 80 kg.

9. CUSTOMER SERVICE & SUPPORT

For any questions, concerns, or assistance with your Homall Electric Sit-Stand Desk, please contact our customer service team. We are committed to providing quality service to our users.

Please refer to your purchase documentation or the Homall official website for specific contact information and warranty details.

Online Resources: [Visit the Homall Store on Amazon](#)

© 2023 Homall. All rights reserved.