

GAOMON LHYJ-GAKITCHENTABLESET-23102314

GAOMON Kitchen Dining Table Set for 4 Instruction Manual

Model: LHYJ-GAKITCHENTABLESET-23102314

[Overview](#)

[Safety](#)

[Contents](#)

[Assembly](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Support](#)

1. PRODUCT OVERVIEW

This manual provides instructions for the GAOMON Kitchen Dining Table Set for 4. This set includes a rectangular dining table and four upholstered chairs, designed for small spaces such as apartments, studios, or compact dining areas. The rustic brown finish complements various interior styles.



Image 1.1: The GAOMON Kitchen Dining Table Set, featuring a rustic brown table and four upholstered chairs, suitable for small dining areas.

2. SAFETY INFORMATION

Please read and understand all safety warnings before assembly and use.

- Avoid placing heavy objects on the table that could cause it to tip over.
- Be cautious of the edges on the chairs and table, especially during handling and assembly.
- Ensure all screws and fasteners are securely tightened before use and periodically check for looseness.
- Do not stand on the chairs or table.
- Keep small parts away from children during assembly to prevent choking hazards.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer service.

- 1 x Rectangular Dining Table (Rustic Brown)

- 4 x Upholstered Dining Chairs (Black upholstery, Rustic Brown frame)
- Assembly Hardware Kit (screws, bolts, Allen wrench, etc.)
- Instruction Manual

PRODUCT SIZE

table*1 chairs*4



Image 3.1: Product dimensions and weight capacities for the table and chairs.

4. ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward. It is recommended to have two people for easier assembly. Please follow these steps carefully.

4.1 Before You Begin

- Clear a spacious area for assembly.
- Lay out all components and hardware.
- Do not fully tighten any screws until all components are loosely assembled. This allows for proper alignment.

4.2 Chair Assembly

1. Attach the chair backrest to the seat frame using the provided bolts.

2. Secure the chair legs to the seat frame.
3. Once all bolts are in place for a single chair, gradually tighten them in a diagonal or star pattern to ensure even pressure and stability.
4. Repeat for all four chairs.



Image 4.1: The upholstered seat and ergonomically curved backrest of a GAOMON dining chair.

4.3 Table Assembly

1. Attach the table legs to the tabletop frame using the provided hardware.
2. Connect any crossbars or support structures between the legs as indicated in the diagram.
3. Once all bolts are in place, gradually tighten them, ensuring the table is stable and level.

Sturdy Tabletop



Image 4.2: Detail of the sturdy rustic brown tabletop surface.

4.4 Final Checks

- Ensure all screws are fully tightened.
- Check that the table and chairs are stable and do not wobble. If wobbling occurs, adjust the leveling feet on the table legs if present, or re-tighten screws.

5. OPERATING INSTRUCTIONS

The GAOMON Kitchen Dining Table Set is designed for everyday use in dining areas. Its compact design allows for efficient space utilization.

5.1 Space-Saving Design

The chairs can be neatly stored underneath the table when not in use, optimizing space in smaller living areas.

SPACE SAVING

Suitable for Small Spaces or Apartment



Image 5.1: The space-saving design allows chairs to be tucked under the table.

5.2 General Use

- Use the table for dining, work, or other household activities.
- Ensure even distribution of weight on the tabletop.
- When moving chairs, lift them slightly rather than dragging to prevent damage to floor surfaces and chair legs.

6. CARE AND MAINTENANCE

Proper care will extend the lifespan and maintain the appearance of your dining set.

- **Cleaning:** The surface of the dining table features a waterproof and anti-corrosive coating. Wipe spills, food, and dust clean with a damp cloth immediately. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Protection:** Use placemats or coasters to protect the tabletop from hot items, scratches, and spills.
- **Inspection:** Periodically check all bolts and screws for tightness and re-tighten as necessary to maintain structural integrity.
- **Environment:** Avoid prolonged exposure to direct sunlight or extreme temperature changes, which can affect

the wood and metal components.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

7.1 Wobbling Table or Chairs

- **Solution:** Ensure all assembly screws are fully tightened. For tables, check if the floor is uneven; adjustable leveling feet (if present) can be used to stabilize the unit. Loosen all screws slightly, press down on the wobbly corner to level, then re-tighten screws.

7.2 Scratches or Minor Damage

- **Solution:** For minor scratches on the rustic brown surface, furniture repair markers or wood stain pens can be used to blend the damage. For deeper damage, contact customer service for advice.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	GAOMON
Model Number	LHYJ-GAKITCHENTABLESET-23102314
Color	Rustic Brown
Material	Engineered Wood (Tabletop), Steel (Frame)
Table Dimensions (L x W x H)	43.3 x 27.6 x 30 inches
Chair Dimensions (L x W x H)	17.75 x 15.16 x 35 inches
Item Weight	Approximately 64.8 pounds (total package)
UPC	196336206022
Assembly Required	Yes

9. WARRANTY AND CUSTOMER SUPPORT

GAOMON provides customer support for product inquiries, missing parts, or assembly assistance. Please refer to your purchase documentation for specific warranty details and contact information. For assistance, please contact GAOMON customer service through the retailer where the product was purchased or visit the official GAOMON website.