

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Maydolly](#) /

> [Maydolly Electric Baby Bouncer B0CLLN2S3B Instruction Manual](#)

Maydolly Electric Baby Bouncer B0CLLN2S3B

Maydolly Electric Baby Bouncer B0CLLN2S3B Instruction Manual

Model: B0CLLN2S3B

INTRODUCTION

This manual provides essential information for the safe and effective use of your Maydolly Electric Baby Bouncer. Please read these instructions carefully before assembly and operation, and retain them for future reference.

Your browser does not support the video tag.

Video: An introductory overview of the Maydolly Electric Baby Bouncer, highlighting its features and benefits for both baby and parent.

SAFETY PRECAUTIONS

- Always use the 5-point safety harness to secure your child.
- Do not leave your child unattended in the bouncer.
- Maximum weight capacity for active swing use is 9 kg (20 lbs). For stationary use, maximum weight is 15 kg (33 lbs).
- Ensure the bouncer is placed on a flat, stable surface.
- Keep away from open flames, heaters, and other heat sources.
- Do not use if any parts are damaged or missing.
- Adult assembly required.



Image: A detailed view of the 5-point safety harness, emphasizing its role in securing the baby.

PACKAGE CONTENTS

Please verify that all components are present before assembly:

- Main Bouncer Frame
- Seat Pad with 5-point harness
- Head Pillow
- Mosquito Net
- Toy Bar with hanging toys
- Remote Control
- Power Adapter
- Instruction Manual

SETUP

Follow these steps to assemble your electric baby bouncer:

1. **Assemble the Frame:** Connect the frame components securely until they click into place. Ensure all connections are firm.
2. **Install the Seat Pad:** Carefully slide the seat pad over the frame, ensuring all straps and buckles align with their respective slots. Secure the buckles.
3. **Attach the Head Pillow:** Position the head pillow for optimal comfort and support for your baby.
4. **Insert Batteries (if applicable):** If your model uses batteries for vibration or other functions, open the battery compartment (usually at the base) with a screwdriver, insert the required batteries (e.g., 1 x C battery), observing polarity, and close the compartment.
5. **Attach the Toy Bar:** Insert the toy bar into the designated slots on the bouncer frame. Ensure it is securely attached.
6. **Connect Power:** Plug the power adapter into the bouncer and a suitable power outlet.

Your browser does not support the video tag.

Video: This video demonstrates the assembly process for the electric baby bouncer, including connecting frame parts, installing the seat pad, and attaching accessories. It shows how to insert batteries and secure the toy bar.

リモコンで遠距離操作



Image: A baby comfortably resting in the Maydolly Electric Baby Bouncer, with a remote control visible. This image highlights the remote operation feature.

2種類の操作方法: リモコンorタッチパネル



Image: Close-up of the bouncer's control panel, showing buttons for power, speed, timer, music, and volume. This illustrates the easy operation.

OPERATING INSTRUCTIONS


Your Maydolly Electric Baby Bouncer offers various features for your child's comfort:

- **Power On/Off:** Press the power button on the control panel or remote control to turn the bouncer on or off.
- **Swing Speed Adjustment:** Select from 5 swing speeds using the speed buttons (1-5) on the control panel or remote. Adjust according to your baby's preference.
- **Timer Function:** Set the operating time to 15, 30, or 60 minutes using the timer button. The bouncer will automatically stop after the set time.
- **Music Playback:** Choose from 15 built-in lullabies using the music button. Adjust volume with the volume controls.
- **Reclining Function:** The bouncer features a reclining function to adjust the seat angle for optimal comfort.
- **Mosquito Net:** Attach the mosquito net to protect your baby from insects, especially during naps.

赤ちゃんの吐きもどしにくいデザイン



赤ちゃんの胃
はまだ未発達で、
ミルクを多く飲み過ぎると吐
き戻してしまうことがあります。



座面の後ろはベルトの
調節ができます。

Image: A baby sleeping peacefully in the bouncer with the mosquito net attached, demonstrating protection from insects.



Image: The bouncer with musical notes floating around it, indicating the music playback feature.

MAINTENANCE AND CARE

- **Cleaning the Seat Pad:** The seat pad is removable and washable. Hand wash or machine wash on a gentle cycle with mild detergent. Air dry only; do not tumble dry.
- **Cleaning the Frame:** Wipe the frame with a damp cloth and mild soap. Do not use abrasive cleaners.
- **Storage:** When not in use, store the bouncer in a clean, dry place away from direct sunlight.
- **Regular Checks:** Periodically check all screws, bolts, and connections to ensure they are tight and secure.



Image: The bouncer with its seat pad removed, illustrating the ease of cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Bouncer does not turn on.	No power connection or dead batteries.	Ensure power adapter is securely plugged in. If using batteries, replace them.
Swing motion is weak or inconsistent.	Low battery power or obstruction.	Replace batteries or check for any objects hindering the swing mechanism. Ensure baby's weight is within limits.
Music does not play.	Volume too low or music function off.	Increase volume or ensure music function is activated.

SPECIFICATIONS

- **Product Dimensions:** 80 x 55 x 50 cm
- **Product Weight:** 4.62 kg
- **Recommended Maximum Weight (Stationary):** 15 kg
- **Recommended Maximum Weight (Active Swing):** 9 kg
- **Power Source:** AC Adapter (included) / 1 x C Battery (not included, for vibration function if applicable)
- **Swing Speeds:** 5 levels

- **Timer Settings:** 15, 30, 60 minutes
- **Built-in Melodies:** 15 lullabies
- **Safety Harness:** 5-point

WARRANTY AND SUPPORT

This product comes with a 1-year warranty from the date of purchase. In case of any defects or issues within this period, please contact our customer support for assistance. We offer product exchange or refund services.

For assembly questions or any other inquiries, please do not hesitate to contact us. Our support team is ready to help.

Contact Information: Please refer to the contact details provided on your purchase receipt or the official Maydolly website.

