

Ikarao Break X1

Ikarao Break X1 Karaoke Machine User Manual

Brand: Ikarao

PRODUCT OVERVIEW

The Ikarao Break X1 is an all-in-one portable karaoke machine designed for adults, featuring a built-in 13.3-inch screen for lyrics display and streaming apps. It comes with two self-charging wireless microphones and delivers powerful 460W peak power audio with dynamic light shows, making it ideal for various party and performance settings.

Key features include dual 2.6" tweeters and a 6.5" woofer with DSP chip and Ikarao PRO Sound 3.0 for balanced, noise-reduced, and echo-cancelled sound. The microphones offer super-cardioid pickup for clear vocals and include 8 sound effects and EQ adjustments. With 9 connection options, including HDMI for TV display, USB, TF cards, and AUX, the Break X1 offers versatile media playback and connectivity. Its built-in battery provides up to 6 hours of playtime, with microphones lasting up to 30 hours.

WHAT'S IN THE BOX

- Break X1 Smart Karaoke Machine
- 2 Wireless Microphones
- Shoulder Strap
- Power Cable
- User Manual

SETUP GUIDE

Unpacking and Initial Setup

Carefully remove all components from the packaging. Place the Ikarao Break X1 on a stable, flat surface. Connect the power cable to the machine and a power outlet to begin charging the internal battery. The unit is designed for portability with integrated handles and a shoulder strap for easy transport.



Figure 1: Ikarao Break X1 Karaoke Machine with its built-in screen and two wireless microphones.

Microphone Setup

The two wireless microphones are designed for convenience. Simply place them into their designated slots on the top panel of the machine. They will automatically begin charging when the unit is powered on or plugged in, ensuring they are always ready for use. Each microphone features independent controls for volume and voice effects.

13.3" HD Screen, $\pm 180^\circ$ Rotation

Pre-installed app, unlimited music & videos,
best karaoke lyrics viewing experience.



reddot winner 2024



WiFi 2.4G & 5G

<1ms

Touchscreen Response



Bluetooth 5.3

2+64

2G RAM & 64G ROM



HDMI 1.4 & 2.0

3+8

3 Music Mode 8 Mic Effect



TWS Mode

6.5mm

Guitar & Wired Mic Port

4

Lighting Mode

9

Output Input Connections

Figure 2: The top panel of the Ikarao Break X1, highlighting the self-charging microphone slots and the main control interface.

OPERATING INSTRUCTIONS

Power On/Off and Basic Controls

To power on the Ikarao Break X1, press and hold the power button located on the top panel. The built-in 13.3-inch screen will illuminate, displaying the main interface. Volume adjustments for the main unit are made using the rotary knobs on the side panels. The central control panel provides dedicated buttons for microphone settings, reverb, treble, bass, and music ducking.

460W Peak Power

Delivers crisp highs, pure mids, and deep bass, ensuring an immersive sound quality experience.



Figure 3: The main control panel and screen interface of the Ikarao Break X1.

Connectivity Options

The Break X1 offers extensive connectivity. For synchronized lyrics display on a larger screen, connect to a TV via HDMI. The unit also supports Bluetooth 5.3 for wireless audio streaming from compatible devices. Additional ports on the rear panel include USB and TF card slots for local media playback, and AUX-in/out for connecting external audio sources or a PA system.

Karaoke Connect to TV

Connect to TV for real-time streaming via HDMI, Bluetooth, and WiFi, for a complete karaoke experience.



WiFi 2.4G & 5G



Bluetooth 5.3



HDMI 1.4 & 2.0



Figure 4: Ikarao Break X1 connected to an external TV for an enhanced karaoke experience.



Figure 5: Detailed view of the rear connectivity panel, including HDMI, USB, TF, and AUX ports.

Karaoke Features

The built-in 13.3-inch screen provides a seamless karaoke experience with pre-installed apps like YouTube, KaraFun, and SingPlay. Users can easily search for songs, view lyrics, and even record their performances. The wireless microphones offer various voice effects, including Original, Karaoke, Super, Popular, Profession, Cartoon, Monster, and Custom settings, allowing for personalized vocal styles.

Your browser does not support the video tag.

Video 1: Official product video showcasing the Ikarao Break X1's main features and karaoke capabilities.

Lighting Modes

Enhance your party atmosphere with the Break X1's dynamic lighting. Choose from various lighting modes such as Light, Romantic, Dynamic, and Bright. The unit also features 'Starlight' effects, which

can be set to 'Upper' or 'Surround' to create a captivating visual display that pulses with the music.

Professional and Easy to Use

Built-in microphone storage & automatic charging, EQ settings, sound effects, bass boost, and more, all at your fingertips.



Figure 6: The Ikarao Break X1 showcasing its integrated dynamic lighting system.

MAINTENANCE

To ensure the longevity and optimal performance of your Ikarao Break X1, regularly wipe the exterior with a soft, dry cloth. Avoid using abrasive cleaners or solvents. Store the unit in a cool, dry place away from direct sunlight and extreme temperatures. Ensure microphones are properly seated in their charging slots when not in use to maintain battery health.

TROUBLESHOOTING

No Power

- Ensure the power cable is securely connected to both the unit and a working power outlet.
- Check if the power button is pressed and held for a few seconds to turn on the device.
- Verify the battery level. If low, charge the unit for at least 30 minutes before attempting to power on again.

No Sound Output

- Check the main volume knobs on the side of the unit and ensure they are turned up.
- If using Bluetooth, ensure the device is properly paired and the volume on the connected device is also turned up.
- If using wired connections (AUX, HDMI), ensure cables are securely connected and the correct input source is selected on the screen.

Microphone Not Working

- Ensure the microphone's power button is pressed and held to turn it on.
- Check the microphone's battery level. Place it in the charging slot to recharge if needed.
- Verify that the microphone is properly connected wirelessly to the main unit.

PRODUCT SPECIFICATIONS

Feature	Specification
Item Weight	13.2 pounds
Product Dimensions	23.5 x 15 x 13.5 inches
Item Model Number	Break X1
Batteries	1 Lithium Ion batteries required.
Color	Black
Material Type	Plastic, Aluminum
Speaker Count	3
Power Source	Battery Powered

Compatible Devices	TV, HDMI, Guitar, USB, AUX IN, AUX OUT, TF, Micro SD, Wireless/Wired Microphone
Special Feature	Touch Screen for Lyric Display, Built-In Microphone(Auto charging), Rechargeable 460W Peak Power Bluetooth Speaker, Karaoke Light, Portable to connect TV, AUX-IN/OUT, WiFi 2.4G/5G, Bluetooth 5.3

WARRANTY AND SUPPORT




The Ikarao Break X1 comes with a 1-year manufacturer's warranty. For detailed warranty information and terms, please refer to the included User Manual (PDF) or Instructions for Use (IFU) (PDF) documents. These can also be accessed online via the provided links.




For any technical support, troubleshooting assistance, or product inquiries, please contact Ikarao customer service. Customer service is available 24 hours online. Refer to the User Manual for specific contact details or visit the official Ikarao Store on Amazon.

User Manual (PDF): [Click Here](#)

Instructions for Use (IFU) (PDF): [Click Here](#)

Related Documents - Break X1

	Ikarao Break X2 Smart Karaoke Speaker User Manual Comprehensive user manual for the Ikarao Break X2 Smart Karaoke Speaker, detailing setup, features, troubleshooting, and technical specifications for an enhanced karaoke experience.
	Ikarao Break X1 Smart Karaoke Speaker User Manual Comprehensive user manual for the Ikarao Break X1 Smart Karaoke Speaker, detailing features, operation, and troubleshooting. Includes setup, controls, sound effects, and connectivity options.
	Ikarao Break X1 All-in-One Portable Party Speaker Instruction Manual Comprehensive instruction manual for the Ikarao Break X1, an all-in-one portable party speaker. Learn about setup, features, usage, safety, and troubleshooting for this Bluetooth-enabled karaoke machine with a 13.3-inch screen.

 <p>The image shows the Ikarao Break X2 smart karaoke speaker. It is a white, rectangular device with a large screen at the top, two yellow circular speakers on the front, and various control buttons and ports below the screen. The Ikarao logo is visible in the top left corner of the image.</p>	<p>Ikarao Break X2 Smart Karaoke Speaker User Manual</p> <p>Comprehensive user manual for the Ikarao Break X2 smart karaoke speaker, covering setup, features, operation, troubleshooting, and technical specifications. Includes details on microphones, connectivity, lighting effects, and media playback.</p>
 <p>The image is a cover for the Ikarao BREAK X1 Quick Start Guide. It features a black and white photo of a group of people singing and playing instruments. The text 'Ikarao BREAK X1' is on the left, and 'QUICK START GUIDE' is on the right.</p>	<p>Ikarao BREAK X1 Quick Start Guide</p> <p>A concise guide to setting up and using the Ikarao BREAK X1 portable karaoke speaker system, covering features like Bluetooth, Wi-Fi, microphones, and charging.</p>
 <p>The image is a cover for the Ikarao Break X2 Quick Start Guide. It features a black and white photo of a person singing into a microphone. The text 'Ikarao Break X2' is on the left, and 'QUICK START GUIDE' is on the right.</p>	<p>Ikarao Break X2 Smart Karaoke Machine: Quick Start Guide & Specifications</p> <p>Get started with your Ikarao Break X2 Smart Karaoke Machine. This guide covers setup, features, specifications, and usage for the karaoke system with a 10.1-inch tablet and wireless microphones.</p>