

[Manuals.plus](#) /

› [Sloosh](#) /

› SLOOSH Inflatable Tanning Pool Lounger Float Instruction Manual (Model: B0CLMHL64T)

Sloosh B0CLMHL64T

SLOOSH Inflatable Tanning Pool Lounger Float Instruction Manual

Model: B0CLMHL64T

Brand: Sloosh

INTRODUCTION

Thank you for choosing the SLOOSH Inflatable Tanning Pool Lounger Float. This manual provides essential information for the safe and effective use, setup, maintenance, and storage of your product. Please read these instructions carefully before use and retain them for future reference.

PRODUCT FEATURES

- **Dimensions:** Approximately 70 inches (L) x 46 inches (W).
- **Capacity:** Designed to accommodate up to 2 people, with a weight limit of 140 kilograms (approximately 308 pounds).
- **Material:** Constructed from thick, heavy-duty, and UV-resistant PVC with a thickness of 0.3mm.
- **Comfort:** Features an inflatable base for enhanced comfort, a ribbed air cushion base, and a removable headrest for neck and back support.
- **Convenience:** Includes two integrated drink holders.
- **Stability:** Equipped with integrated pad eyes and a wrap-around grab line for maneuverability and stability.



Image: The SLOOSH Inflatable Tanning Pool Lounger Float showcasing its dimensions of 70 inches by 46 inches.

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the lounger float from its packaging.
2. **Placement:** Choose a flat, clear area free of sharp objects. A tarp or ground cloth is recommended underneath to prevent punctures.
3. **Inflation:**
 - Locate the air valves on the main body and the removable headrest.
 - Use an air pump (not included) to inflate the lounger. An electric pump is recommended for efficiency.
 - Inflate until firm to the touch, but do not over-inflate. Ensure all chambers are adequately filled.
 - Attach the headrest to the main body if desired.
4. **Filling with Water (Optional):**
 - If using as a tanning pool, fill the inner basin with a shallow amount of water using a garden hose.
 - Do not overfill; a small amount of water is sufficient for cooling.



Your Personal Pool

Pool, patio, or backyard—relax anywhere.
Easy to inflate and move.

Image: The lounger float being prepared for use, showing the inflation process and filling with water.

OPERATING INSTRUCTIONS

The SLOOSH Inflatable Tanning Pool Lounger Float is designed for relaxation and sunbathing, either with or without a shallow layer of water. It can be used on a flat surface in your yard or as a float in a larger pool.

- **Lounging:** Position yourself comfortably on the ribbed air cushion base. The removable headrest can be adjusted or removed based on your preference for back or stomach lounging.
- **Hydration:** Utilize the two integrated cup holders to keep beverages within easy reach.
- **Maneuverability:** The wrap-around grab line and integrated pad eyes allow for easy movement and securing of the float, whether in water or on land.



Image: A woman comfortably lounging on the float in a backyard setting, demonstrating its use for relaxation.



2 Oversized Cup Holders

Extra-large design keeps your favorite drinks within easy reach.

Image: A woman sunbathing on the float, highlighting the comfort and convenience of the drink holders.

MAINTENANCE

- **Cleaning:** After each use, especially if filled with water, drain the water using the drain plug located at the bottom of the lounger. Clean the surface with mild soap and water, then rinse thoroughly.
- **Drying:** Ensure the lounger is completely dry before deflating and storing to prevent mold or mildew growth.
- **Storage:** Deflate the lounger completely. Fold or roll it neatly and store in a cool, dry place away from direct sunlight and sharp objects.
- **Repair:** In case of minor punctures, use the included patch kit for repair. Follow the instructions provided with the patch kit carefully.

TROUBLESHOOTING

Issue	Possible Cause	Solution
-------	----------------	----------

Issue	Possible Cause	Solution
Lounger loses air quickly.	Valve not properly sealed, small puncture, or under-inflation.	Ensure all valves are securely closed. Check for punctures and repair with the patch kit. Re-inflate to proper firmness.
Water does not drain completely.	Drain plug obstructed or lounger not positioned correctly.	Ensure the drain plug is fully open and clear of debris. Slightly tilt the lounger to facilitate complete drainage.

SPECIFICATIONS

- **Model Number:** B0CLMHL64T
- **Brand:** Sloosh
- **Material:** Polyvinyl Chloride (PVC)
- **Product Dimensions (Inflated):** 70"L x 46"W (177.8 cm L x 116.8 cm W)
- **Material Thickness:** 0.3mm
- **Item Weight:** 3.21 Kilograms (7.06 pounds)
- **Weight Limit:** 140 Kilograms (approximately 308 pounds)
- **Age Range (Recommended):** Adult (Manufacturer recommended age: 3 years and up)
- **UPC:** 840332623184

SAFETY INFORMATION

- **WARNING:** This is not a lifesaving device. Do not leave children unattended while device is in use.
- Always supervise children when they are near water.
- Do not use in rough water or strong currents.
- Keep away from open flames and heat sources.
- Avoid over-inflation, which can cause bursting.
- Inspect the product for damage before each use.



Image: Product packaging displaying important safety warnings and age recommendations.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official Sloosh website. Keep your purchase receipt for warranty claims.