

[manuals.plus](#) /

› [Voopwink](#) /

› [Kids Headphones with Microphone, Wired Over Ear Headsets with Limited Volume 85dB/ 94dB for Boys Girls Teens Children Online School/Travel/iPad/Tablet/Cellphone](#)

Voopwink

Kids Headphones with Microphone, Wired Over Ear Headsets with Limited Volume 85dB/ 94dB

Brand: Voopwink

PRODUCT OVERVIEW

The Voopwink Kids Headphones are wired over-ear headsets designed for children, teens, boys, and girls. They feature a built-in microphone and a volume limiting switch to protect sensitive ears. These headphones are ideal for online learning, travel, and use with various electronic devices.



Figure 1: Voopwink Kids Headphones in Light Green and Purple.

1. Unpacking

Carefully remove the headphones and the included cable from the packaging. Ensure all components are present.

2. Connecting to a Device

1. Locate the 3.5mm audio jack on your device (tablet, laptop, iPad, Chromebook, cellphone).
2. Insert the 3.5mm plug of the headphone cable firmly into the device's audio jack.
3. The headphones are now ready for use. No additional drivers or software are required for basic audio and microphone functions.



Figure 2: Headphones connected to a device, illustrating the microphone and volume control on the cable.

OPERATING INSTRUCTIONS

1. Wearing the Headphones

- Adjust the headband to fit comfortably on the user's head. The headband is adjustable to accommodate various head sizes.
- Ensure the soft over-ear cushions fully cover the ears for optimal sound and comfort. The earcups can swivel 90 degrees for a better fit.



Figure 3: Headphone comfort features including adjustable headband and soft earcups.

2. Volume Limit Switch

The headphones feature a volume limit switch on the audio cable to protect hearing. This switch allows you to select between two volume levels:

- **85dB (Study Mode):** Recommended for normal environments to protect vulnerable and sensitive ears during long-term use.
- **94dB (Travel Mode):** Suitable for noisy environments such as public parks, cars, or airplanes, allowing clear audio while still protecting hearing. This mode is intended for short-term use in louder settings.



Figure 4: Volume limit settings for different environments.

3. Multi-functional Button

The audio cable includes a multi-functional button for convenient control:

- **Single Press:** Answer/hang up calls, play/pause music.
- **Double Press:** Skip to the next track.
- **Triple Press:** Go back to the previous track.

4. Built-in HD Microphone

The integrated HD microphone in the braided cord provides clear voice pickup without lag, facilitating online learning, classroom interaction, and video calls.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the headphones. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, fold the headphones to save space and protect them from damage. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid sharp bends or excessive pulling on the cable to prevent internal wire damage.

Foldable & Portable

Unique foldable design
not only saves space
but also makes it
portable



Figure 5: Foldable design for easy storage and portability.

Problem	Possible Cause	Solution
No sound or low volume	<ul style="list-style-type: none">• Cable not fully inserted.• Device volume too low.• Headphone volume limit switch set to 85dB in a noisy environment.	<ul style="list-style-type: none">• Ensure the 3.5mm jack is fully inserted into the device.• Increase the volume on your connected device.• Switch the volume limit to 94dB if in a noisy environment.
Microphone not working	<ul style="list-style-type: none">• Microphone muted on device.• Application settings.• Cable not fully inserted.	<ul style="list-style-type: none">• Check device's microphone settings to ensure it's not muted.• Verify microphone input settings within the application (e.g., video call software).• Ensure the 3.5mm jack is fully inserted.
Sound distortion	<ul style="list-style-type: none">• Volume too high on device.• Damaged cable or headphones.	<ul style="list-style-type: none">• Lower the volume on your connected device.• Inspect the cable and headphones for visible damage. If damaged, replacement may be necessary.

SPECIFICATIONS

Model Name: kids headphones

Connectivity Technology: Wired

Headphones Jack: 3.5 mm Jack

Audio Driver Size: 40 Millimeters

Frequency Range: 20 Hz - 20,000 Hz

Control Type: Volume Control (via switch on cable)

Control Method: Touch (for multi-function button)

Microphone: Built-in HD Microphone

Volume Limit: 85dB / 94dB switchable

Ear Placement: Over Ear

Form Factor: On Ear, Over Ear

Noise Control: Sound Isolation

Material: Acrylonitrile Butadiene Styrene (ABS)

Age Range (Description): Kid

Compatible Devices: Tablets, Laptops, iPads, Chromebooks

Cable Feature: Retractable

Item Weight: 1.76 ounces

Package Dimensions: 6.73 x 6.18 x 2.24 inches

Manufacturer: Voopwink

Country of Origin: China

WARRANTY & SUPPORT

For warranty information and customer support, please refer to the product packaging or contact Voopwink customer service directly. Details regarding specific warranty periods and support channels are typically provided with your purchase.