

[Manuals.plus](#) /

› [VASAGLE](#) /

› VASAGLE KKS031K11 Kitchen Baker's Rack Instruction Manual

VASAGLE KKS031K11

VASAGLE KKS031K11 Kitchen Baker's Rack Instruction Manual

Model: KKS031K11 | Brand: VASAGLE

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use of this product. Failure to follow these instructions may result in injury or damage to the product.

- Keep all packaging materials away from children.
- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly to avoid damaging the material.
- Always use the anti-tip kit provided to secure the rack to a wall, especially if children or pets are present.
- Do not exceed the maximum weight capacity for each shelf. Refer to the specifications section for details.
- The integrated power strip is designed for kitchen appliances. Do not overload it. It features overload and leakage protection.
- Keep liquids away from the power strip to prevent electrical hazards.
- This product is intended for indoor use only.



Surface facile à nettoyer



Kit anti-basculement



Pieds réglables

Image: Detail of the anti-tip kit, showing how it secures the rack to the wall for stability, along with adjustable feet and easy-clean surface.

2. PRODUCT OVERVIEW

The VASAGLE KKS031K11 Kitchen Baker's Rack is a versatile storage solution designed for kitchens. It features multiple shelves, a secure power strip, S-hooks, and a pull-out basket to help organize various kitchen items and appliances.

VASAGLE

by SONGMICS HOME



Image: Fully assembled VASAGLE KKS031K11 Kitchen Baker's Rack, showcasing its design and storage capabilities in a kitchen environment.

3. ASSEMBLY INSTRUCTIONS

Assembly is straightforward with clear illustrations and numbered parts. It is recommended to have two people for assembly.

3.1 Unpacking and Part Identification

- Carefully unpack all components and lay them out on a clean, soft surface.
- Verify that all parts listed in the packing list are present. Refer to the included manual for the complete parts list.

3.2 Step-by-Step Assembly

1. Attach the main frame components using the provided screws. Ensure all connections are secure but do not fully tighten until the entire frame is assembled.
2. Install the wooden shelves into the designated slots. The two lower central shelves are height-adjustable; choose your preferred height.
3. Mount the power strip unit to the side frame.
4. Attach the upper shelves and the S-hook bar.
5. Insert the pull-out basket into its runners.
6. Once all components are in place, fully tighten all screws.
7. Attach the adjustable feet to the bottom of the rack and level the unit.
8. Secure the rack to the wall using the anti-tip kit.

Espaces de stockage personnalisables

- 2 options d'installation pour les espaces inférieurs
- Tablettes centrales inférieures réglables sur 3 hauteurs



Option A

Grand espace à gauche

Option B

Grand espace à droite

Image: Customizable storage options, illustrating how the lower shelves can be adjusted for different configurations (Option A: large space left, Option B: large space right).

4. OPERATING INSTRUCTIONS

4.1 Using the Power Strip

- Plug the power strip's main cable into a suitable wall outlet.
- Press the on/off switch to activate the outlets.
- Connect kitchen appliances (e.g., microwave, coffee maker, toaster) to the 4 AC outlets.
- The power strip is equipped with overload and leakage protection. If it trips, disconnect some devices and reset the switch.
- Maximum power: 1875 watts. Do not exceed this limit.



220V/15A
4 prises CA



Interrupteur
marche/arrêt



Puissance
maximale :
1875 watts



Câble de 1,5 m

4.2 Utilizing Storage Features

- **Upper Shelves:** Ideal for spices, small jars, or decorative items.
- **S-Hooks:** Use the 8 removable S-hooks to hang cups, utensils, or dishcloths.
- **Main Work Surface:** Provides a spacious area for appliances like microwaves or coffee makers.
- **Adjustable Lower Shelves:** Customize the height to fit larger pots, pans, or small appliances.
- **Pull-out Basket:** Convenient for storing fruits, vegetables, or cutlery. The stopper prevents it from falling out.



Image: Overview of the rack's storage capacity, showing different items placed on its shelves and hooks.

Panier extractible avec stoppeur

Permet l'accès facile aux contenus et empêche le panier de tomber




Image: Detail of the pull-out basket with stopper, demonstrating easy access and secure design.

5. MAINTENANCE AND CARE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Immediately wipe up any spills, especially on the wooden surfaces, to prevent staining or water damage.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Adjustable Feet:** Ensure the adjustable feet are properly set to keep the rack level and stable on uneven floors.

6. TROUBLESHOOTING

- **Issue:** The rack feels wobbly or unstable.
 - **Solution:** Check that all screws are securely tightened. Adjust the leveling feet on the bottom of the rack to compensate for uneven floors. Ensure the anti-tip kit is properly installed and secured to the wall.
- **Issue:** Power strip is not working.
 - **Solution:** Check if the main power switch on the strip is in the "ON" position. Verify that the power strip's cable is securely plugged into a functional wall outlet. If the power strip has tripped due to overload, unplug some devices and press the reset button (if available) or cycle the on/off switch.
- **Issue:** Parts do not fit during assembly.
 - **Solution:** Double-check the part numbers against the assembly diagram. Ensure you are not forcing parts. Sometimes, rotating a piece 180 degrees can resolve fit issues. If a part is genuinely defective or incorrect, contact customer support.

7. SPECIFICATIONS

Model Number	KKS031K11
Brand	VASAGLE
Overall Assembled Dimensions (W x D x H)	90 x 40 x 165.5 cm (35.4 x 15.7 x 65.2 inches)
Item Weight	19.2 Kilograms (42.3 lbs)
Material	Alloy Steel, Engineered Wood
Color	Vintage Brown + Ink Black
Number of Shelves	5
Power Strip	4 AC Outlets, Overload & Leakage Protection, On/Off Switch
Max Power (Power Strip)	1875 Watts
Cable Length (Power Strip)	1.5 meters
Included Components	8 S-hooks, Power Strip, Pull-out Basket, Anti-tip Kit
Assembly Required	Yes




Image: Detailed dimensions and weight capacities of the rack components.

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official VASAGLE website. If you encounter any issues during assembly or use, or if you have questions about the product, please contact VASAGLE customer support through the retailer where you purchased the item.

Online Support: For additional resources, FAQs, and contact information, please visit the [VASAGLE Brand Store on Amazon](#).

