

[Manuals.plus](#) /

› [addlon](#) /

› addlon 42-inch Black Ceiling Fan with Light and Remote Control (Model KDM42PLY5B01R1) Instruction Manual

addlon KDM42PLY5B01R1

addlon 42-inch Black Ceiling Fan with Light and Remote Control

INSTRUCTION MANUAL

Model: KDM42PLY5B01R1 | Brand: addlon

1. Safety Information

Please read and understand this entire manual before attempting to assemble, operate, or install the product. Failure to do so may lead to electric shock, fire, or other injuries that could be fatal.

- Ensure the power is turned off at the circuit breaker before installation or maintenance.
- All wiring must be in accordance with national and local electrical codes.
- Installation should be performed by a qualified electrician if you are unsure about the process.
- Mount the fan to a ceiling outlet box marked 'Acceptable for Fan Support of 35 lbs (15.9 kg) or less'.
- Keep children and pets away from the product during installation.

2. Package Contents

Verify that all components are present and undamaged before beginning installation. If any parts are missing or damaged, contact customer support.



6 Speeds Selectable

Select different wind speeds for different scenarios

Two Colors
Available



Level 1-2

LOW Comfortable Wind

For sleeping / ventilation etc.



Level 3-4

Medium Natural Wind

For daily use



Level 5-6

High Cooling Wind

For exercise & hot weather

Image: All components of the addlon 42-inch ceiling fan laid out, including the fan motor assembly, canopy, downrod, hanger ball, blades, light board, shade, controller, remote, and accessory hardware.

- Fan Motor Assembly
- Canopy
- Downrod & Hanger Ball
- Motor Cover Assembly
- Blades (5x, reversible black/walnut)
- Light Board & Shade
- Controller & Remote Control (with batteries)
- Accessory Hardware (screws, wire nuts, etc.)
- Instruction Manual

3. Specifications

Feature	Specification
Brand	addlon
Model Name	KDM42PLY5B01R1
Size	42 inch
Color	Black
Power Source	AC
Voltage	120 Volts
Wattage	51 watts
Motor Type	Brushless DC
Number of Blades	5
Wind Speeds	6 (with Natural Wind Mode)
Air Flow Capacity	3579 Cubic Inches Per Minute
Noise Level	35 Decibels
Light Features	3 CCT (3000K, 4000K, 6000K), Dimmable (10%-100%)
Control Method	Remote
Installation Type	Downrod Mount
Indoor/Outdoor Usage	Indoor, Outdoor (Not to be exposed directly to rain)
Item Weight	8.49 pounds

4. Setup and Installation

Follow these steps for proper installation. Detailed instructions and videos are available to assist you.

4.1. Unboxing and Component Identification

Video: This video demonstrates the unboxing process and identifies all components of the ceiling fan, including the motor, blades, light kit, and remote control. It also shows the assembly of the blades and light kit to the motor.

4.2. Blade Assembly

The fan blades are reversible, offering both black and walnut finishes. Choose your preferred side before assembly.

1. Attach the blade holders to the fan blades using the provided screws. Ensure the desired blade color faces downwards.
2. Securely fasten the assembled blades to the motor housing.

52" Wood Blades Ceiling Fan with Light

Image: A close-up view of the reversible fan blades being attached to the motor housing with screws.

4.3. Light Kit Installation

The fan features a replaceable LED light kit.

1. Connect the LED light board wires to the corresponding connectors in the fan motor assembly.
2. Secure the light board to the fan motor assembly with screws.
3. Attach the light shade by twisting it into place.



Image: A person installing the LED light board and shade into the main fan body.

4.4. Mounting and Wiring

This fan supports downrod mount installation. Ensure the mounting bracket is securely attached to a suitable ceiling junction box.

1. Install the mounting bracket to your ceiling's electrical junction box.
2. Thread the electrical wires from the ceiling through the downrod and connect them to the fan's wiring.
3. Carefully lift the fan assembly and hang it onto the mounting bracket.
4. Connect the fan's electrical wires to the household wiring according to local codes (typically black to black, white to white, and green/bare copper to ground).
5. Secure the canopy to cover the wiring and mounting bracket.

Video: This installation tutorial provides a step-by-step guide for mounting the ceiling fan, including securing the downrod and connecting the electrical wiring to the ceiling bracket.

5. Operating Instructions

Your addlon ceiling fan is controlled via the included remote control. It also features a memory function for convenience.

5.1. Remote Control Functions



Multi-function Fan



Timer Setting

1 / 2 / 4 / 8 H



Reversible

Summer / Winter Modes



Remote control



6 Wind Speeds

With nature wind mode



Customizable Light

10%-100%
3000-6000K

Image: An illustration highlighting the multi-function remote control with buttons for timer setting, reversible mode, 6 wind speeds, and customizable light.

- **Fan On/Off:** Press the power button to turn the fan on or off.
- **Fan Speed:** Select from 6 adjustable wind speeds (Levels 1-2 for low/comfortable, 3-4 for medium/natural, 5-6 for high/cooling).
- **Natural Wind Mode:** Activates a varying wind speed to simulate natural breezes.
- **Light On/Off:** Press the light button to toggle the light.
- **Light Dimming:** Use the '+' and '-' buttons to adjust light brightness from 10% to 100%.
- **Color Temperature (CCT):** Cycle through 3000K (warm white), 4000K (natural white), and 6000K (cold white) using the CCT button.
- **Reversible Function:** Press the reverse button to change the direction of the fan blades (downward for summer cooling, upward for winter heat circulation).
- **Timer:** Set the fan to turn off automatically after 1, 2, or 4 hours.
- **Anti-Theft Function:** (If available on your model) Activates the light for 5 minutes every two hours.

5.2. Memory Function

The fan retains the last light brightness, color temperature, and fan speed settings when turned off via the remote or wall switch (if off for at least 10 seconds). If turned on within 10 seconds, the light color temperature may switch.



Image: Visual guide explaining the memory function: select desired light settings, turn off for 10+ seconds, and the settings will be remembered for the next use.

5.3. Wall Switch Control

The fan is compatible with conventional wall switches for basic on/off control of both the fan and light. Do not connect to dimmer switches or fan gear switches.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Use a soft brush or lint-free cloth to prevent scratching the finish. Do not use water or harsh detergents.
- **Blade Balance:** Check fan blades periodically for tightness and balance. Minor wobbling is normal, but excessive wobble may indicate loose screws or unbalanced blades.
- **Light Kit:** The LED light kit is designed for long life and is replaceable if needed.

7. Troubleshooting

If you experience issues with your fan, refer to the following common problems and solutions.

- **Fan does not start:** Check power supply, ensure all wire connections are secure, and verify remote control batteries.
- **Light does not work:** Check wire connections to the light kit, ensure power is on.
- **Remote control not responding:** Replace remote batteries (2 AAA required, included). Ensure the remote is within range and not obstructed.
- **Excessive fan wobble:** Check that all blade screws are tightened. Ensure the mounting bracket is securely

installed.

8. Warranty and Support

addlon offers comprehensive support for your product.

- **Motor Warranty:** Up to 120 months (10 years).
- **Other Parts Warranty:** 2 years.
- **Customer Support:** 24-hour customer support is available for any questions during installation or use.



Image: Contact information for addlon customer support, available 24 hours a day.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question