

[manuals.plus](#) /› [Linksys](#) /› [Linksys 5G AX1800 Mobile Hotspot \(Model FGHSAX1800-AH\) User Manual](#)

Linksys FGHSAX1800-AH

Linksys 5G AX1800 Mobile Hotspot User Manual

Model: FGHSAX1800-AH

INTRODUCTION

The Linksys 5G AX1800 Mobile Hotspot is a portable device designed to provide high-speed 5G and WiFi 6 connectivity for multiple devices. With its ultra-thin design and long battery capacity, it allows you to stay connected on the go. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your mobile hotspot.

Key features include:

- Portable 5G supersonic speed and bandwidth.
- WiFi 6 speeds up to 1.8 Gbps (AX1800).
- Supports connection for 15+ devices simultaneously.
- Ultra-thin and lightweight design for maximum convenience.
- Long-lasting battery for extended use.
- Powered by leading-edge 5G technology by Qualcomm.



Figure 1: Front view of the Linksys 5G AX1800 Mobile Hotspot, showing LED indicators for battery, 5G/LTE, and Wi-Fi status.

SETUP

1. Install SIM Card

The Linksys 5G AX1800 Mobile Hotspot requires a Nano-SIM card for 5G/LTE connectivity. Ensure the device is powered off before inserting the SIM card.

1. Locate the SIM card slot cover on the side of the device.
2. Gently open the cover.
3. Insert the Nano-SIM card into the slot with the gold contacts facing down and the notched corner aligned correctly.
4. Close the SIM card slot cover securely.



Figure 2: Side view of the mobile hotspot, highlighting the SIM card slot cover.

2. Charge the Device

Before first use, fully charge the mobile hotspot. Use the provided charging cable and a compatible USB power adapter.

1. Connect one end of the USB cable to the charging port on the device.
2. Connect the other end to a USB power adapter or a computer's USB port.
3. The battery indicator LED will show charging status. Allow several hours for a full charge.



Figure 3: Bottom view of the mobile hotspot, showing the USB-C charging port.

3. Power On/Off

To power on the device, press and hold the power button located on the side until the LED indicators light up.

To power off, press and hold the power button again until the indicators turn off.



Figure 4: Side view of the mobile hotspot, indicating the location of the power button.

OPERATING INSTRUCTIONS

1. Connecting Devices to Wi-Fi

Once powered on, the mobile hotspot will broadcast a Wi-Fi network. You can connect up to 15+ devices simultaneously.

1. On your device (smartphone, laptop, tablet), open the Wi-Fi settings.
2. Search for available Wi-Fi networks.
3. Select the network name (SSID) of your Linksys Mobile Hotspot. The default SSID and password are usually found on a sticker inside the device or on its packaging.
4. Enter the Wi-Fi password when prompted.
5. Your device should now be connected to the internet via the mobile hotspot.

2. Understanding LED Indicators

The LED indicators on the front of the device provide important status information:

- **Battery Indicator:** Shows the current battery level and charging status.
- **5G/LTE Indicator:** Indicates the mobile network connection status (e.g., solid blue for 5G, solid green for LTE, blinking for searching).
- **Wi-Fi Indicator:** Shows if the Wi-Fi network is active and broadcasting.



Figure 5: Angled front view of the mobile hotspot, clearly showing the LED indicators for battery, 5G/LTE, and Wi-Fi.

3. Accessing the Web Management Interface

For advanced settings, such as changing the Wi-Fi name or password, managing connected devices, or checking data usage, you can access the device's web management interface.

1. Ensure your device is connected to the mobile hotspot's Wi-Fi network.
2. Open a web browser (e.g., Chrome, Firefox, Safari).
3. Enter the default IP address for the hotspot (usually 192.168.1.1 or 192.168.0.1, refer to the device's documentation or sticker for the exact address) into the address bar and press Enter.
4. Log in using the default username and password (also found on the device sticker or documentation). It is highly recommended to change the default password for security.

MAINTENANCE

1. Battery Care

- Avoid exposing the device to extreme temperatures.
- Do not leave the device fully discharged for extended periods.
- Use only the original or certified compatible charging accessories.

2. Cleaning

Wipe the device with a soft, dry, lint-free cloth. Do not use liquid cleaners or aerosols directly on the device.

3. Firmware Updates

Periodically check for firmware updates through the web management interface. Keeping the firmware updated ensures optimal performance and security.

TROUBLESHOOTING

No Internet Connection

- Ensure the SIM card is correctly inserted and activated with a data plan.
- Check the 5G/LTE indicator on the device. If it's blinking or off, the device may be searching for a network or have no signal.
- Restart the mobile hotspot and your connected device.
- Verify that your data plan has not been exhausted.

Slow Wi-Fi Speed

- Move closer to the mobile hotspot to improve signal strength.
- Reduce the number of connected devices or data-intensive activities.
- Check for network congestion in your area.

Device Not Connecting to Hotspot

- Ensure the Wi-Fi indicator on the hotspot is active.
- Double-check the Wi-Fi password.
- Restart both the hotspot and the device you are trying to connect.

Factory Reset

If issues persist, you may perform a factory reset. This will revert all settings to their default values, including Wi-Fi name and password. Refer to the device's specific instructions for the reset procedure, usually involving a small reset button.

SPECIFICATIONS

Feature	Detail
Brand	Linksys
Model Name	FGHSAX1800
Item Model Number	FGHSAX1800-AH
Connectivity Technology	5G
Wi-Fi Standard	WiFi 6 (AX1800)
Data Transfer Rate	Up to 1.8 Gigabits Per Second
Frequency Band Class	Dual-Band

Antenna Type	Internal
Special Features	Access Point Mode
Included Components	SIM CARD SLOT
Voltage	12 Volts
Package Dimensions	14 x 7.5 x 1.55 cm
Item Weight	185 g

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Linksys support website. You can typically find FAQs, driver downloads, and contact information for customer service there.

Linksys Official Support: <https://www.linksys.com/support>