



[Manuals.plus](#) /

› [Finger Rock](#) /

› Finger Rock M24 Sniper Rifle Model Building Blocks Instruction Manual

## Finger Rock M24

# Finger Rock M24 Sniper Rifle Model Building Blocks Instruction Manual

Model: M24 (Item No. 23018)

[Introduction](#)

[Safety Information](#)

[Package Contents](#)

[Assembly Instructions](#)

[Operating](#)

[Instructions](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Customer Support](#)

## 1. INTRODUCTION

Thank you for choosing the Finger Rock M24 Sniper Rifle Model Building Blocks Set. This 1086-piece kit allows you to construct a detailed 1:1 scale replica of the M24 sniper rifle, complete with a functional shooting mechanism. This manual provides comprehensive instructions to guide you through the assembly process and ensure proper operation. Please read all instructions carefully before beginning assembly.



Image 1.1: The completed Finger Rock M24 Sniper Rifle Model, featuring 1086 pieces and recommended for ages 14 and up.

## 2. SAFETY INFORMATION

- **Choking Hazard:** This product contains small parts and is not suitable for children under 3 years of age. Keep all small components away from young children to prevent accidental ingestion.
- **Age Recommendation:** This building set is recommended for ages 14 and up due to its complexity and the presence of small parts.
- **Proper Use:** This model is a toy and should be used responsibly. Do not aim the shooting mechanism at people or animals. Use only the provided or approved projectiles.
- **Adult Supervision:** Adult supervision is recommended during assembly and play, especially for younger users within the recommended age range.
- **Disposal:** Dispose of packaging materials properly and keep them away from children.

## 3. PACKAGE CONTENTS

Before starting assembly, please verify that all components are present in your package:

- 1086 Building Block Pieces (sorted into bags)
- 1 Instruction Manual (this document)
- Projectile blocks for shooting function

If any parts are missing, please refer to the "Customer Support" section for assistance.

## 4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your M24 Sniper Rifle model. The instructions are presented visually, with each

step building upon the previous one. It is recommended to sort pieces by type and size before beginning.

## 4.1 General Assembly Overview




Image 4.1: Overview of the M24 model's main components and features.

The model features a loading pull bolt, an adjustable magnifier (scope), a barrel, a retractable stand (bipod), a trigger, a removable clip (magazine), and a stock. The launch function allows for projectile firing.

## 4.2 Step-by-Step Assembly

1. **Unpack and Sort:** Carefully open all bags containing building blocks. It is highly recommended to sort the pieces by color, size, and type to facilitate the assembly process.
2. **Follow the Visual Guide:** The included instruction manual provides detailed visual steps. Each step illustrates the specific pieces required and how they connect. Pay close attention to the number of pieces indicated for each step.
3. **Base Structure:** Begin by constructing the core frame of the rifle, as shown in the initial steps of the manual. Ensure all connections are firm and secure.
4. **Adding Details:** Progress through the manual, adding sub-assemblies such as the stock, barrel, scope, and bipod.
5. **Magazine and Trigger Mechanism:** Assemble the magazine and the internal trigger mechanism according to the diagrams. These parts are crucial for the shooting function.
6. **Final Touches:** Attach any remaining decorative or functional elements.



Image 4.2: Visual guide for key assembly and operational steps, including loading and firing.

If you encounter difficulties with the visual instructions, consider using a translation app like Google Lens on the physical manual for text assistance, as some manuals may contain non-English text.

## 5. OPERATING INSTRUCTIONS

---

Once assembled, your Finger Rock M24 Sniper Rifle model can simulate firing. Follow these steps for safe and proper operation of the shooting function:

1. **Load Projectiles:** Insert the provided block projectiles into the magazine. Ensure they are seated correctly.
2. **Insert Magazine:** Securely insert the loaded magazine into the rifle's receiver.
3. **Load Chamber:** Pull back the loading bolt mechanism firmly and then push it forward until it clicks into place. This action loads a projectile into the firing chamber.
4. **Aim:** Use the adjustable magnifier (scope) to aim at a safe target. Ensure no people or animals are in the line of fire.
5. **Fire:** Gently press the trigger to launch the projectile.
6. **Eject Spent Casing (Simulated):** After firing, pull back the loading bolt again to simulate ejecting a spent casing and prepare for the next shot.

## Building An Exquisite Model Kit With Family Or Friends



Image 5.1: Detailed steps for loading the magazine, operating the bolt, and firing the model.

### 5.1 Adjustable Magnifier

The scope on your M24 model features an adjustable magnifier. Rotate the adjustment dials on the scope to change the simulated magnification effect, as illustrated below.



Image 5.2: Demonstrating the adjustable magnifier's visual effects.

## 6. MAINTENANCE

To ensure the longevity and proper function of your Finger Rock M24 Sniper Rifle model, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to gently wipe down the model and remove dust. Avoid using harsh chemicals or abrasive cleaners, as these can damage the plastic.
- **Storage:** Store the model in a cool, dry place away from direct sunlight and extreme temperatures. Prolonged exposure to heat or sunlight can cause deformation or discoloration of the plastic blocks.

- **Handling:** Handle the model with care to prevent accidental breakage of delicate parts.
- **Loose Connections:** Periodically check for any loose connections between blocks and press them firmly together to re-secure.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Missing parts during assembly.	Packaging error or accidental loss.	Contact customer service with a list of missing bricks. Refer to the "Customer Support" section.
Difficulty understanding instructions.	Visual complexity or language barrier (if manual is not in English).	Carefully review each visual step. Use a translation app (e.g., Google Lens) for any non-English text in the physical manual.
Shooting mechanism not working.	Incorrect assembly of trigger/bolt mechanism, or projectile not loaded correctly.	Re-check assembly steps for the trigger and bolt. Ensure projectiles are fully inserted into the magazine and the bolt is pulled back and pushed forward completely.
Blocks not fitting together securely.	Incorrect block orientation or manufacturing variation.	Ensure blocks are oriented correctly. Apply firm, even pressure. If a block consistently does not fit, try an alternative piece of the same type if available.

## 8. SPECIFICATIONS

**Model Name:** M24 Sniper Rifle

**Item Model Number:** 23018

**Brand:** Finger Rock

**Number of Pieces:** 1086

**Scale:** 1:1 (approximate)

**Product Dimensions (Assembled):** Approximately 42 x 5.9 x 10 inches (106.7 x 15 x 25.4 cm)

**Item Weight:** Approximately 2.44 pounds (1.11 kg)

**Recommended Age:** 14 years and up

**Features:** Shootable function, adjustable magnifier, retractable stand, removable magazine.



Image 8.1: Approximate dimensions of the assembled M24 Sniper Rifle model.

## 9. CUSTOMER SUPPORT

---

For any questions, concerns, or assistance with missing parts, please contact our customer service team. We are committed to providing the best service to ensure your satisfaction.

- **Missing Parts:** If you find any missing bricks, please contact the seller directly. Provide details of the missing parts (e.g., step number in the manual, type, and quantity of the brick). The seller will arrange for the corresponding parts to be sent to you.
- **General Inquiries:** For other product-related questions, please reach out to the seller through the platform where the purchase was made.

We value your experience and are here to help.

