

[Manuals.plus](#) /

> [Meonum](#) /

> Meonum 500W Portable Electric Space Heater (Model Meonum-Space Heater-0584) Instruction Manual

Meonum Meonum-Space Heater-0584

Meonum 500W Portable Electric Space Heater Instruction Manual

Model: Meonum-Space Heater-0584 | Brand: Meonum

1. IMPORTANT SAFETY INFORMATION

Please read all safety warnings and instructions before using this appliance to prevent injury or damage. Keep this manual for future reference.

- **Electrical Safety:** A hot or loose plug may indicate a worn outlet. Inspect and replace faulty outlets before use to prevent overheating.
- **Supervision:** Do not operate the heater unattended for long periods.
- **Flammable Materials:** Keep the heater away from flammable materials such as straw, paper, or fabrics.
- **Stability:** Use a stable chain or other secure fixing tools if needed to ensure the heater is firmly positioned.
- **Unplug When Not in Use:** Always turn off and unplug the unit when not in use.
- **Placement:** This is a wall socket portable heater for indoor use in small spaces. Avoid using in areas with excessive moisture or where it could be submerged.
- **Certification:** The heater has been CE safety certified.

2. PRODUCT OVERVIEW

The Meonum 500W Portable Electric Space Heater is designed for efficient and quiet heating in small indoor spaces. Its compact, wall-mounted design saves floor space and eliminates cord hazards. Featuring an adjustable thermostat, digital LED display, built-in timer, and remote control, it offers convenient and customizable warmth.

Key Features:

- **Power:** 500 watts, 110-220 volt, 50-60HZ.
- **Rotating Plug:** Convenient 180° rotating plug with 2 prongs to fit any angle socket.
- **Digital Thermostat:** Adjustable temperature from 60°F (15°C) to 90°F (32°C) with LED display.
- **Built-in Timer:** 1 to 12 hour timer in 1-hour increments.
- **Remote Control:** For easy operation from a distance.
- **Safety Features:** Overheat protection.
- **Compact Design:** 5.5 inch round, wall-mounted to save space.

- **Heating Coverage:** Up to 100 square feet (depending on room sealing).



Image: Meonum 500W Portable Electric Space Heater showing its digital display and included remote control.

3. SETUP

1. **Unpack:** Carefully remove the heater and remote control from the packaging.
2. **Plug Rotation:** Locate the button under the plug. Press this button to adjust the degree of rotation of the plug (180°) to fit your wall outlet orientation.
3. **Plug In:** Insert the heater directly into a standard 110-220 volt wall outlet. Ensure the outlet is in good condition and not loose.
4. **Power On:** Locate the on/off kill switch on the side of the heater and turn it on. The LED display will illuminate.



Image: Close-up of the Meonum heater demonstrating the 180° rotatable wall plug design for flexible placement.

4. OPERATING INSTRUCTIONS

Using the Digital Display and Buttons:

- **Power On/Off:** Use the kill switch on the side of the unit.
- **Temperature Adjustment:** Use the '+' and '-' buttons on the top of the unit to set your desired temperature between 60°F (15°C) and 90°F (32°C). The heater will automatically turn on/off to maintain this temperature.
- **Fan Speed:** Press the 'MENU' button to cycle through fan speed settings (e.g., Low, High).
- **Timer Setting:** Press the 'MENU' button repeatedly until the timer icon appears. Use the '+' and '-' buttons to set the desired operating time from 1 to 12 hours.

Using the Remote Control:

The remote control provides convenient access to all functions from a distance.

- **Power Button:** Turns the heater on or off.
- **Timing Button:** Activates and adjusts the timer function (1-12 hours).
- **Wind Speed Button:** Cycles through fan speed settings (Low, High).
- **Heat Up/Cool Down Buttons:** Adjusts the target temperature up or down.



Image: Close-up of the heater's digital display showing temperature settings and control buttons.

Your browser does not support the video tag.

Video: Official product video demonstrating the Meonum 500W Desk Heater's quiet operation and fast heating for small spaces.

5. MAINTENANCE

- **Cleaning:** Ensure the heater is unplugged and completely cool before cleaning. Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or allow water to enter the unit.
- **Storage:** When not in use, store the heater in a cool, dry place.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in, power switch off, or faulty outlet.	Ensure unit is securely plugged in. Turn the side power switch to 'ON'. Check the outlet with another appliance.
Heater stops working unexpectedly.	Overheat protection activated.	Unplug the unit and allow it to cool down for 30 minutes. Check for obstructions around the air vents. Plug back in and restart.
Remote control not working.	Dead batteries or obstruction.	Replace remote control batteries. Ensure no obstructions between remote and heater.
Loose fit in wall outlet.	Worn wall outlet.	Inspect and replace faulty outlets before use to prevent overheating.

7. SPECIFICATIONS

- **Brand:** Meonum
- **Model Number:** Meonum-Space Heater-0584
- **Color:** White
- **Power:** 500W
- **Voltage:** 110-220V
- **Frequency:** 50-60HZ
- **Product Dimensions:** 5.5"D x 2"W x 5.5"H
- **Item Weight:** 1.63 pounds
- **Heating Coverage:** Up to 100 square feet
- **Temperature Range:** 60°F (15°C) to 90°F (32°C)
- **Number of Speeds:** 3 (Fan settings)
- **Mounting Type:** Wall Mount
- **Certification:** CE Safety Certified

8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Meonum Portable Electric Space Heater, please contact the manufacturer directly through your purchase platform or refer to the contact information provided with your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CLP3B5ZB>

More documents and user manuals: <https://manuals.plus/>