

## Vactidy C6

# Vactidy C6 Corded Vacuum Cleaner User Manual

Model: C6

## 1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always disconnect the vacuum cleaner from the power outlet before cleaning or performing maintenance.
- Do not use the appliance outdoors or on wet surfaces.
- Do not allow children to operate the vacuum cleaner. Close supervision is necessary when used near children.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without the dust cup and/or filters in place.
- Inspect the power cord and plug for damage before each use. Do not use if the cord or plug is damaged.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Store the appliance indoors in a cool, dry place.

## 2. PRODUCT OVERVIEW

The Vactidy C6 is a powerful and versatile corded vacuum cleaner designed for efficient cleaning of various floor types. It features a robust motor, a long power cable, and a multi-layer filtration system.



Image 1: Vactidy C6 Corded Vacuum Cleaner and included accessories, including the main unit, extension tube, floor brush, crevice tool, brush tool, and spare filters.

## Package Contents:

- Main Motor Unit
- Extension Tube
- Floor Brush
- Crevice Tool
- 2-in-1 Brush Tool
- Wall Mount Bracket
- Power Cable (7 meters)
- User Manual

- Additional HEPA Filters (typically 2 included)

### 3. ASSEMBLY AND SETUP

---

Follow these steps to assemble your Vactidy C6 vacuum cleaner:

1. **Attach the Extension Tube:** Insert the extension tube into the main motor unit until it clicks securely into place.
2. **Attach the Floor Brush:** Connect the floor brush to the other end of the extension tube, ensuring it locks firmly.
3. **Alternative Attachments:** For handheld use or specific cleaning tasks, you can directly attach the crevice tool or 2-in-1 brush tool to the main motor unit or the extension tube.
4. **Wall Mount Installation (Optional):** The included wall mount bracket can be installed to store the vacuum. Choose a suitable location, mark the drilling points, drill holes, insert wall plugs, and secure the bracket with screws.



Image 2: Illustration of the Vactidy C6 components, showing how the main unit, extension tube, and various attachments connect for different cleaning configurations.

### 4. OPERATING INSTRUCTIONS

---

Using your Vactidy C6 vacuum cleaner is straightforward:

1. **Power Connection:** Plug the 7-meter power cable into a suitable electrical outlet. The long cable provides extended reach without frequent outlet changes.
2. **Power On/Off:** Press the power button located on the main motor unit to turn the vacuum cleaner on or off.
3. **Suction Modes:** The vacuum cleaner offers two speed settings for different cleaning needs. Press the speed control button to switch between standard and powerful suction modes.
4. **Floor Adaptability:** The floor brush is designed to adapt to various floor types, including hard floors (wood, tile) and carpets. Adjust the brush settings if available, or rely on the powerful suction for effective cleaning on both surfaces.
5. **Using Attachments:**
  - **Floor Brush:** Ideal for general cleaning of large floor areas.
  - **Crevice Tool:** Use for narrow gaps, corners, and hard-to-reach spaces.

- **2-in-1 Brush Tool:** Suitable for upholstery, curtains, keyboards, and delicate surfaces.



Image 3: A user demonstrating the Vactidy C6 vacuum cleaner in action on a hard floor, highlighting its ease of use for everyday cleaning.

## 5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your Vactidy C6 vacuum cleaner.

### 5.1 Emptying the Dust Cup

The C6 features an 800ml dust cup. Empty it regularly to maintain suction power.

1. **Disconnect Power:** Ensure the vacuum cleaner is unplugged from the power outlet.
2. **Remove Dust Cup:** Press the dust cup release button and detach the dust cup from the main motor unit.
3. **Empty Contents:** Position the dust cup over a trash bin and press the bottom release button to open the lid and empty the collected debris.
4. **Reattach Dust Cup:** Close the dust cup lid and reattach it to the main motor unit until it clicks securely.

### 5.2 Cleaning the Filters

The C6 uses a 3-layer high-efficiency filtration system, including a HEPA filter. Clean filters regularly (e.g., monthly, or more often with heavy use) to prevent clogging and maintain suction.

1. **Access Filters:** With the dust cup removed, locate and carefully remove the internal filters (pre-filter and HEPA filter).
2. **Clean Filters:** Tap the filters gently over a trash bin to remove loose dust. For a deeper clean, rinse the filters under cold running water.
3. **Dry Filters: IMPORTANT:** Allow filters to air dry completely for at least 24 hours before reinserting them. Do not use the vacuum with wet filters.
4. **Reassemble:** Once completely dry, place the filters back into the dust cup and reattach the dust cup to the main unit.

### 5.3 Cleaning the Floor Brush

Periodically check the floor brush for tangled hair or debris. Use scissors to cut away any tangled hair and remove it. Ensure the brush roll spins freely.

## 6. TROUBLESHOOTING

If you encounter issues with your Vactidy C6, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on.	Not plugged in. Power outlet malfunction. Damaged power cord/plug.	Ensure the power cord is securely plugged into a working outlet. Test the outlet with another appliance. Do not use if damaged; contact customer support.
Low suction power.	Full dust cup. Clogged filters. Blockage in nozzle, tube, or hose. Brush roll tangled.	Empty the dust cup. Clean or replace the filters (ensure they are completely dry). Check for and remove any blockages. Clean the brush roll.
Vacuum overheats and shuts off.	Clogged filters. Blockage in airflow. Prolonged use (anti-overheating protection activated).	Clean or replace filters. Check for and remove any blockages. Turn off the vacuum and allow it to cool down for at least 30 minutes before restarting.
Unusual noise.	Blockage in the brush roll or air path. Loose component.	Check for and remove any blockages. Ensure all components are securely assembled.

If the problem persists after trying these solutions, please contact Vactidy customer support.

## 7. SPECIFICATIONS

Brand	Vactidy
Model Number	C6
Power	600 Watts
Suction Power	Up to 25 KPA
Dust Cup Capacity	800 ml
Cable Length	7 meters
Filter Type	HEPA Filter (3-layer filtration system)
Dimensions (L x W x H)	40 x 25 x 15 cm
Item Weight	2.92 Kilograms
Special Features	Compact, Lightweight, 3-in-1 design, Anti-overheating protection, Telescopic metal tube
Included Components	Motor unit, Telescopic bar, Floor brush, 2-in-1 brush, Long crevice nozzle, Wall mount, User manual, 2 accessory shelves

## 8. WARRANTY AND SUPPORT

Vactidy is committed to providing high-quality products and customer satisfaction.

### Warranty Information:

- **Money-back Guarantee:** The product typically includes a 30-day money-back guarantee.
- **Product Warranty:** A warranty of up to 24 months is generally provided. Please refer to your purchase documentation or the official Vactidy website for specific terms and conditions applicable to your region.

### Customer Support:




For any questions, concerns, or technical assistance, please contact Vactidy customer support. Details can usually be found on the product packaging, the official Vactidy website, or through your retailer.

Vactidy aims to provide a responsive service team to assist you.



© 2024 Vactidy. All rights reserved.

### Related Documents - C6

	<p><a href="#">Vactidy Blitz C6 Corded Vacuum Cleaner Instruction Manual</a></p> <p>Comprehensive instruction manual for the Vactidy Blitz C6 corded vacuum cleaner. This guide covers essential safety precautions, assembly steps, operating instructions, and maintenance procedures for optimal performance.</p>
	<p><a href="#">Vactidy T7 Robot Aspirapolvere Lavapavimenti: Manuale di Installazione e Guida Utente</a></p> <p>Guida completa all'installazione e all'uso del robot aspirapolvere lavapavimenti Vactidy T7. Scopri le funzionalità WiFi, App, Alexa, Siri e Google per una pulizia efficiente della tua casa.</p>
	<p><a href="#">Vactidy T6 Robot Vacuum Cleaner User Manual</a></p> <p>Comprehensive user manual for the Vactidy T6 Robot Vacuum Cleaner, covering safety instructions, product operation, maintenance, specifications, and troubleshooting.</p>



## Vactidy T7 Robot Vacuum Cleaner User's Manual

User's manual for the Vactidy T7 Robot Vacuum Cleaner, covering safety instructions, product description, operation, maintenance, specifications, and troubleshooting. Learn how to use and care for your Vactidy T7 robot vacuum.



## VACTIDY T6 Robot Vacuum Cleaner User Manual

Comprehensive user manual for the VACTIDY T6 Robot Vacuum Cleaner, covering safety, components, operation, app connection, maintenance, specifications, and troubleshooting.



# VACTIDY T6 Robot Vacuum Cleaner User's Manual

The VACTIDY T6 Robot Vacuum Cleaner User's Manual provides comprehensive instructions for safe operation, maintenance, and troubleshooting. Learn about product features, charging, cleaning modes, app configuration, and how to ensure optimal performance for your robotic vacuum.