

[Manuals.plus](#) /

› [MisterVac](#) /

› MisterVac Replacement Hose for Parkside PWD 30 C1 Vacuum Cleaner, Model 419173_2210

MisterVac 419173_2210

MisterVac Replacement Hose for Parkside PWD 30 C1 Vacuum Cleaner

Model: 419173_2210

1. INTRODUCTION

This manual provides instructions for the proper installation, operation, and maintenance of your MisterVac replacement hose, designed for compatibility with the Parkside PWD 30 C1 industrial vacuum cleaner. Please read this manual thoroughly before using the product to ensure safe and efficient operation.

2. SAFETY INFORMATION

- Always ensure the vacuum cleaner is unplugged before attaching or detaching the hose or any accessories.
- Inspect the hose for any damage (cracks, punctures) before each use. Do not use a damaged hose.
- Keep the hose away from sharp objects, excessive heat, and open flames.
- Do not use the hose to pick up flammable liquids, hot ashes, or large, sharp debris that could cause internal damage.
- Ensure all connections are secure to prevent loss of suction or accidental disconnection during operation.

3. PACKAGE CONTENTS

Your MisterVac replacement hose package includes:

- 1x Flexible Vacuum Hose (approx. 1.9 meters)
- 1x Tool Adapter (approx. 0.11 meters)

4. SETUP AND INSTALLATION

Follow these steps to properly install the replacement hose onto your Parkside PWD 30 C1 vacuum cleaner:

1. **Prepare the Vacuum Cleaner:** Ensure your Parkside PWD 30 C1 vacuum cleaner is turned off and unplugged from the power source.
2. **Attach Hose to Vacuum:** Take one end of the replacement hose. This end features a swivel connection. Align it with the

suction inlet on your vacuum cleaner. Push and twist clockwise until it is securely locked in place.

3. **Attach Tool Adapter:** The other end of the hose is designed to connect to the included tool adapter. Push the tool adapter firmly into the hose end until it clicks or feels secure. This adapter allows for connection to various vacuum accessories or power tools.



Image 1: The MisterVac replacement hose connected to a compatible vacuum cleaner, showing the secure attachment points.



Image 2: A detailed view of the hose end and the separate tool adapter, ready for assembly.

5. OPERATING INSTRUCTIONS

Once the hose is securely attached, you can begin using your vacuum cleaner. The MisterVac replacement hose is designed for flexibility and robustness, making it suitable for various industrial and workshop applications.

- **General Use:** Connect your desired vacuum accessory (e.g., floor nozzle, crevice tool) to the tool adapter. Ensure the accessory is firmly attached.
- **Power Tool Connection:** The tool adapter can be connected to the dust extraction port of compatible power tools (e.g., sanders, saws) for efficient dust collection during operation.
- **Flexibility:** The hose's flexible design allows for easy maneuverability around obstacles and during various cleaning or dust extraction tasks.



Image 3: The flexible hose in action, demonstrating its utility in different work environments.

6. MAINTENANCE

Regular maintenance will extend the life of your replacement hose:

- **Cleaning:** Periodically clean the inside and outside of the hose. For internal cleaning, you can run water through it (ensure it's completely dry before reattaching to the vacuum) or use a long brush to dislodge debris. Wipe the exterior with a damp cloth.
- **Inspection:** Regularly check the hose for any signs of wear, tears, or blockages. Pay close attention to the connection points.
- **Storage:** Store the hose in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid kinking or sharply bending the hose during storage to prevent damage.

7. TROUBLESHOOTING

If you encounter issues with your replacement hose, consider the following:

- **Reduced Suction:**
 - Check all connections (hose to vacuum, adapter to hose, accessory to adapter) to ensure they are secure.
 - Inspect the hose for blockages. Disconnect the hose and carefully look through it, or use a long, blunt object to clear any obstructions.
 - Ensure the vacuum cleaner's dust bag/container is not full and its filters are clean.
- **Hose Damage:** If the hose is visibly damaged (e.g., a tear or hole), it will lead to a loss of suction and should be replaced.

8. SPECIFICATIONS

Feature	Specification
Brand	MisterVac
Model Number	419173_2210
Compatibility	Parkside PWD 30 C1 Industrial Vacuum Cleaner
Hose Length	Approx. 1.9 meters
Tool Adapter Length	Approx. 0.11 meters
Total Configurable Length	Up to 30 meters (with additional compatible hose segments, ASIN: B0C3HG7R52)
Material	Rubber
Color	Black
Connection Type	Swivel on both sides (handle and tool adapter)

9. WARRANTY AND SUPPORT

For warranty information or technical support regarding your MisterVac replacement hose, please refer to the documentation provided with your original purchase or contact MisterVac customer service directly. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CLP9X3CP>

More documents and user manuals: <https://manuals.plus/>