

Xoopar Ice-P (XP61145)

Xoopar Ice-Powerbank User Manual

Model: Ice-P (XP61145)

1. INTRODUCTION

Thank you for choosing the Xoopar Ice-Powerbank. This portable charger is designed to provide convenient power for your mobile devices and features an integrated LED touch light. Made with GRS-certified recycled plastic, it combines functionality with environmental responsibility. Please read this manual carefully to ensure proper use and maintenance of your device.

2. PRODUCT OVERVIEW

The Xoopar Ice-Powerbank is a compact and versatile portable charger. It features a 5000 mAh high-density battery, a built-in 10 cm charging cable with both Lightning and USB-C outputs, and a USB-C input for recharging the power bank itself. An integrated LED touch light provides illumination when needed.



Figure 2.1: The Xopar Ice-Powerbank, shown in red.

Key Features:

- **5000 mAh Battery:** Provides up to 2 full charges for most smartphones.
- **Integrated LED Touch Light:** Offers convenient illumination.
- **Built-in 10 cm Cable:** Features both Lightning and USB-C outputs for broad device compatibility.
- **USB-C Input:** For recharging the power bank.
- **Compact and Portable:** Slim design for easy carrying.
- **Sustainable Design:** Made from GRS-certified recycled plastic.




Figure 2.2: The integrated LED touch light provides illumination.

3. SETUP

3.1 Charging the Power Bank

Before first use, fully charge your Xoopar Ice-Powerbank. To charge the power bank:

1. Locate the USB-C input port on the power bank.
2. Connect a USB-C charging cable (not the built-in output cable) to this port.
3. Connect the other end of the USB-C cable to a compatible USB power adapter (e.g., a wall charger) or a computer's USB port.
4. The LED indicator lights on the power bank will illuminate to show the charging status. Once all indicators are solid, the power bank is fully charged.

Batterie 5000 mAh avec lumière tactile intégrée

5000 mAh battery with integrated touch light



Figure 3.1: Diagram illustrating the USB-C input port and the dual output cable (USB-C and Lightning).

4. OPERATING INSTRUCTIONS

4.1 Charging Your Devices

The Xoopar Ice-Powerbank features a built-in 10 cm cable with both Lightning and USB-C connectors, allowing you to charge a wide range of smartphones and tablets.

1. Pull out the built-in cable from its storage slot on the power bank.
2. Select the appropriate connector (Lightning for Apple devices or USB-C for compatible Android and other devices).
3. Plug the connector into your device's charging port.
4. The power bank will automatically begin charging your device. The LED indicators will show the remaining battery level of the power bank.
5. Once charging is complete, disconnect your device and return the built-in cable to its storage slot.

Chargeur-lampe de poche, idéal pour la vie quotidienne
flashlight charger, ideal for everyday life



Figure 4.1: The power bank actively charging a smartphone.

4.2 Using the LED Touch Light

The Ice-Powerbank includes an integrated LED touch light for convenience.

- To turn the LED light ON, gently touch the designated touch area on the power bank.
- To turn the LED light OFF, touch the same area again.



Figure 4.2: The LED light can be used for illumination in various situations.

5. MAINTENANCE

5.1 Cleaning

To clean your power bank, wipe it with a soft, dry cloth. Do not use harsh chemicals, cleaning solvents, or strong detergents. Avoid getting moisture into any openings.

5.2 Storage

Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, ensure the power bank is charged to approximately 50% to prolong battery life.

5.3 Battery Care

- Avoid fully discharging the power bank frequently.
- Do not expose the power bank to temperatures above 45°C (113°F) or below 0°C (32°F).
- The power bank contains an integrated lithium polymer battery that is not user-replaceable. Do not attempt to open the device.

6. TROUBLESHOOTING

If you encounter issues with your Xoopar Ice-Powerbank, please refer to the following common solutions:

- **Power bank not charging:** Ensure the USB-C input cable is securely connected to both the power bank and the power source. Try a different USB-C cable or power adapter.
- **Device not charging from power bank:** Ensure the built-in cable is fully inserted into your device's charging port. Check if the power bank itself has sufficient charge. Try a different device to rule out a device-specific issue.
- **LED light not working:** Ensure the power bank has some charge. Gently touch the touch area to activate the light. If it still doesn't work, the power bank might be fully discharged.
- **Slow charging:** Ensure your device and the power bank are compatible with the charging speed. Some devices may charge slower than others.

If the problem persists after trying these steps, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Name	Ice-P
Model Number	XP61145
Battery Capacity	5000 mAh
Battery Type	Lithium Polymer
Input	USB Type-C (5V)
Output	Built-in Lightning & USB Type-C (3 Amps)
Special Features	Integrated LED Touch Light, Pocket Size, Slim Design
Compatible Devices	Smartphones, Tablets, Speakers
Item Weight	85 Grams
Manufacturer	XOOPAR
Country of Origin	China

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The Xoopar Ice-Powerbank comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

8.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your Xoopar Ice-Powerbank, please contact your retailer or visit the official Xoopar website for support contact information.

