

Manuals.plus /
› Accutime /
› Accutime Pac-Man Power-Ups and Ghosts Analog Watch User Manual

Accutime PAC8002STK

Accutime Pac-Man Power-Ups and Ghosts Analog Watch User Manual

Model: PAC8002STK | Brand: Accutime

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Accutime Pac-Man Power-Ups and Ghosts Analog Watch. This manual provides essential information for the proper setup, operation, and maintenance of your new timepiece. This watch features a classic analog display with a unique Pac-Man themed design, showcasing iconic power-ups and ghosts on the watch face.



Figure 1: Angled view of the Accutime Pac-Man Analog Watch, highlighting the watch face with various Pac-Man elements and the black gunmetal strap.

2. SETUP

2.1 Unboxing

Carefully remove the watch from its packaging. Inspect the watch for any visible damage. Ensure all protective films are removed from the watch face and strap before use.



Figure 2: The Accutime Pac-Man Analog Watch presented within its themed retail packaging.

2.2 Setting the Time

1. **Pull out the Crown:** Locate the small knob (crown) on the right side of the watch case. Gently pull the crown outwards until you feel a click. This will stop the second hand.
2. **Adjust the Time:** Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time.
3. **Push in the Crown:** Once the time is set, push the crown back into its original position. The second hand will resume movement.





Figure 3: Front view of the watch face, illustrating the position of the crown for time adjustment.

3. OPERATING THE WATCH

3.1 Wearing the Watch

The watch features a durable black gunmetal strap with a flip clasp. To secure the watch, open the flip clasp, place the watch on your wrist, and close the clasp until it clicks securely. Ensure the fit is comfortable, not too tight or too loose.

4. MAINTENANCE

4.1 Cleaning

- Wipe the watch case and strap regularly with a soft, dry cloth to remove dust and fingerprints.
- For stubborn dirt, slightly dampen the cloth with water and gently wipe. Avoid using harsh chemicals or abrasive materials.

4.2 Storage

When not in use, store the watch in a cool, dry place, away from direct sunlight and extreme temperatures. Keeping it in its original box or a watch case can help protect it from scratches and dust.

4.3 Battery Replacement

This analog watch is powered by a standard watch battery. When the watch stops running, it indicates the battery needs replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and function.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch is not running	Battery is depleted or crown is pulled out.	Push the crown in fully. If still not running, replace the battery.
Time is incorrect	Time was not set correctly or crown was accidentally pulled out.	Reset the time as per Section 2.2. Ensure the crown is fully pushed in.
Strap feels loose/tight	Strap not adjusted to wrist size.	The metal strap may require professional adjustment (link removal/addition) for optimal fit.

6. SPECIFICATIONS

- **Model Number:** PAC8002STK
- **Brand:** Accutime
- **Item Type:** Analog Watch
- **Department:** Unisex-Adult
- **Clasp Type:** Flip Clasp
- **Manufacturer:** Accutime Watch Corp.
- **ASIN:** B0CLQCDS8

7. WARRANTY AND SUPPORT

Accutime products are manufactured with quality and care. For specific warranty information regarding your Pac-Man Analog Watch, please refer to the warranty card included with your purchase or visit the official Accutime website. For technical support or service inquiries, please contact Accutime customer service through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CLQCDS8>

More documents and user manuals: <https://manuals.plus/>