

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [Chipolino](#) /

> Chipolino Hip Hop Tricycle for Two Children - User Manual

## Chipolino TRKHH0233SA

# Chipolino Hip Hop Tricycle for Two Children - User Manual

Model: TRKHH0233SA

## 1. INTRODUCTION

Thank you for choosing the Chipolino Hip Hop Tricycle. This manual provides essential information for the safe assembly, operation, and maintenance of your new tricycle. Please read it thoroughly before first use and keep it for future reference. This tricycle is designed for two children, suitable from 18 months of age, with a maximum total weight capacity of 40 kg (20 kg per child).

## 2. SAFETY INSTRUCTIONS

Your child's safety is paramount. Always adhere to the following safety guidelines:

- **Age and Weight Limits:** Suitable for children aged 18 months and older. Do not exceed the maximum total weight of 40 kg (20 kg per child).
- **Adult Supervision:** Always ensure children are under direct adult supervision while using the tricycle.
- **Secure Fastening:** Before each ride, ensure both children are securely fastened with the safety belts provided in each seat.
- **Push Handle Use:** The parental push handle is for guiding the tricycle only. Do not use it to lift the tricycle or carry it with children inside.
- **Foot Protection:** The front wheel cover is designed to prevent children's feet from getting caught in the pedals or wheel spokes. Ensure it is always in place.
- **Brakes:** Utilize the brake pedals on the rear wheels to secure the tricycle when stationary.
- **Hazard Avoidance:** Do not use the tricycle near stairs, steep inclines, swimming pools, or on uneven/busy roads.
- **Regular Inspection:** Periodically check all screws, bolts, and fasteners to ensure they are tight and secure. Inspect for any damaged or worn parts before each use.
- **Assembly:** Ensure the tricycle is fully and correctly assembled according to the instructions before allowing children to use it.

### 3. PRODUCT FEATURES

---

The Chipolino Hip Hop Tricycle offers a range of features designed for comfort, safety, and versatility:

- Designed for two children (siblings or twins).
- Maximum total weight capacity: 40 kg (20 kg per child).
- Parental push handle for easy guidance.
- Both seats feature a 360° rotation function, allowing children to face forward, backward, or towards each other.
- Individual front safety bars on both seats.
- Safety belts for secure fastening in each seat.
- Foldable and movable footrests for both seats.
- Two large, foldable sun canopies with sun visors.
- Wide and comfortable seats with soft textile covers.
- Mudguard on the front wheel to prevent feet from getting caught.
- Durable EVA tires for a smooth ride.
- Storage basket on the handlebar and an additional basket between the rear wheels.
- Brake pedals on the rear wheels for stability.

### 4. ASSEMBLY AND SETUP

---

The Chipolino Hip Hop Tricycle requires assembly. Please follow the detailed diagrams and instructions provided in the separate assembly guide included with your product. Ensure all components are correctly installed and securely fastened before initial use.

#### **Key Assembly Points:**

- Attach the front wheel assembly, ensuring the mudguard is correctly positioned.
- Install the rear wheels and the rear axle with the storage basket.
- Mount the main frame and attach the two seats. Ensure the 360° rotation mechanism is functional and secure.
- Install the parental push handle, sun canopies, and front safety bars.
- Verify all screws, nuts, and bolts are tightened to prevent loosening during use.



Figure 1: Fully assembled Chipolino Hip Hop Tricycle in beige. This image shows the tricycle from a front-side angle, highlighting its dual seats, canopies, and parental push handle.



Figure 2: Side view of the Chipolino Hip Hop Tricycle with both sun canopies fully extended, demonstrating sun protection for both children.

## 5. OPERATING INSTRUCTIONS

Operating the Chipolino Hip Hop Tricycle is straightforward, offering flexibility for both parents and children:

1. **Child Seating and Safety:** Place each child in their respective seat. Ensure both children are securely fastened with the safety belts. Adjust the front safety bar as needed.
2. **Parental Control:** For younger children or when parental guidance is preferred, use the parental push handle to steer and propel the tricycle. The handle allows for comfortable control.
3. **Child Propulsion:** Older children can propel the tricycle independently using the pedals on the front wheel. Ensure their feet are properly placed on the pedals.
4. **Seat Rotation:** The seats can rotate 360°. To change the seat direction, disengage the locking mechanism (refer to the assembly guide for specific details) and rotate the seat to the desired position (forward, backward, or facing each other). Ensure the seat is securely locked in place after rotation.
5. **Footrests:** The footrests can be folded up or down depending on whether the child is pedaling or resting their feet.
6. **Braking:** To stop the tricycle, apply pressure to the brake pedals located on the rear wheels. For parking, engage the brakes fully.



Figure 3: Side view of the Chipolino Hip Hop Tricycle with both sun canopies retracted, showing the open design for clear visibility.



Figure 4: Detailed views of the tricycle. This image shows a close-up of the front wheel and pedal area with the mudguard, the rear wheels with the storage basket, and the adjustable sun canopy mechanism.

## 6. MAINTENANCE

Regular maintenance will extend the life of your Chipolino Hip Hop Tricycle and ensure continued safe operation:

- **Cleaning:** Clean the tricycle regularly with a damp cloth and mild soap. Avoid abrasive cleaners or solvents. Dry thoroughly after cleaning.
- **Textile Covers:** The soft textile covers can be removed for cleaning. Follow the care instructions on the fabric label.
- **Lubrication:** Periodically apply a small amount of silicone-based lubricant to moving parts such as wheel axles and seat rotation mechanisms to ensure smooth operation.
- **Storage:** Store the tricycle in a dry, cool place, away from direct sunlight and extreme temperatures, to prevent material degradation.
- **Tire Care:** The EVA tires are maintenance-free. Check them periodically for any signs of wear or damage.

## 7. TROUBLESHOOTING

If you encounter any issues with your Chipolino Hip Hop Tricycle, refer to the following common troubleshooting tips:

- **Tricycle pulls to one side:** Check if all wheels are properly aligned and securely attached. Ensure no debris is obstructing wheel movement.
- **Difficulty with seat rotation:** Ensure the locking mechanism is fully disengaged. Clean any dirt or debris from the rotation mechanism and apply a small amount of lubricant if necessary.
- **Pedals not engaging:** Verify that the pedals are correctly installed and that the child's feet are positioned properly. For parental control mode, ensure the pedal lock (if applicable) is engaged.
- **Loose parts:** Regularly inspect and tighten all screws, bolts, and fasteners. Do not use the tricycle if any parts are loose or missing.
- **Squeaking noises:** Identify the source of the squeak (e.g., wheels, seat mechanism) and apply a small amount of lubricant to the moving parts.

If you cannot resolve an issue using these tips, please contact customer support.

## 8. SPECIFICATIONS

Feature	Specification
Model Number	TRKHH0233SA
Recommended Age	18 months - 5 years
Maximum Weight Capacity	40 kg (20 kg per child)
Product Dimensions (L x W x H)	131 x 49 x 95 cm
Product Weight	9.4 kg
Material	Plastic, Textile, EVA
Seat Rotation	360°
Assembly Required	Yes

## 9. WARRANTY AND SUPPORT

Specific warranty information for the Chipolino Hip Hop Tricycle is typically provided at the point of purchase or within separate documentation. Please refer to your purchase receipt or contact the retailer for details regarding warranty coverage and claims.

For technical support, spare parts, or any questions not covered in this manual, please contact Chipolino customer service or your authorized dealer. Keep your proof of purchase handy when contacting support.

