

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Piebert](#) /

› [1 mm Comb User Manual for Philips Trimmers](#)

Piebert 422203632221

User Manual

1 mm Comb for Philips Trimmers

PRODUCT OVERVIEW

This document provides instructions for the proper use and maintenance of the Piebert 1 mm comb, designed as a compatible replacement part for specific Philips beard trimmer models.



Image: The Piebert 1 mm comb, a grey plastic attachment with multiple teeth, designed to fit compatible Philips beard trimmers. The "1MM" marking is visible on the front.

COMPATIBILITY

This 1 mm comb is specifically designed to be compatible with the following Philips beard trimmer models:

- Philips MG5720
- Philips MG7730
- Philips MG7770

The comb is a replacement for Philips part number 422203632221.

SETUP

1. **Ensure Trimmer is Off:** Before attaching or detaching the comb, ensure your Philips beard trimmer is switched off and unplugged from any power source.
2. **Align the Comb:** Locate the attachment points on your trimmer's blade head. Align the comb with these points, ensuring the teeth face away from the trimmer body.
3. **Attach Securely:** Gently push the comb onto the trimmer head until it clicks into place. Verify that it is firmly attached and does not wobble. Do not force the comb if it does not fit easily.

OPERATING INSTRUCTIONS

Once the 1 mm comb is securely attached, you can use your Philips beard trimmer for precise 1 mm trimming. Follow the operating instructions provided with your specific Philips trimmer model for general usage.

- **Trimming Length:** The comb provides a fixed 1 mm cutting length.
- **Even Trim:** For an even trim, move the trimmer against the direction of hair growth, ensuring the comb remains flat against the skin.
- **Cleaning During Use:** Periodically remove accumulated hair from the comb during extended trimming sessions to maintain optimal performance.

MAINTENANCE

Proper maintenance ensures the longevity and hygiene of your 1 mm comb.

- **Cleaning:** After each use, detach the comb from the trimmer. Rinse the comb under running water to remove hair and debris. Use a small brush if necessary to dislodge stubborn hairs.
- **Drying:** Allow the comb to air dry completely before reattaching it to the trimmer or storing it. Do not use heat to dry the comb.
- **Storage:** Store the comb in a clean, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Comb does not attach securely.	Incorrect alignment or debris in attachment points.	Ensure correct alignment. Clean any debris from the comb and trimmer attachment points. Do not force.
Uneven trimming.	Comb not flat against skin or hair accumulation.	Ensure the comb is held flat against the skin. Clean the comb and trimmer blades frequently during use.

SPECIFICATIONS

Product Type: Replacement Comb Attachment

Brand: Piebert

Model Number: 422203632221

Trimming Length: 1 mm

Compatibility: Philips MG5720, MG7730, MG7770 beard trimmers

Material: Plastic

Dimensions (approx.): 10 x 10 x 2 cm

Weight (approx.): 10 grams

WARRANTY AND SUPPORT

For information regarding warranty coverage or product support, please refer to the documentation provided with your original purchase or contact the seller directly. As this is a replacement part, specific warranty terms may vary.

Seller: [Hubert & Piening Handels GmbH](#)



© 2023 Piebert. All rights reserved.

This manual is for informational purposes only. Always refer to your original Philips trimmer manual for complete safety and operating instructions.