

[Manuals.plus](#) /

› [Coolski](#) /

› Coolski 36-inch Black Back Bar Refrigerator Instruction Manual

Coolski Beverage Refrigerator-215BH

Coolski 36-inch Black Back Bar Refrigerator Instruction Manual

Model: Beverage Refrigerator-215BH

INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Coolski 36-inch Black Back Bar Refrigerator. Please read these instructions thoroughly before using the appliance and retain them for future reference.



The Coolski 36-inch Black Back Bar Refrigerator, Model Beverage Refrigerator-215BH, is designed for commercial beverage storage.

Key Features

- **Capacity:** 7.0 Cu.Ft. (7.4 cubic feet total capacity), capable of holding up to 192 cans or 84 bottles.
- **Temperature Range:** Digital controller maintains an optimal environment between 33°F and 41°F.
- **Doors:** Two double-layer Low-E glass doors with self-closing mechanism and locks for security and energy efficiency.
- **Shelving:** Four adjustable wire shelves for flexible storage.
- **Lighting:** Bright LED interior lighting for clear visibility.
- **Cooling System:** Powerful forced-air system with R-290 natural refrigerant and automatic defrost.
- **Construction:** Anti-corrosion embossed aluminum interior and sleek black painted finish exterior.
- **Certifications:** ETL, ETL SANITATION (NSF Standard 7), and DOE approved.

SETUP INSTRUCTIONS

1. Unpacking

1. Carefully remove all packaging materials, including foam, tape, and any protective film.
2. Inspect the refrigerator for any shipping damage. Report any damage to your supplier immediately.
3. Keep packaging materials until you are satisfied with the product's condition.

2. Placement

- Place the refrigerator on a flat, stable, and level surface capable of supporting its weight when fully loaded.
- Ensure adequate ventilation around the unit. Maintain a minimum of 4 inches (10 cm) clearance from walls and other appliances to allow for proper airflow and heat dissipation.
- Avoid direct sunlight or proximity to heat sources such as ovens, radiators, or heating vents, as this can affect cooling performance and energy efficiency.
- This unit is designed for freestanding, undercounter, or built-in installation. If built-in, ensure proper ventilation is maintained.

3. Leveling

- Use a level to ensure the refrigerator is perfectly level. Adjust the leveling feet at the bottom of the unit as needed. Proper leveling is crucial for door alignment and efficient operation.

4. Power Connection

- Before plugging in, allow the unit to stand upright for at least 2-4 hours. This allows the refrigerant to settle, preventing potential damage to the cooling system.
- Connect the refrigerator to a dedicated 115V, 60Hz grounded electrical outlet. Do not use extension cords or adapter plugs.

5. Initial Operation

- After plugging in, allow the unit to run empty for several hours (e.g., 24 hours) to reach its set temperature before loading with beverages.



The refrigerator features four adjustable coated shelves for flexible storage configurations.

OPERATING INSTRUCTIONS

1. Temperature Control

- The refrigerator is equipped with a digital temperature controller located on the front panel.
- The factory preset temperature range is between 33°F and 41°F (0.5°C and 5°C).
- To adjust the temperature, use the up and down arrows on the digital controller. Press the 'Set' button to confirm your desired temperature.
- Allow time for the unit to reach the new set temperature after adjustment.



The digital temperature controller allows precise adjustment of the internal temperature between 33°F and 41°F.

2. LED Interior Lighting

- The refrigerator features bright LED interior lighting to illuminate your beverages.
- The lighting can typically be controlled via a switch on the control panel or inside the unit. Refer to the specific location of the light switch on your model.

Bright LED Interior Lighting

Quickly and easily see the beverages



Bright LED interior lighting enhances visibility of stored items.

3. Adjustable Shelves

- The wire shelves are adjustable to accommodate various sizes of cans, bottles, or kegs.
- To adjust a shelf, empty it, lift the shelf slightly, and pull it out. Reinsert the shelf at the desired height, ensuring it is securely seated on the shelf supports.

MAINTENANCE

1. Cleaning

- **Interior:** Regularly clean the interior with a mild detergent and warm water. Rinse thoroughly and dry completely to prevent odors and mildew. Remove shelves for easier cleaning.
- **Exterior:** Wipe the exterior surfaces with a soft cloth and mild cleaner. Avoid abrasive cleaners or solvents that could damage the finish.
- **Glass Doors:** Clean glass doors with a glass cleaner. The Low-E glass is designed to reduce condensation and improve energy efficiency.

2. Automatic Defrost

- This refrigerator features an automatic defrost system, eliminating the need for manual defrosting.
- During the defrost cycle, water will drain into an evaporation pan and evaporate. Ensure the drain is not blocked.

3. Door Seals

- Periodically check the door gaskets for proper sealing. Clean them with warm water and a mild detergent. A tight seal is crucial for maintaining temperature and energy efficiency.
- The self-closing magnetic doors are designed to ensure a secure closure.

"Low-E" Double Layers Glass Doors

Heat Insulation & Reduce Condensation & Energy Efficient



The Low-E double-layer glass doors provide excellent insulation and reduce condensation.

TROUBLESHOOTING

Before contacting customer service, please review the following common issues and solutions:

Problem	Possible Cause	Solution
Refrigerator does not operate	No power; circuit breaker tripped; power cord unplugged.	Check power supply, circuit breaker, and ensure cord is securely plugged in.
Unit is not cooling sufficiently	Temperature setting too high; door left open; excessive door openings; warm items loaded; poor ventilation; dirty condenser coils.	Adjust temperature setting; ensure doors are closed properly; reduce frequency of door openings; allow warm items to cool before loading; ensure proper clearance for ventilation; clean condenser coils (refer to maintenance).

Problem	Possible Cause	Solution
Unusual noise	Unit not level; loose parts; fan obstruction.	Level the unit; check for and tighten any loose parts; ensure fan is not obstructed. Normal operating sounds include compressor hum and refrigerant flow.
Excessive condensation inside	High humidity; door gasket not sealing; frequent door openings.	Ensure door gaskets are clean and sealing properly; reduce frequency of door openings.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

Detailed technical specifications for the Coolski 36-inch Black Back Bar Refrigerator (Model: Beverage Refrigerator-215BH):



Product dimensions: 21"D x 36"W x 33"H.

Feature	Detail
Product Dimensions (D x W x H)	21"D x 36"W x 33"H
Brand	Coolski
Capacity	7.4 cubic feet (7.0 Cu.Ft. Refrigerator Net Capacity)

Feature	Detail
Configuration	Air-cooled
Color	Black
Special Features	Adjustable Shelves, Automatic Defrost, Digital Temperature Control, Door Locks, LED Lighting
Installation Type	Freestanding/Undercounter/Built-in
Number of Doors	2
Defrost System	Automatic
Voltage	115 volts
Shelf Type	Wire
Number Of Shelves	4
Power Plug Type	Type A - 2 pin (North American)
Door Orientation	Left and Right
Compressor Type	Hermetic
Lock Type	Key
Item Weight	127 pounds
Annual Energy Consumption	1.78 kwh
Refrigerant	R-290
Finish Types	Matte
Door Material Type	Glass
Model Name	Commercial Beverage Refrigerator Cooler Black
Model Number	Beverage Refrigerator-215BH
Included Components	Shelves
Manufacturer	Coolski
Certifications	ETL, NSF



The refrigerator is certified by ETL, ETL SANITATION (NSF Standard 7), and DOE.

WARRANTY AND SUPPORT

Warranty Information

Your Coolski Back Bar Refrigerator comes with the following warranty:

- **Compressor:** 5-year warranty
- **Parts:** 2-year warranty

Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, technical assistance, or warranty claims, please contact Coolski customer service. Refer to the contact information provided with your purchase documentation or visit the official Coolski website for support details.

When contacting support, please have your model number (Beverage Refrigerator-215BH) and purchase date readily available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CLRVSM1D>

More documents and user manuals: <https://manuals.plus/>