

- Manuals.plus /
- › Fanbulous /
- › Fanbulous 16-inch Black Fandelier Ceiling Fan User Manual

Fanbulous Fanbulous X-structure ceiling fan-Black

# Fanbulous 16-inch Black Fandelier Ceiling Fan User Manual

Model: Fanbulous X-structure ceiling fan-Black | Brand: Fanbulous

## 1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Fanbulous 16-inch Black Fandelier Ceiling Fan. This product combines the functionality of a ceiling fan with the aesthetic appeal of a chandelier, featuring a unique caged design. It is equipped with a quiet DC motor, multiple speed settings, and a convenient remote control for ease of use. This manual provides essential information for safe installation, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your fan.



This image shows the Fanbulous 16-inch black fandelier ceiling fan installed, highlighting its caged design and the included remote control.

## 2. SAFETY INFORMATION

Please read all instructions carefully before beginning installation. Failure to follow these instructions could result in electric shock, fire, or personal injury.

- Ensure the power is turned off at the circuit breaker before installation or maintenance.
- All electrical connections must be in accordance with local codes, ordinances, and the National Electric Code (NEC). If you are unfamiliar with proper electrical wiring, consult a qualified electrician.
- The mounting structure must be capable of supporting a minimum of 35 pounds (15.9 kg).
- Do not bend the fan blades or other components during installation or cleaning.
- Keep children away from the fan during operation.
- Use only the replacement parts specified by the manufacturer.

### 3. PRODUCT FEATURES

- **X-Shape Metal Cage Design:** Stylish and versatile, allowing for farmhouse or enclosed aesthetic.
- **Quiet DC Motor:** Provides stable, safe, and powerful performance with minimal noise (approx. 30dB), ideal for quiet environments.
- **6 Adjustable Fan Speeds:** Offers a range of airflow from gentle breeze to strong cooling.
- **Reversible Motor:** Supports both downdraft (summer) and updraft (winter) modes for year-round comfort.
- **Remote Control:** Full control over light on/off, fan speed, timing (1/2/4/8 hours), and reversible function. Includes a mute button to eliminate beeping sounds.
- **Easy Installation:** Designed for straightforward setup with detailed instructions.



This image highlights the main features of the 16-inch caged ceiling fan, including its multiple speed settings, reversible motor for year-round use, silent operation, timer function, and convenient remote control.



 **1-2 GEAR**  
Gentle wind  
Suitable For Sleep

→  **3-4 GEAR**  
Natural wind  
Suitable For Family Enjoyment

→  **5-6 GEAR**  
Cooling wind  
Suitable For Summers

Designed for comfortable sleeping, the fan operates at a low 30dB, significantly quieter than typical room sounds, and includes a 'no beep' function and timer settings (1/2/4/8 hours).

*Fanbulous*

# Reversible Motor

Two modes for summer and winter



## SUMMER FORWARD

*Downdraft mode make you feeling cooling in summer*



## WINTER REVERSAL

*Updraft mode keep the room warm by circulating the warm air a winter*



The reversible motor allows for two modes: Summer Forward (downdraft) for cooling, and Winter Reversal (updraft) to circulate warm air.

## 4. SPECIFICATIONS

| Feature                 | Specification                                 |
|-------------------------|-----------------------------------------------|
| Model Name              | Fanbulous X-structure ceiling fan-Black       |
| Product Dimensions      | 16.3"D x 16.3"W x 6"H                         |
| Item Weight             | 9.5 Pounds                                    |
| Blade Count             | 7 Blades                                      |
| Fan Speeds              | 6 Gear                                        |
| Timer Settings          | 1 / 2 / 4 / 8 Hours                           |
| Power Source            | AC/DC                                         |
| Wattage                 | 40W MAX                                       |
| Voltage                 | 110-240V (AC)                                 |
| Light Socket Base       | E26 (Bulbs Not Included)                      |
| Recommended Bulb Types  | ST19 / A19 / T14 / G14 / B11                  |
| Recommended Room Height | 8-10 FT                                       |
| Control Method          | Remote Control                                |
| Indoor/Outdoor Usage    | Outdoor (Suitable for covered outdoor spaces) |

*Fanbulous*

# Dimension



Room Size: **8.5FT × 8.5FT**



Detailed dimensions of the fan, including its 16.3-inch diameter and adjustable height with 4-inch and 8-inch downrods, suitable for various ceiling heights.

*Fanbulous*



**4×E26 BULBS**  
(Not Included)



## Information

|                                                                                                                       |                                                                                                                |
|-----------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|
|  Blade: <b>7 BLADES</b>            |  Power: <b>40W MAX</b>      |
|  Fan Speeds: <b>6 GEAR</b>         |  Voltage: <b>110-240V</b>   |
|  Timer: <b>1/2/4/8H</b>            |  Socket Base : <b>E26</b>   |
|  Bulb: <b>ST19/A19/T14/G14/B11</b> |  Room Height: <b>8~10FT</b> |

Key product information including blade count, fan speeds, timer settings, power consumption, voltage, bulb requirements (E26 socket, bulbs not included), and recommended room height.

## 5. SETUP (INSTALLATION)

Before starting installation, ensure you have all necessary components and tools. It is recommended to have a second person assist with installation for safety.

### Required Tools (Not Included):

- Phillips screwdriver
- Flathead screwdriver
- Wire strippers
- Electrical tape
- Ladder

### Installation Steps:

#### 1. Step 1: Unpack and Verify Components

Carefully remove all parts from the packaging. Refer to the parts list in your included manual to ensure all components are present and undamaged.



Step 1: Unpack all components and verify against the parts list. This includes the fan body, downrods, canopy, mounting bracket, remote control, and wiring accessories.

#### 2. Step 2: Assemble Downrod

Choose the appropriate downrod length (4-inch or 8-inch) for your ceiling height. Insert the downrod into the fan motor assembly and secure it with the provided screws and pins. Ensure it is tightly fastened.



Step 2: Securely attach the chosen downrod (4-inch or 8-inch) to the fan motor assembly using the provided screws and tools.

#### 3. Step 3: Mount Ceiling Bracket

Attach the mounting bracket to the ceiling junction box. Ensure the bracket is securely fastened to the building

structure, capable of supporting the fan's weight. Lift the fan assembly and hook it onto the mounting bracket.



Step 3: Carefully lift the fan assembly and hook it onto the pre-installed ceiling mounting bracket, ensuring it is securely seated.

#### 4. **Step 4: Wire Connections**

Connect the electrical wires from the fan to the corresponding wires in the ceiling junction box (Live, Neutral, Ground) using the provided wire nuts. Ensure all connections are tight and secure. Tuck the wires neatly into the junction box.



Step 4: Connect the electrical wires (live, neutral, ground) from the fan to the corresponding wires in the ceiling junction box using wire nuts. Ensure all connections are tight and secure.

#### 5. **Step 5: Install Canopy and Bulbs**

Slide the canopy up to cover the mounting bracket and secure it. Install four E26 base bulbs (not included) into the sockets. Ensure bulbs are fully screwed in.

#### 6. **Step 6: Restore Power and Test**

Once installation is complete, restore power at the circuit breaker and test the fan and light functions using the remote control.



The versatile design of the Fanbulous ceiling fan makes it suitable for various indoor spaces, including kitchens, living rooms, and corridors, enhancing both comfort and aesthetics.

## 6. OPERATING INSTRUCTIONS

Your Fanbulous ceiling fan is operated via the included remote control. Ensure batteries are installed correctly in the remote.

### Remote Control Functions:

- **Fan On/Off:** Press the fan button to turn the fan on or off.
- **Speed Adjustment (1-6):** Use the speed buttons to cycle through 6 fan speeds. Speed 1 is the lowest, Speed 6 is the highest.
- **Light On/Off:** Press the light button to turn the light on or off.
- **Timer Setting:** Press the timer button to set the fan to turn off automatically after 1, 2, 4, or 8 hours.
- **Reversible Function:** Press the reverse button to switch between summer (downdraft) and winter (updraft) modes.
- **Mute Button:** Press this button to disable the beeping sound when operating the fan.

*Fanbulous*

## 6 Speeds Adjustment

Small ceiling fan is powful and quite



The fan offers 6 adjustable speeds: 1-2 for gentle wind suitable for sleep, 3-4 for natural wind for family enjoyment, and 5-6 for cooling wind suitable for summer.

## 7. MAINTENANCE

Regular maintenance helps ensure the long-term performance and appearance of your fan. Always turn off the power at the circuit breaker before performing any maintenance.

- **Cleaning:** To clean the fan, wipe it with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish.
- **Bulb Replacement:** Ensure the light is off and bulbs have cooled before attempting to replace them. Use E26 base bulbs of the recommended types (ST19, A19, T14, G14, B11).
- **Tightening Screws:** Periodically check all screws and connections on the fan and mounting bracket to ensure they are secure.

## 8. TROUBLESHOOTING

If you experience issues with your Fanbulous ceiling fan, refer to the following common problems and solutions:

| Problem                    | Possible Cause                                                                                | Solution                                                                                                          |
|----------------------------|-----------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| Fan does not start         | No power to the fan; Loose wire connections; Remote control battery low/dead.                 | Check circuit breaker; Verify all wire connections are secure; Replace remote control batteries.                  |
| Light does not turn on     | Bulbs are loose or burnt out; Incorrect bulb type; Loose wire connections.                    | Tighten or replace bulbs; Ensure correct E26 base bulbs are used; Check light wiring connections.                 |
| Fan is noisy               | Loose screws; Fan not securely mounted; Obstruction in fan cage.                              | Tighten all screws; Ensure mounting bracket is secure; Check for any objects interfering with the fan blades.     |
| Remote control not working | Battery low/dead; Remote not paired (if applicable); Obstruction between remote and receiver. | Replace batteries; Refer to remote pairing instructions (if provided in full manual); Ensure clear line of sight. |

If the problem persists after attempting these solutions, please contact customer support.

## 9. WARRANTY AND SUPPORT

Fanbulous offers a **2-year after-sales service** for this product. If you encounter any problems or have questions regarding your ceiling fan, please do not hesitate to contact our customer service team. We are committed to replying and solving your problem within 24 hours.

For support, please refer to the contact information provided with your purchase or visit the official Fanbulous website.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0CLRZYL48>

More documents and user manuals: <https://manuals.plus/>