

Smeg CJF11BLUS

SMEG CJF11BLUS 50's Retro Style Citrus Juicer Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and care of your SMEG CJF11BLUS 50's Retro Style Citrus Juicer. Please read these instructions thoroughly before first use and retain them for future reference.

The SMEG CJF11BLUS is designed for extracting juice from citrus fruits such as oranges, lemons, and grapefruits. It features automatic activation, a drip-free spout, and efficient straining for a smooth juicing experience.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- To protect against electrical hazards, do not immerse the motor base, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact customer support for examination, repair, or adjustment.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always ensure the appliance is properly assembled before use.
- Do not use the appliance for purposes other than its intended use.

PRODUCT OVERVIEW

Familiarize yourself with the components of your SMEG Citrus Juicer:

- **Dust Cover:** Protects the reamer and strainer when not in use.
- **Reamer:** Extracts juice from citrus halves.
- **Strainer:** Separates pulp and seeds from the juice.
- **Juicing Bowl:** Collects the extracted juice.
- **Anti-Drip Spout:** Allows for direct pouring into a glass and prevents drips when closed.
- **Motor Base:** Houses the motor and controls.



Figure 1: Front view of the SMEG CJF11BLUS Citrus Juicer, black with chrome accents and a clear dust cover.



Figure 2: Side view of the SMEG CJP11BLUS Citrus Juicer, showing the anti-drip spout in the open position.



Figure 3: Top view of the reamer and strainer components, illustrating the efficient straining design.

SETUP AND ASSEMBLY

1. Unpack all components and remove any packaging materials.
2. Wash the dust cover, reamer, strainer, and juicing bowl in warm, soapy water, then rinse thoroughly and dry. Alternatively, these parts are dishwasher safe.
3. Place the motor base on a stable, flat, and dry surface.
4. Position the juicing bowl onto the motor base, ensuring it is seated correctly.
5. Place the strainer into the juicing bowl.
6. Place the reamer onto the central shaft of the juicing bowl.
7. Plug the power cord into a suitable electrical outlet.

OPERATING INSTRUCTIONS

1. Cut your desired citrus fruit (e.g., oranges, lemons, grapefruits) in half.
2. Ensure the anti-drip spout is in the down position to allow juice to flow into your glass or container.
3. Place a glass or container directly under the anti-drip spout.
4. Take one half of the citrus fruit and firmly press it onto the reamer. The juicer will automatically activate upon pressure.
5. Apply gentle, consistent pressure and rotate the fruit slightly to extract all the juice.
6. Once juicing is complete, lift the fruit from the reamer. The motor will automatically stop.
7. To stop the flow of juice, push the anti-drip spout upwards.
8. Repeat the process for additional fruit halves.



Figure 4: Illustrates the process of pressing a citrus fruit half onto the reamer for juice extraction.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your juicer.

1. Always unplug the appliance from the power outlet before cleaning.
2. Disassemble the removable parts: dust cover, reamer, strainer, and juicing bowl.
3. The reamer, dust cover, strainer, and juicing bowl are dishwasher safe. For manual cleaning, wash them in warm, soapy water, rinse thoroughly, and dry.
4. Wipe the motor base clean with a soft, damp cloth. Do not immerse the motor base in water or any other liquid.
5. Ensure all components are thoroughly dry before reassembling or storing the appliance.
6. Use the dust cover when the appliance is not in use to keep it clean.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Juicer does not turn on.	Appliance not plugged in; power outage; parts not assembled correctly.	Check power cord connection; verify power supply; ensure juicing bowl and reamer are correctly seated.
No juice flowing from spout.	Spout is in the closed (up) position; strainer is clogged.	Push the anti-drip spout down; clean the strainer to remove pulp buildup.
Excessive pulp in juice.	Strainer not properly seated or damaged.	Ensure the strainer is correctly placed in the juicing bowl. If damaged, contact customer support for a replacement.
Motor stops during juicing.	Overheating due to continuous use; excessive pressure on fruit.	Allow the juicer to cool down for a few minutes. Apply moderate pressure when juicing.

TECHNICAL SPECIFICATIONS

Feature	Detail
Brand	Smeg
Model Name	Smeg Citrus Juicer (CJF11BLUS)
Product Dimensions	8"D x 7"W x 11"H
Item Weight	6 pounds
Power Source	Corded Electric
Maximum Power	80 Watts
Voltage	120 Volts
Number of Speeds	1
Reamer/Strainer Material	Stainless Steel
Juicing Bowl Material	Impact-resistant Tritan Renew (BPA-free)
Recommended Uses	Juicing lemons, limes, grapefruit
UPC	812895023367

WARRANTY INFORMATION

This product is covered by the manufacturer's standard warranty. Please refer to the warranty card included with your purchase or visit the official Smeg website for detailed terms and conditions, including warranty period and claim procedures.

CUSTOMER SUPPORT

For technical assistance, spare parts, or any inquiries regarding your SMEG CJF11BLUS Citrus Juicer, please contact Smeg customer service. Contact details can typically be found on the official Smeg website or in the documentation provided with your appliance.

You can visit the official Smeg website for support: www.smeg.com

