

DASH DSSP355GBWH02

DASH SmartStore™ Deluxe Stirring Popcorn Maker (Model DSSP355GBWH02) - Instruction Manual

Your guide to delicious homemade popcorn.

1. INTRODUCTION AND OVERVIEW

The DASH SmartStore™ Deluxe Stirring Popcorn Maker is designed to produce up to 24 cups of fresh, buttery popcorn. This electric hot oil popcorn machine features a stirring bar for thorough popping and a large lid that doubles as a serving bowl for convenience. Its SmartStore™ design allows the base and lid to stack for compact storage.

Key features include:

- Produces up to 24 cups of popcorn.
- Integrated stirring bar ensures even popping.
- Lid functions as a serving bowl.
- Built-in butter melting tray.
- Compact, stackable design for easy storage.



Figure 1: Fully assembled DASH SmartStore Deluxe Stirring Popcorn Maker with popcorn.

Video 1: Product Overview. This video demonstrates the main features and components of the popcorn maker.

2. COMPONENTS

The DASH SmartStore™ Deluxe Stirring Popcorn Maker includes the following main components:

- **Popcorn Maker Base:** Contains the heating plate, stirring mechanism, and power button.
- **Stirring Bar:** Ensures even distribution of kernels during popping.
- **Transparent Lid/Serving Bowl:** Covers the heating plate during operation and doubles as a serving bowl.
- **Butter Melting Tray:** Integrated into the lid for melting butter during popping.
- **Measuring Cup:** For precise measurement of kernels and oil.

EVERYTHING YOU NEED

to make *movie night* better



Figure 2: Main components of the popcorn maker, including the base, lid, and serving bowl.

3. SETUP

Before first use, ensure all packaging materials are removed and components are clean. Place the popcorn maker on a stable, heat-resistant surface.

1. Ensure the stirring bar is correctly attached to the center of the heating plate.
2. Place the transparent lid onto the base, aligning the handles.
3. Plug the power cord into a standard 120V/60Hz electrical outlet.

4. OPERATING INSTRUCTIONS

Follow these steps to make popcorn:

1. Remove the transparent lid from the popcorn maker base.
2. Add 30ml of cooking oil (e.g., vegetable, canola, or coconut oil) to the heating plate. Spread evenly.
3. Add 4.6 ounces of popcorn kernels to the heating plate. Ensure kernels are evenly distributed by the stirring bar.

4. If desired, sprinkle sugar evenly over the kernels for kettle corn.
5. Place the transparent lid back onto the base. Ensure the black vent cover on top of the lid is removed to allow steam to escape.
6. Turn on the power switch located on the front of the base. The stirring bar will begin to rotate, and the heating plate will warm up.
7. If adding butter, place a small amount of butter in the butter melting tray on top of the lid. The heat from the popping process will melt it.
8. Allow approximately 3 minutes for the popcorn to pop. The popping will slow down once complete.
9. Once popping stops, turn off the power switch and unplug the unit immediately.
10. Carefully remove the lid using the handles. The lid can be inverted and used as a serving bowl.

THREE SIMPLE STEPS

Fresh Popcorn Made Simple




Figure 3: Three simple steps for making popcorn.

NO KERNEL LEFT BEHIND

Stirring bar ensures every kernel is popped.



**NONSTICK
HEATING PLATE**
For Even
Popping.



Figure 4: The stirring bar ensures no kernel is left unpopped.

BRING ON THE BUTTER

Built-in butter melting tray adds butter while you cook.

Cap before serving for **MESS-FREE ENJOYMENT.**



Figure 5: The built-in butter melting tray.

Video 2: Popcorn Machine in operation (5-second preview). This short video shows the popcorn maker in action.

Video 3: Honest Review of This Popcorn Maker. This video provides a user's perspective on the popcorn maker's performance.

Video 4: Dash Large Stirring Popcorn Maker. This video demonstrates the stirring function and overall operation.

Video 5: Delicious Popcorn with Only 3 Ingredients. This video shows how to prepare popcorn using the machine with minimal ingredients.

5. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your popcorn maker.

- Always unplug the appliance and allow it to cool completely before cleaning.
- The heating plate has a non-stick surface. Wipe it clean with a damp cloth or sponge. Do not immerse the base in water.
- The transparent lid and stirring bar are hand wash only. They are not dishwasher safe.
- For thorough cleaning, the stirring bar can be unscrewed from the heating plate.
- Ensure all parts are completely dry before reassembling or storing.

6. TROUBLESHOOTING

If you encounter issues with your popcorn maker, refer to the following common solutions:

- **Popcorn not popping:** Ensure the unit is properly plugged into a working outlet. Verify that the correct amount of oil and kernels are used.
- **Many unpopped kernels:** Check the freshness of your popcorn kernels. Old or dry kernels may not pop effectively. Ensure the stirring bar is functioning correctly to distribute heat evenly.
- **Popcorn is soggy:** Ensure the black vent cover on the lid is removed during popping to allow steam to escape.
- **Burning smell:** Unplug the unit immediately. Ensure the correct amount of oil is used and that the unit is not left unattended after popping is complete.







7. SPECIFICATIONS

Attribute	Value
Brand	DASH
Model Number	DSSP355GBWH02
Color	White
Capacity	24 Cups
Special Feature	Manual
Material	Plastic
Product Dimensions	10.9"L x 8.9"W x 8.9"H
Included Components	Product, Manual
Is Electric	Yes
UPC	810137390499
Item Weight	6.78 pounds
Manufacturer	DASH
ASIN	B0CLSDF17X
Voltage	120 V/ 60 Hz
Power Rating	850 W

8. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your product or contact DASH customer service directly. Keep your purchase receipt for warranty claims.

Related Documents - DSSP355GBWH02

 <p>dash SMARTSTORE™ STIRRING POPCORN MAKER Instruction Manual Recipe Guide</p>	<p>Dash DSSP300 SmartStore Stirring Popcorn Maker Instruction Manual and Recipe Guide</p> <p>Comprehensive guide for the Dash DSSP300 SmartStore Stirring Popcorn Maker, including important safety precautions, parts identification, operating instructions, cleaning and maintenance tips, and a variety of popcorn recipes.</p>
 <p>dash FRESH POP POPCORN MAKER Instruction Manual Recipe Guide</p>	<p>Dash Fresh Pop Popcorn Maker Instruction Manual and Recipe Guide</p> <p>Comprehensive instruction manual and recipe guide for the Dash Fresh Pop Popcorn Maker (Model #DAPP150V2), featuring operating instructions, safety precautions, cleaning tips, and a variety of popcorn recipes.</p>
 <p>dash FRESH POP POPCORN MAKER Instruction Manual Recipe Guide</p>	<p>Dash Fresh Pop Popcorn Maker: Instruction Manual & Recipe Guide</p> <p>Learn how to use and maintain your Dash Fresh Pop Popcorn Maker (Model DAPP150V2) with this comprehensive instruction manual and recipe guide, featuring safety tips and delicious popcorn recipes.</p>
 <p>dash SMARTSTORE™ ESSENTIAL UTENSIL SET Instruction Manual</p>	<p>Dash SmartStore™ Essential Utensil Set Instruction Manual</p> <p>Official instruction manual for the Dash SmartStore™ Essential Utensil Set (DSUH600), covering parts, features, usage, cleaning, maintenance, customer support, and warranty information.</p>
 <p>dash ceramic smartstore™ 7-IN-1 MULTIPURPOSE NESTING COOKWARE SET Instruction Manual Recipe Guide</p>	<p>Dash SmartStore 7-in-1 Multipurpose Nesting Cookware Set: Instruction Manual & Recipe Guide</p> <p>Comprehensive instruction manual and recipe guide for the Dash SmartStore 7-in-1 Multipurpose Nesting Cookware Set (Model DCCWRS05). Learn about features, usage, and find recipes for ribs, sweet potatoes, cornbread, bread, chicken, and more.</p>
 <p>dash DELUXE EVERYDAY GRIDDLE Instruction Manual Recipe Guide</p>	<p>DASH Deluxe Everyday Griddle Instruction Manual and Recipe Guide</p> <p>Comprehensive guide for the DASH Deluxe Everyday Griddle, including important safety information, operating instructions, cleaning and maintenance tips, troubleshooting advice, and a collection of recipes.</p>