

Bullard BKDGP

Bullard Standard Non-Vented, Dove Grey, Polyester Browpad Instruction Manual

Model: BKDGP | Brand: Bullard

1. PRODUCT OVERVIEW

The Bullard Bump Cap, featuring the Standard Non-Vented, Dove Grey, Polyester Browpad, is engineered to provide essential head protection in environments where there is a potential for minor bumps, bruises, and lacerations. This lightweight and sleek design prioritizes all-day comfort, durability, and effective protection.

It incorporates an easy-to-install slide lock suspension system, designed to accommodate a wide range of head sizes, ensuring a secure and comfortable fit. The replaceable polyester browpad contributes to user comfort and ease of maintenance. This bump cap is suitable for various applications, including food and beverage processing, maintenance distribution centers, mechanics and quick-lube oil centers, and transportation and agriculture.

Key Features:

- Safety and Protection:** Provides essential head protection in low-risk environments.
- Comfortable:** Equipped with an easy-to-clean and replace polyester browpad.
- Snug, Balanced Fit:** Pinlock suspension is easily adjustable for a secure and personalized fit.
- Versatile and Stylish:** Available in various colors and designs to suit different preferences and work environments.
- Lightweight:** Constructed from durable and lightweight materials for all-day wear.
- Origin:** Designed and crafted in Cynthiana, Kentucky, USA.



Figure 1.1: The Bullard Standard Non-Vented Bump Cap in Dove Grey, showcasing its sleek design and browpad.

2. SETUP AND ADJUSTMENT

The Bullard Bump Cap is designed for straightforward setup and adjustment to ensure optimal comfort and protection.

2.1. Suspension System Adjustment

The bump cap features an easy-to-install slide lock suspension system, also referred to as a pinlock suspension. This system allows for quick and secure adjustment to fit various head sizes.

- 1. Identify the Pinlock:** Locate the pinlock mechanism at the back of the suspension system inside the cap.
- 2. Adjust Size:** To adjust the size, disengage the pins from their current slots.
- 3. Secure Fit:** Slide the suspension band to the desired head size and re-engage the pins into the corresponding slots. Ensure the fit is snug but comfortable, allowing for full range of motion without slippage.
- 4. Check Balance:** Verify that the cap sits balanced on your head, providing even coverage.




Figure 2.1: Internal view of the Bullard Bump Cap, highlighting the slide lock suspension system and other features.

2.2. Browpad Installation/Replacement

The polyester browpad is replaceable and designed for easy cleaning or replacement.

1. **Removal:** Gently detach the existing browpad from the suspension system. It is typically held in place by small clips or a channel.
2. **Installation:** Align the new browpad with the front of the suspension system. Press firmly to secure it into place, ensuring it is evenly seated and comfortable against the forehead.

3. OPERATING AND USAGE

The Bullard Bump Cap is intended for use in environments where protection against minor impacts is required. It is not a substitute for a hard hat in areas requiring ANSI/OSHA compliant head protection.

3.1. Proper Wearing

- Ensure the bump cap is adjusted to fit securely on your head, as described in Section 2.1.
- The cap should cover the top of your head and forehead adequately to provide intended protection.
- Do not wear the bump cap backwards unless specifically designed and approved for such use, as this may compromise protection.

3.2. Intended Environments

This bump cap is suitable for:

- Food and beverage processing facilities
- Maintenance distribution centers
- Mechanics and quick-lube oil centers

- Transportation and agriculture settings
- Any indoor or outdoor environment where minor head bumps are a risk, but falling objects are not.



Figure 3.1: A worker demonstrating the use of a Bullard Bump Cap in a typical work environment.

4. MAINTENANCE AND CARE

Proper maintenance extends the life of your Bullard Bump Cap and ensures continued hygiene and comfort.

4.1. Cleaning Instructions

- **Browpad:** The polyester browpad is designed to be easy to clean. It can be hand washed with mild soap and water. Rinse thoroughly and allow to air dry completely before re-installing.
- **Cap Shell:** The cap shell can be wiped clean with a damp cloth and mild soap. Avoid abrasive cleaners or solvents, as these may damage the material.
- **Drying:** Always allow all components to air dry completely before reassembly or storage to prevent mildew or odor.

4.2. Storage

Store the bump cap in a cool, dry place away from direct sunlight, extreme temperatures, and harsh chemicals. Avoid storing it in a compressed or distorted state.

5. TROUBLESHOOTING

This section addresses common concerns and provides guidance for resolving minor issues with your Bullard Bump Cap.

5.1. Common Issues

- **Cap feels loose or slips:**

Ensure the pinlock suspension is properly adjusted and securely fastened to your head size. Refer to Section 2.1 for adjustment instructions.

- **Browpad feels uncomfortable or dirty:**

The browpad may need cleaning or replacement. Refer to Section 2.2 for replacement and Section 4.1 for cleaning instructions.

- **Visible damage to the cap shell or suspension:**

If the cap shows signs of cracks, dents, or other damage, its protective integrity may be compromised. It is recommended to replace the cap immediately. Do not attempt to repair damaged protective equipment.

6. SPECIFICATIONS

Attribute	Detail
Product Dimensions	10.63 x 8.25 x 4.7 inches
Item Weight	7.36 ounces
Item Model Number	BKDGP
Department	unisex-adult
Date First Available	October 25, 2023
Manufacturer	Bullard
ASIN	B0CLT55VBB
Country of Origin	USA
Fabric Type	100% Polyester (Browpad)
Care Instructions	Hand Wash Only
Closure Type	Pull-On

7. WARRANTY AND SUPPORT

Specific warranty details for the Bullard Standard Non-Vented, Dove Grey, Polyester Browpad are not provided within this manual's data. For comprehensive warranty information, product support, or to inquire about replacement parts, please refer to the official Bullard website or contact Bullard customer service directly.

You can typically find contact information and detailed warranty policies on the manufacturer's official product support pages.

Manufacturer: Bullard

Official Website: www.bullard.com

