

[Manuals.plus](#) /

› [GWY](#) /

› GWY Air Fryer Accessories Instruction Manual

GWY FD302, FD101, OS301, FD401, OS101, FD305CO, OS401, OP302, OP305, Instant Pot Pro 8 QT, Instant Pot Duo 7-in-1

GWY Air Fryer Accessories Instruction Manual

Model: FD302, FD101, OS301, Instant Pot Pro Duo 8 QT Compatible

PRODUCT OVERVIEW

The GWY Air Fryer Accessory is a round wire rack designed to enhance your cooking experience with compatible air fryers and pressure cookers. Crafted from food-grade stainless steel, this accessory is non-toxic, tasteless, and meets FDA standards, ensuring healthy and safe cooking. Its unique mesh design promotes 360-degree heat circulation for even cooking without the need for flipping.

This accessory is ideal for preparing a variety of foods, including chicken, bacon, fish, vegetables, and more. It features two smooth handles for easy removal from the frying basket and is designed for durability and ease of cleaning.



Image: The GWY Air Fryer Accessory shown with cooked french fries and carrots, demonstrating its use inside an air fryer. Below, the accessory is depicted with skewers, a whole roasted chicken, and a Ninja Foodi appliance, highlighting its versatility.

COMPATIBILITY

This air fryer accessory is specifically designed to fit the following models:

- Ninja Foodi 5 QT FD101
- Ninja Foodi 6.5 QT FD302
- Ninja Foodi 6.5 QT OS301
- Ninja Foodi FD401
- Ninja Foodi OS101
- Ninja Foodi FD305CO
- Ninja Foodi OS401
- Ninja Foodi OP302

- Ninja Foodi OP305
- Instant Pot Pro 8 QT 10-in-1
- Instant Pot Duo 7-in-1 Air Fryer Electric Pressure Cooker

Important: Please measure the inside diameter of your cooking appliance before purchasing to ensure compatibility. The maximum size of this accessory is 9.2 inches (L) x 9.2 inches (W) x 3.9 inches (H).

APPLICATION



SUITABLE FOR



Design for Ninja Foodi FD302 FD401
OS101 OS301 FD305CO OS401
not suitable other model

Image: A visual representation indicating the GWY Air Fryer Accessory's compatibility with various Ninja Foodi models, showing the accessory placed inside the appliance.

SETUP AND FIRST USE

1. **Unpack:** Carefully remove the air fryer accessory and any included cleaning cloth from its packaging.
2. **Inspect:** Check the accessory for any signs of damage during transit.
3. **Initial Cleaning:** Before first use, thoroughly wash the air fryer rack with warm soapy water or place it in a dishwasher. Rinse completely and dry. This removes any manufacturing residues.

OPERATING INSTRUCTIONS

The GWY Air Fryer Accessory is designed for versatile cooking within your compatible appliance.

- **Placement:** Place the air fryer rack inside the cooking pot or basket of your air fryer or pressure cooker.
- **Food Placement:** Arrange your food items on the rack. The mesh design allows for optimal air circulation, ensuring even cooking.
- **Cooking:** Adjust the temperature and cooking time of your appliance according to the specific food being prepared. The rack's design promotes 360-degree heat circulation, often eliminating the need to flip food during cooking.
- **Easy Removal:** Utilize the integrated smooth handles to safely lift the hot rack and cooked food out of the appliance after cooking.

Applications: This rack is perfect for oven cooking and baking. It is suitable for a wide range of foods, including:

- Chicken (wings, pieces, whole roasted)
- Bacon
- Fish
- Meatballs
- Steak
- Vegetables (e.g., potatoes, carrots)
- Cookies and Cakes
- Pizza
- French Fries

Grill Pan of 6.5QT for Various Foods



Image: Four examples of the GWY Air Fryer Accessory in use, showing it holding a wrap, a whole roasted chicken, a steak, and a mix of fries and shrimp, demonstrating its versatility for different meal types.

Product Features



Handle Design for
easy take



Food grade Material
and coating



Air Circulation &
360°C Heating


Image: A visual breakdown of the product's features, highlighting the handle design for easy removal, the food-grade material, and the 360-degree air circulation for even heating, with the accessory shown inside an air fryer.

MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and performance of your GWY Air Fryer Accessory.

- **Cool Down:** Always allow the air fryer basket and accessory to cool down completely before cleaning to prevent burns and potential damage.
- **Dishwasher Safe:** The air fryer replacement parts are dishwasher safe for convenient cleaning.
- **Hand Washing:** For hand washing, use warm soapy water and a soft cloth or sponge. Rinse thoroughly.
- **Avoid Abrasives:** Do not use rough abrasive cloths, metal balls, or harsh scouring pads to clean the accessory, as this can damage the stainless steel surface. Use the included magic cleaning cloth if available.
- **Drying:** Ensure the accessory is completely dry before storing to prevent water spots or corrosion.

Clean It Directly with Water



Easy to Clean



Dishwasher Safe



Image: A collage showing the GWY Air Fryer Accessory being cleaned under running water by hand and being placed into a dishwasher, illustrating both cleaning methods.

TROUBLESHOOTING

- **Accessory Does Not Fit:** If the accessory does not fit your appliance, please re-measure the inside diameter of your cooking device. Ensure it matches the specified dimensions of 9.2" (L) x 9.2" (W) x 3.9" (H).
- **Quality Problems:** If you encounter any quality problems with the product, please refer to the "Warranty and Support" section for assistance.
- **Food Sticking:** While the accessory is designed to be non-stick, some foods may leave residue. A quick soak in warm soapy water can help loosen stuck-on food before cleaning.

SPECIFICATIONS

Item Type	Air Fryer Wire Rack
-----------	---------------------

Material	Food Grade Stainless Steel
Shape	Round
Dimensions	9.2 inches (L) x 9.2 inches (W) x 3.9 inches (H)
Color	Silver
Item Weight	8.4 ounces
Package Dimensions	9.49 x 9.41 x 4.13 inches

Product Size




Image: A detailed diagram illustrating the dimensions of the GWY Air Fryer Accessory, including its diameter and height, with measurements in both centimeters and inches.

Customer satisfaction is our top priority. GWY is committed to providing premium products and support. If you experience any quality problems with your GWY Air Fryer Accessory, please do not hesitate to contact our customer service. We are dedicated to resolving any issues promptly, offering exchanges or refunds as appropriate. For assistance, please contact us through the platform where you purchased the product or visit the official GWY brand page for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question