

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VEGER](#) /

> [VEGER Portable Charger for iPhone Built in Cables and Wall Plug, 10000mah Slim Fast Charging USB C Power Bank, Travel Essential Battery Pack Compatible with iPhones, iPad, Samsung More Devices\(Pink\) F Dark Pink](#)

VEGER V1115

VEGER 10000mAh Portable Charger User Manual

Model: V1115

INTRODUCTION

The VEGER 10000mAh Portable Charger is a versatile power solution designed for on-the-go charging. Featuring built-in cables for various devices and an integrated wall plug for convenient recharging, this power bank eliminates the need for multiple adapters and cables. Its compact design and high capacity make it an essential accessory for travel and daily use.



Image: The VEGER 10000mAh Portable Charger in dark pink, showcasing its sleek design and built-in cables.

SETUP

Initial Charging of the Power Bank

Before first use, it is recommended to fully charge your VEGER portable charger to optimize battery performance.

- **Using the Built-in Wall Plug:** Extend the integrated AC wall plug and insert it directly into a standard wall outlet. The digital display on the power bank will illuminate and show the charging progress, indicating the battery percentage increasing.
- **Using a USB-C Cable:** Alternatively, connect a USB-C cable (not included) to the power bank's USB-C input port and plug the other end into a compatible USB wall adapter or computer USB port.



Image: Illustration showing the two methods for recharging the power bank: directly via the built-in wall plug or using a USB-C cable.

OPERATING INSTRUCTIONS

Charging Your Devices

The VEGER portable charger offers multiple output options to charge a wide range of devices.

- **Using Built-in Cables:** Select the appropriate built-in cable (USB-C, Lightning for iPhone, or Micro USB) and connect it directly to your device. The power bank will automatically detect your device and begin charging.
- **Using USB-A or USB-C Output Ports:** For devices requiring other cable types, use your own USB-A or USB-C cable and connect it to the corresponding output port on the power bank.

Simultaneous Charging

This power bank is designed to charge up to four devices concurrently, utilizing its various output options.




Image: A setup demonstrating the VEGER power bank simultaneously charging a tablet, two smartphones, and wireless earbuds.

Checking Battery Level

The integrated digital display shows the remaining battery percentage of the power bank, allowing you to monitor its charge status at a glance.

Universal Compatibility

For iPhones / iPads series



iPhone 13/12/11/ Xs/
X 12 pro max/SE/8 plus



iPad Air 9.7"/10.5"/10.9"
iPad Pro 10.5"/10.9"



Apple AirPods Pro/
AirPods...

Type-C



Google Pixel P5/P4/P4a
/P3/P3XL...



Samsung S21/S20/S10/S9/
Z Fold2/ Note20/Note 10

Micro USB



vivo Z5x/Z3X/

And More



Image: The Veger power bank positioned with various compatible devices, including iPhones, iPads, Samsung phones, and Google Pixel devices, highlighting its broad compatibility.

MAINTENANCE

- **Storage:** Store the power bank in a cool, dry place away from direct sunlight, high humidity, and extreme temperatures.
- **Cleaning:** To clean the exterior, use a soft, dry cloth. Avoid using liquid cleaners, aerosols, or harsh chemicals.
- **Battery Care:** For optimal battery longevity, fully charge the power bank at least once every three months if it is not in regular use. Avoid completely draining the battery frequently.

TROUBLESHOOTING

- **Device not charging:**

- Ensure the power bank has sufficient charge (check the digital display).
- Verify that the cable is securely connected to both the power bank and your device.
- Try using a different built-in cable or a different output port.
- Test with a different device to confirm the power bank's functionality.

- **Power bank not charging:**

- Ensure the wall outlet is functional by testing it with another appliance.
- If using the built-in wall plug, ensure it is fully inserted into the outlet.
- If charging via USB-C, try a different USB-C cable and/or wall adapter.

- **Slow charging:**

- Charging multiple devices simultaneously may reduce the charging speed for each individual device.
- Ensure your device and cable support fast charging if you expect rapid charging speeds.

- **Overheating:**

- It is normal for the power bank to become slightly warm during charging or discharging.
- If the power bank becomes excessively hot, disconnect it immediately from all devices and power sources. Allow it to cool down in a well-ventilated area.
- Avoid charging in confined spaces or under direct sunlight.

SPECIFICATIONS

Feature	Detail
Model Number	V1115
Battery Capacity	10000 Milliamp Hours (mAh)
Battery Type	Lithium Polymer
Product Dimensions	5.9 x 2.7 x 0.72 inches
Item Weight	8 ounces
Input (Wall Plug)	AC 100-240V, 50/60Hz
Input (USB-C)	USB Type C
Output (Built-in Cables)	USB-C, Lightning, Micro USB (up to 15W each)
Output (Ports)	USB-A, USB-C (up to 15W each)
Special Features	Built-in Cables, Built-in Wall Plug, Digital Display
What's in the Box	Portable Charger with Built-in Cables, User Manual

WARRANTY AND SUPPORT

Your VEGER portable charger comes with a worry-free **12-month guarantee** from the date of purchase. If

you encounter any issues or have questions, please contact our customer service team. We offer **7 Day/24H friendly customer service** to assist you.

For support, please reach out to the seller, VEGER-US, through the platform where you made your purchase. They are committed to resolving any problems within 12 hours.

© 2025 VEGER. All rights reserved.