

## Greenworks GPW3001FCA

# Greenworks 3000 PSI Pressure Washer Instruction Manual

Model: GPW3001FCA

## SAFETY INFORMATION

---

Please read and understand all safety warnings and instructions before operating this pressure washer. Failure to follow these instructions may result in electric shock, fire, and/or serious injury.

### General Safety Rules

- Always wear appropriate personal protective equipment (PPE) such as safety glasses, hearing protection, and sturdy footwear.
- Never point the spray gun at people, pets, or electrical outlets.
- Ensure all connections are secure before operating to prevent leaks and pressure loss.
- Do not operate the pressure washer in an enclosed space.
- Keep children and pets away from the operating area.
- Always disconnect power and water supply when not in use or before performing maintenance.

## PRODUCT OVERVIEW

---

The Greenworks 3000 PSI Pressure Washer is designed for powerful and efficient cleaning of various outdoor surfaces. It features a TruBrushless motor for maximum cleaning power and is PWMA certified for verified performance.

### Key Features

- **TruBrushless Motor:** Powerful 14 Amp motor generating 3000 PSI and 2.0 GPM for maximum cleaning power.
- **PWMA Certified:** All water pressure (PSI) and flow rate (GPM) claims are tested and verified by an independent lab.
- **JettFlow Technology:** Delivers up to 50% more flow, enabling reach to higher areas and quick power rinsing.

- **Rugged Design + Accessories:** Equipped with a durable metal gun and a hassle-free 25-FT Uberflex kink-resistant hose.
- **Nozzle Tips:** Includes 15°, 25°, and 40° tips, plus soap and turbo nozzles for versatile cleaning.
- **Built-in Detergent Tank:** For easy soap application.
- **10" Never-Flat Wheels:** For easy maneuverability and transportation.

## Product Components



Figure 1: Greenworks 3000 PSI Pressure Washer with key components labeled, including the rugged spray gun, on-board accessory storage, 25' steel-braided hose, simple on/off switch, 14-Amp TruBrushless motor, durable steel frame, 35' power cord with GFCI, built-in detergent tank, premium foam cannon, and 10" never-flat wheels.

## SETUP

### Unpacking and Assembly

Carefully remove all components from the packaging. Ensure all parts listed in the packing list are present before beginning assembly.



Figure 2: The Greenworks 3000 PSI Pressure Washer fully assembled with its main components, including the pressure washer unit, spray gun, wand, hose, and foam cannon.

## Connecting Water Supply

1. Connect your garden hose to the water inlet on the pressure washer. Ensure the connection is tight to prevent leaks.
2. Connect the high-pressure hose to the outlet on the pressure washer and to the spray gun.
3. Ensure the water supply is turned on fully before starting the unit.

## Power Connection

Plug the power cord into a grounded 120V outlet. Ensure the outlet is suitable for the pressure washer's power requirements (14 Amp motor).



# SIMPLE ON/OFF SWITCH

## NO GAS, NO OIL, NO EMISSIONS

Figure 3: Close-up of the simple ON/OFF switch on the Greenworks pressure washer, highlighting its ease of use with no gas, no oil, and no emissions.

## OPERATING INSTRUCTIONS

---

### Starting the Pressure Washer

1. Ensure all hoses are properly connected and the water supply is fully open.
2. Squeeze the trigger on the spray gun to purge air from the system until a steady stream of water emerges.
3. Turn the pressure washer ON using the power switch.
4. Release the trigger to allow the motor to build pressure.

### Selecting Nozzles

The Greenworks pressure washer comes with various quick-connect nozzles for different cleaning tasks:

- **15° Tip (Orange):** For intense cleaning of hard-to-remove stains on durable surfaces.
- **25° Tip (Green):** For general cleaning of most surfaces.
- **40° Tip (White):** For gentle cleaning of delicate surfaces.
- **Soap Nozzle (Black):** For applying detergent.
- **Turbo Nozzle:** For concentrated, oscillating spray for tough jobs.



## **TURBO NOZZLE**

### FOR TOUGH JOBS

Figure 4: Close-up of the Turbo Nozzle, designed for tough jobs by providing a concentrated, oscillating spray.

### **Using the Foam Cannon**

The premium foam cannon allows for easy application of detergent. Fill the detergent tank with pressure washer-safe soap. Attach the foam cannon to the spray gun and apply soap to the desired surface.



## **BUILT-IN DETERGENT TANK**

### EASY SOAP APPLICATION

Figure 5: The built-in detergent tank for easy soap application, allowing for effective cleaning with foam.

## **MAINTENANCE**


---

### **After Each Use**

- Turn off the pressure washer and disconnect the power supply.
- Turn off the water supply and squeeze the spray gun trigger to release any remaining pressure.
- Disconnect all hoses and drain any remaining water from the unit and hoses.
- Clean the nozzles and store them in the on-board accessory storage.

### **Storage**

- Store the pressure washer in a dry, frost-free area.
- If storing for extended periods, consider using a pump protector to prevent corrosion.



## INTEGRATED CONVENIENCE

### BUILT-IN ACCESSORY STORAGE

Figure 6: The integrated accessory storage provides convenient space for nozzles and other attachments, ensuring quick application and easy storage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Motor does not start	Power cord not plugged in; GFCI tripped; No power at outlet.	Plug in cord; Reset GFCI; Check power supply.
Low pressure	Insufficient water supply; Clogged nozzle; Air in pump.	Ensure full water flow; Clean nozzle; Purge air by squeezing trigger.
Pulsating pressure	Air in pump; Water supply restriction; Clogged nozzle.	Purge air; Check water hose for kinks; Clean nozzle.

## SPECIFICATIONS

- **Brand:** Greenworks
- **Model Number:** GPW3001FCA
- **Power Source:** AC Electric

- **Maximum Pressure:** 3000 PSI
- **Maximum Flow Rate:** 2.0 GPM
- **Hose Length:** 25 Feet (Steel-Braided)
- **Item Weight:** 47 Pounds
- **Product Dimensions:** 17.9"L x 38.39"W x 24.09"H
- **Certification:** PWMA Certified
- **UPC:** 195526158318

## WARRANTY AND SUPPORT

---

Greenworks offers a comprehensive warranty for this product. Please refer to the warranty card included in your packaging for specific terms and conditions.

For technical support, troubleshooting assistance, or to order replacement parts, please visit the official Greenworks website or contact customer service:

- **Greenworks Store:** [Visit the Greenworks Store on Amazon](#)
- **Customer Support:** Refer to your product manual for contact details or visit the Greenworks website.