



Manuals.plus /

› SONGMICS /

› SONGMICS 130L Laundry Hamper User Manual (Model LCB513W01)

SONGMICS LCB513W01

SONGMICS 130L Laundry Hamper User Manual (Model LCB513W01)

Comprehensive instructions for assembly, use, and maintenance of your SONGMICS laundry hamper.

1. INTRODUCTION

Thank you for choosing the SONGMICS 130L Laundry Hamper. This manual provides detailed instructions to ensure safe and efficient use of your new product. Please read it thoroughly before assembly and retain it for future reference.



Image: The SONGMICS 130L Laundry Hamper, cream white, with its lid open, accompanied by two removable mesh laundry bags.

2. SAFETY INFORMATION

- Keep all packaging materials away from children to prevent choking hazards.
- Do not overload the hamper beyond its stated capacity (15 kg).
- Ensure the hamper is placed on a flat, stable surface to prevent tipping.
- Avoid placing hot items directly into the hamper.
- Do not use the hamper as a step stool or climbing apparatus.

- Keep away from open flames and excessive heat sources.
- Regularly check for any damage to the fabric or frame. Discontinue use if damaged.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- 1 x Laundry Hamper Body (Oxford Fabric with Bamboo Frame)
- 1 x Lid with PU Handle
- 2 x Removable Mesh Laundry Bags
- 4 x Fiberglass Support Rods
- 1 x Instruction Manual



Image: Unpacked components including the folded hamper body, lid, and fiberglass support rods.

4. SETUP INSTRUCTIONS

Assembly is quick and requires no tools. Follow these steps:

Step 1: Unfold the Hamper Body

Carefully unfold the main hamper body. Ensure the bamboo frame is at the top opening.

1



2



3



4



Image: Illustration showing the hamper body being unfolded.

Step 2: Insert Support Rods

Insert the four fiberglass support rods into the designated vertical sleeves located at each corner inside the hamper. Push them down until they are fully seated.



Image: Illustration demonstrating the insertion of support rods into the hamper's corner sleeves.

Step 3: Attach Removable Bags

The hamper includes two removable mesh laundry bags. Attach each bag to the interior of the hamper using the hook-and-loop fasteners (Velcro) provided. Ensure the bags are securely fastened to the loops inside the hamper.



Image: Close-up showing how to attach the mesh laundry bag using the hook-and-loop fasteners inside the hamper.

Step 4: Place the Lid

Position the lid on top of the hamper. The lid is designed to rest securely on the bamboo frame, covering the contents.



Image: The hamper with its lid placed on top, showing the PU handle for easy opening.

5. OPERATING INSTRUCTIONS

Using the Hamper

- **Sorting Laundry:** Utilize the two internal compartments to sort laundry (e.g., lights and darks, delicates and regular items).
- **Lid Functionality:** The lid helps contain odors and keeps laundry out of sight. Use the integrated PU handle

for easy opening and closing.

- **Transporting Laundry:** When a bag is full, detach it from the hamper by unfastening the hook-and-loop strips. Use the drawstring handles on the mesh bag to carry it to your washing machine.



Image: A person placing clothes into the hamper, demonstrating its use in a laundry room.



Image: The hamper's 130L capacity illustrated with two full mesh bags, positioned beside a washing machine.

Removable Mesh Bags

- The mesh bags are designed to be machine washable. They can also serve as a laundry sorting bag directly in the washing machine.
- After washing, reattach the clean bags to the hamper using the hook-and-loop fasteners.



1,35M

Bewertungen weltweit



965K+

5-Sterne-Bewertungen



4,56

von 5 Sternen im
Durchschnitt weltweit

Image: Detail of the mesh bag's drawstring and its use for carrying laundry.

6. MAINTENANCE

- **Hamper Body:** The 600D Oxford fabric is water-resistant and easy to clean. Wipe the exterior with a damp cloth and mild detergent if necessary. Do not machine wash the hamper body.
- **Removable Bags:** The mesh laundry bags are machine washable. Wash them with similar colors on a gentle cycle. Air dry or tumble dry on low heat.
- **Bamboo Frame:** Wipe the bamboo frame with a dry or slightly damp cloth. Avoid harsh chemicals.
- **Storage:** If not in use, the hamper can be folded flat for compact storage. Remove the support rods and bags, then collapse the body.



Image: Details of the hamper's construction, including the bamboo frame, water-resistant fabric, and internal support rods.

Faites de votre chambre un havre de paix



Image: The hamper folded flat, demonstrating its compact storage capability.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Hamper is unstable or wobbly.	Support rods not fully inserted or placed on an uneven surface.	Ensure all four fiberglass support rods are fully inserted into their sleeves. Place the hamper on a flat, level surface.
Removable bags detach easily.	Hook-and-loop fasteners not properly secured.	Press firmly on the hook-and-loop fasteners to ensure a secure attachment to the internal loops.
Lid does not close properly.	Hamper is overfilled or lid is misaligned.	Do not overfill the hamper. Adjust the lid to ensure it sits correctly on the bamboo frame.

8. SPECIFICATIONS

Brand: SONGMICS

Model: LCB513W01

Color: Cream White

Material: 600D Oxford Fabric, Bamboo, PU, Fiberglass

Capacity: 130 Liters

Product Dimensions (L x W x H): 52 x 38.5 x 70.5 cm (20.5 x 15.2 x 27.8 inches)

Item Weight: 2.1 kg (4.6 lbs)

Max. Static Load Capacity: 15 kg (33 lbs)

Number of Compartments: 2

Special Features: Foldable, Removable Bags, Lid, Handles



Image: Detailed dimensions of the hamper and its removable bags.

9. WARRANTY AND SUPPORT

SONGMICS products are designed for quality and durability. For warranty information, please refer to the specific terms and conditions provided at the point of purchase or visit the official SONGMICS website. If you encounter any issues or have questions regarding your product, please contact SONGMICS customer support.

You can find more information and contact details on the SONGMICS Brand Store.

