

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [PayLessHere](#) /
- › [PayLessHere 54in Dark Grey Multi-Level Cat Tree User Manual](#)

PayLessHere 54in Dark Grey

PayLessHere 54in Dark Grey Multi-Level Cat Tree User Manual

Model: 54in Dark Grey

INTRODUCTION

Thank you for choosing the PayLessHere 54in Dark Grey Multi-Level Cat Tree. This activity center is designed to provide your feline companions with a dedicated space for play, rest, and scratching, promoting their natural instincts and well-being. This manual contains important information regarding assembly, usage, maintenance, and troubleshooting to ensure a safe and enjoyable experience for your cats.





Image: The PayLessHere 54-inch Dark Grey Cat Tree, showcasing its multi-level design, integrated condos, scratching posts, and hanging toys, with several cats enjoying the structure.

SAFETY INFORMATION

- Ensure all components are securely fastened before allowing pets to use the cat tree.
- Place the cat tree on a flat, stable surface to prevent tipping.
- Keep small children away from the assembly area and the cat tree during use to prevent accidents.
- Regularly inspect the cat tree for loose parts, wear, or damage. Tighten screws and replace worn components as necessary.
- Do not allow cats to chew or ingest any parts of the cat tree.
- This product is intended for indoor use only.

PACKAGE CONTENTS

Before beginning assembly, please verify that all parts listed below are present and undamaged:

- Baseboard(s)
- Multi-level platforms
- Scratching posts (wrapped in sisal rope)
- Cat condos/houses
- Cat ladder/ramp
- Hanging ball toys
- All necessary screws, bolts, and tools (e.g., Allen wrench)
- Assembly instructions sheet

ASSEMBLY INSTRUCTIONS

Before You Begin

Clear a spacious area for assembly. Lay out all components and hardware. It is recommended to have a second person assist with assembly for easier handling of larger parts.

Step-by-Step Assembly

1. **Attach the Base:** Begin by securing the lowest scratching posts to the main baseboard using the provided screws. Ensure they are tightly fastened for stability.
2. **Build the Lower Levels:** Connect the first set of platforms and the lower cat condo to the initial posts. Follow the diagrams in the included assembly sheet to ensure correct orientation.
3. **Install the Cat Ladder:** Attach the cat ladder to its designated platform, providing easy access for your cat to the lower levels.
4. **Assemble Upper Levels and Condos:** Continue building upwards, attaching additional scratching posts, platforms, and the upper cat condo. Pay attention to the varying lengths of posts and the placement of platforms to create the multi-level structure.
5. **Secure Top Perches:** Fasten the top perches to the uppermost posts. These provide elevated resting and observation spots for your cat.
6. **Attach Hanging Toys:** Securely attach the hanging ball toys to the designated points on the cat tree.
7. **Final Check:** Once all components are assembled, double-check all screws and connections to ensure they are tight and secure. Gently shake the tree to confirm stability.

Multi-layer Cat Tree

Meet the entertainment




Soft Fabric

Plush fabric is soft and comfortable



Hanging Balls

Catch the cat's attention and give the cat fun



Cat Ladder

Increase your cat's range of motion

Image: An exploded view of the cat tree, illustrating the various components such as soft fabric platforms, hanging toys, and the cat ladder, which are assembled to form the complete structure.

Large Condo

The quiet and roomy condo allows for your cat to nap without any disruptions



Reliable Steady Bases

The base plate is thickened for better stability to further protect your cat's safety



Image: A close-up demonstrating the spacious cat condos with their internal dimensions and recommended weight limits, alongside a visual of the thickened, stable base construction.

OPERATING AND USAGE GUIDELINES

The PayLessHere Cat Tree offers multiple functionalities for your cat's enjoyment:

- **Scratching Posts:** The sisal-wrapped posts provide an ideal surface for cats to sharpen their claws, helping to protect your furniture. Encourage use by gently guiding your cat's paws to the posts.
- **Multi-Level Platforms:** Cats can climb, jump, and explore the various platforms, satisfying their natural urge to be at different heights.
- **Cozy Condos:** The enclosed condos offer private, secure spaces for napping, hiding, or simply observing their surroundings from a safe retreat.
- **Hanging Toys:** The attached furry balls provide interactive play opportunities, stimulating your cat's hunting instincts.
- **Cat Ladder:** The integrated ladder assists cats, especially kittens or older cats, in easily accessing different levels of

the tree.



Image: A visual representation of the cat tree's multi-level design, demonstrating how cats can easily climb and navigate between different platforms and enclosed spaces.



Image: A cat resting peacefully on the elevated top perch, highlighting the comfortable and secure napping spot provided by the cat tree.


MAINTENANCE

Proper maintenance will extend the life of your cat tree and keep it hygienic for your pets.

- **Cleaning:** The plush fabric surfaces can be spot cleaned with a damp cloth and mild, pet-safe detergent. For deeper cleaning, the manufacturer recommends **Hand Wash Only**. Avoid harsh chemicals or abrasive cleaners.
- **Vacuuming:** Regularly vacuum the plush surfaces to remove loose fur and dust.
- **Sisal Rope:** The sisal scratching posts are designed to withstand scratching. If the rope becomes excessively frayed, it may be replaced or reinforced.
- **Structural Integrity:** Periodically check all screws and connections for tightness. Re-tighten any loose fasteners to maintain stability.
- **Toy Replacement:** If the hanging toys become detached or damaged, they can be reattached or replaced.

Selected Natural Sisal Rope

Meet cats' habit of scratching



Natural Sisal Rope



2.3in Sisal Rope

Image: A detailed view of the natural sisal rope used on the scratching posts, emphasizing its texture and durability for cat claw maintenance.

TROUBLESHOOTING

Here are some common issues and their potential solutions:

Problem	Possible Cause	Solution
Cat tree wobbles or feels unstable.	Loose screws or uneven placement.	Ensure all screws are tightened. Place the tree on a flat, level surface. If necessary, add shims under the base.
Cats are not using the scratching posts.	Lack of familiarity or preference for other surfaces.	Sprinkle catnip on the sisal posts. Gently guide your cat's paws to the posts. Place the tree in a prominent area where your cat spends time.

Problem	Possible Cause	Solution
Hanging toys detach easily.	Loose attachment or aggressive play.	Re-secure the toys firmly. Consider reinforcing the attachment point if needed.
Plush fabric appears dirty or matted.	Accumulation of fur, dust, or spills.	Vacuum regularly. Spot clean with a damp cloth and mild, pet-safe detergent. Hand wash only for deeper cleaning.

SPECIFICATIONS

Detailed product specifications for the PayLessHere 54in Dark Grey Cat Tree:

Feature	Detail
Model Name	Cat Tree
Color	Dark Grey
Size	54in
Material	Particleboard, Plush, Sisal
Item Weight	28 Pounds
Product Dimensions (L x W x H)	19" x 19" x 54"
Recommended Uses	Indoor
Target Audience	Cats (All Life Stages, Small, Medium, Large Breeds)

