

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Ziegoal](#) /
- › [Ziegoal Kids Smart Watch W1 Instruction Manual](#)

Ziegoal W1

Ziegoal Kids Smart Watch W1 Instruction Manual

Model: W1

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Ziegoal Kids Smart Watch W1. Please read it thoroughly before operating the device and retain it for future reference. This smart watch is designed to offer entertainment and educational features for children, including dual cameras, games, learning activities, and daily habit tracking.



Image 1.1: Ziegoal Kids Smart Watch W1

2. SAFETY INFORMATION

- **Water Exposure:** This watch is **not waterproof**. Avoid contact with water, including rain, splashes, baths, or swimming. Water damage is not covered under warranty.
- **Choking Hazard:** Small parts may be present. Not suitable for children under 3 years old.
- **Battery Safety:** Do not attempt to replace the battery. Use only the provided charging cable. Do not expose the watch to extreme temperatures.
- **Screen Protector:** Apply the included screen protector to prevent scratches and enhance durability.
- **Supervision:** Adult supervision is recommended during use, especially for younger children.

3. PACKAGE CONTENTS

Please check the package for the following items:

- Ziegoal Kids Smart Watch W1
- USB Charging Cable

- Screen Protector Film
- Instruction Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your smart watch:



Image 4.1: Ziegoal Kids Smart Watch W1 Components

- **1.5" IPS Touch Screen:** Main display for interaction.
- **Dual Cameras:** Front and side cameras for photos and videos.
- **Power Button:** Located on the side, used for power on/off and screen wake/sleep.
- **Microphone:** For recording audio.
- **Speaker:** For audio playback.
- **USB Port:** For charging and data transfer.

5. GETTING STARTED (SETUP)

5.1 Charging the Device

1. Connect the USB charging cable to the watch's USB port.
2. Plug the other end of the USB cable into a standard USB power adapter (not included) or a computer's USB port.
3. The watch screen will display a charging indicator. A full charge typically takes 2-3 hours.
4. Ensure the watch is fully charged before first use for optimal battery life.

5.2 Powering On/Off

- **To Power On:** Press and hold the Power Button until the screen lights up.

- **To Power Off:** Press and hold the Power Button until a power-off option appears on the screen. Tap to confirm.

5.3 Applying the Screen Protector

Carefully apply the included screen protector film to the watch screen to prevent scratches and enhance durability. Ensure the screen is clean and dust-free before application.

6. BASIC OPERATION

6.1 Navigating the Touch Screen

- **Tap:** Select an icon or confirm an action.
- **Swipe:** Move between different screens or menus.

6.2 Setting Time and Date

Access the 'Settings' menu on the watch to adjust the time, date, and time format (12-hour or 24-hour).

6.3 Adjusting Volume and Brightness

Within the 'Settings' menu, you can find options to adjust the watch's volume for sounds and music, as well as the screen brightness for comfortable viewing.

7. KEY FEATURES

7.1 Dual Camera

The watch features dual 30W pixel cameras to capture photos and record videos.



Image 7.1: Dual Camera Features

- **Taking Photos:** Tap the camera icon on the main screen, then tap the shutter button to take a picture.
- **Recording Videos:** Switch to video mode within the camera app and tap to start/stop recording.
- **Photo Stickers:** Enhance photos with 20 built-in fun stickers.

7.2 Music Player

Enjoy music directly from your watch.

Melodic Music

Enchanting Fairy Tales

A Delightful Blend of Magic and Rhythm!



Image 7.2: Music Player Interface

- **Playing Music:** Access the 'Music' app. The watch comes with 3 built-in songs.
- **Transferring Music:** Connect the watch to a computer using the USB cable. The watch will appear as a removable drive. You can then drag and drop MP3 files into the designated music folder on the watch.

7.3 Educational Activities

Engage in various learning activities designed to enhance cognitive skills.

Discover the World

Have Fun with Learn



Image 7.3: Educational Features

- **ABC Animal Learning:** Interactive lessons for learning the alphabet with animal associations.
- **Landmark Buildings:** Explore famous global landmarks.
- **Audio Fables:** Listen to engaging stories.

7.4 Games

The watch includes 14 engaging puzzle games to enhance hand-eye coordination and logical thinking.

Diverse Puzzle Games

Designed to spark curiosity and creativity

School Mode: Setting the "Parental Control" Control the gaming time per day.

Keep learning and playtime balanced.



**Protection screen
to prevent scraping**



Image 7.4: Diverse Puzzle Games

- **Playing Games:** Select the 'Games' app to choose from the available puzzle games.
- **School Mode (Parental Control):** Parents can activate 'School Mode' in the settings to manage and limit game playtime, ensuring a balance between learning and play.

7.5 Daily Management

Utilize the watch to help establish and track daily routines.

Lifestyle Management

Nurturing Good Habits - Daily Routine Helpers



Image 7.5: Lifestyle Management and Habit Tracking

- Habit Tracking:** The watch features a 12-habit tracking alarm system to encourage consistent daily routines.
- Alarm Settings:** Set up to 3 alarms simultaneously for various activities like waking up, homework, or bedtime.

7.6 Utility Tools

The watch includes practical tools for daily use.



Image 7.6: Utility Applications

- **Calculator:** Perform basic arithmetic calculations.
- **Timer:** Set countdown timers for various activities.
- **Flashlight:** A small LED light for convenience.

7.7 Customization

Personalize the watch's appearance.

Vivid Wallpaper Themes

29 Wallpapers, 10 Theme



Long Battery Life

5 Hours of Playtime on Fully Charge!



Image 7.7: Wallpaper Themes and Battery Life

- **Wallpapers:** Choose from 29 customizable wallpapers and 10 themes to personalize the watch face.

8. MAINTENANCE

- **Cleaning:** Wipe the watch with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- **Battery Care:** To prolong battery life, avoid fully discharging the watch frequently. Charge it regularly. The 400mAh rechargeable battery provides up to 5 hours of gaming or 2-3 hours of continuous video recording.
- **Storage:** Store the watch in a cool, dry place away from direct sunlight when not in use.
- **Water Exposure:** As stated in the safety information, this watch is **not waterproof**. Exposure to water will damage the device and void the warranty.

9. TROUBLESHOOTING

- Watch will not power on:** Ensure the watch is fully charged. Connect it to the charger and wait a few minutes before attempting to power on again.
- Screen is unresponsive:** Try restarting the watch by holding down the Power Button. If the issue persists, ensure the screen is clean and free of debris.
- Battery not charging:** Check the USB cable for damage and ensure it is securely connected to both the watch and the power source. Try a different USB port or power adapter.
- Cannot transfer music:** Ensure the watch is properly connected to the computer and recognized as a storage device. Check that the music files are in MP3 format.
- Games are disabled:** Check if 'School Mode' is activated in the settings, which limits game access.

10. SPECIFICATIONS

Model Name	W1
Brand	Ziegoal
Screen Size	1.5 Inches
Battery Capacity	400 mAh Lithium Ion
Connectivity Technology	USB
Item Weight	4.6 ounces (0.13 Kilograms)
Product Dimensions	0.52 x 1.48 x 9.91 inches
Special Features	Alarm Clock, Calendaring, Camera, Music Player, Games, Learning Activities

11. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided with your purchase or visit the official Ziegoal website. Keep your proof of purchase for any warranty claims.

© 2024 Ziegoal. All rights reserved.

Related Documents - W1

	<p>Ziegoal Kids Smart Watch: Quick Guide, Features, and Specifications</p> <p>A comprehensive guide to the Ziegoal Kids Smart Watch, covering setup, functions, games, settings, and hardware specifications. Learn how to use the camera, music player, various games, and customize watch settings.</p>
---	---

 <p>W1 Smart Sports Watch Operation Guide Thank you for choosing this product. Read the operation guide carefully before use.</p>	<p><u>W1 Smart Sports Watch Operation Guide</u></p> <p>Comprehensive operation guide for the W1 Smart Sports Watch, covering setup, pairing, functions, maintenance, and safety information. Learn how to use your W1 smartwatch effectively.</p>
	<p><u>Ziegoal Kids Smart Watch: Quick Guide, Features, and Specifications</u></p> <p>A comprehensive guide to the Ziegoal Kids Smart Watch, covering setup, functions, games, settings, and hardware specifications. Learn how to use the camera, music player, various games, and customize watch settings.</p>
 <p>W1 Smart Sports Watch Operation Guide Thank you for choosing this product. Read the operation guide carefully before use.</p>	<p><u>W1 Smart Sports Watch Operation Guide</u></p> <p>Comprehensive operation guide for the W1 Smart Sports Watch, covering setup, pairing, functions, maintenance, and safety information. Learn how to use your W1 smartwatch effectively.</p>
	<p><u>W1 Portable Power Bank User Manual Guangzhou SICI Technical Co.,LTD</u></p> <p>Official user manual for the W1 Pocket Power Bank by Guangzhou SICI Technical Co.,LTD. Learn about specifications, charging, protective functions, and usage for your Apple Watch, Samsung Galaxy Watch, and smartphones.</p>
 <p>قىتىت HAYLOU W1 W2 W3 W4 W5 W6 W7 W8 W9 W10 W11 W12 W13 W14 W15 W16 W17 W18 W19 W20 W21 W22 W23 W24 W25 W26 W27 W28 W29 W30 W31 W32 W33 W34 W35 W36 W37 W38 W39 W40 W41 W42 W43 W44 W45 W46 W47 W48 W49 W50 W51 W52 W53 W54 W55 W56 W57 W58 W59 W60 W61 W62 W63 W64 W65 W66 W67 W68 W69 W70 W71 W72 W73 W74 W75 W76 W77 W78 W79 W80 W81 W82 W83 W84 W85 W86 W87 W88 W89 W90 W91 W92 W93 W94 W95 W96 W97 W98 W99 W100 W101 W102 W103 W104 W105 W106 W107 W108 W109 W110 W111 W112 W113 W114 W115 W116 W117 W118 W119 W120 W121 W122 W123 W124 W125 W126 W127 W128 W129 W130 W131 W132 W133 W134 W135 W136 W137 W138 W139 W140 W141 W142 W143 W144 W145 W146 W147 W148 W149 W150 W151 W152 W153 W154 W155 W156 W157 W158 W159 W160 W161 W162 W163 W164 W165 W166 W167 W168 W169 W170 W171 W172 W173 W174 W175 W176 W177 W178 W179 W180 W181 W182 W183 W184 W185 W186 W187 W188 W189 W190 W191 W192 W193 W194 W195 W196 W197 W198 W199 W200 W201 W202 W203 W204 W205 W206 W207 W208 W209 W210 W211 W212 W213 W214 W215 W216 W217 W218 W219 W220 W221 W222 W223 W224 W225 W226 W227 W228 W229 W220 W221 W222 W223 W224 W225 W226 W227 W228 W229 W230 W231 W232 W233 W234 W235 W236 W237 W238 W239 W230 W231 W232 W233 W234 W235 W236 W237 W238 W239 W240 W241 W242 W243 W244 W245 W246 W247 W248 W249 W240 W241 W242 W243 W244 W245 W246 W247 W248 W249 W250 W251 W252 W253 W254 W255 W256 W257 W258 W259 W250 W251 W252 W253 W254 W255 W256 W257 W258 W259 W260 W261 W262 W263 W264 W265 W266 W267 W268 W269 W260 W261 W262 W263 W264 W265 W266 W267 W268 W269 W270 W271 W272 W273 W274 W275 W276 W277 W278 W279 W270 W271 W272 W273 W274 W275 W276 W277 W278 W279 W280 W281 W282 W283 W284 W285 W286 W287 W288 W289 W280 W281 W282 W283 W284 W285 W286 W287 W288 W289 W290 W291 W292 W293 W294 W295 W296 W297 W298 W299 W290 W291 W292 W293 W294 W295 W296 W297 W298 W299 W299 W300 W301 W302 W303 W304 W305 W306 W307 W308 W309 W300 W301 W302 W303 W304 W305 W306 W307 W308 W309 W310 W311 W312 W313 W314 W315 W316 W317 W318 W319 W310 W311 W312 W313 W314 W315 W316 W317 W318 W319 W320 W321 W322 W323 W324 W325 W326 W327 W328 W329 W320 W321 W322 W323 W324 W325 W326 W327 W328 W329 W330 W331 W332 W333 W334 W335 W336 W337 W338 W339 W330 W331 W332 W333 W334 W335 W336 W337 W338 W339 W340 W341 W342 W343 W344 W345 W346 W347 W348 W349 W340 W341 W342 W343 W344 W345 W346 W347 W348 W349 W350 W351 W352 W353 W354 W355 W356 W357 W358 W359 W350 W351 W352 W353 W354 W355 W356 W357 W358 W359 W360 W361 W362 W363 W364 W365 W366 W367 W368 W369 W360 W361 W362 W363 W364 W365 W366 W367 W368 W369 W370 W371 W372 W373 W374 W375 W376 W377 W378 W379 W370 W371 W372 W373 W374 W375 W376 W377 W378 W379 W380 W381 W382 W383 W384 W385 W386 W387 W388 W389 W380 W381 W382 W383 W384 W385 W386 W387 W388 W389 W389 W390 W391 W392 W393 W394 W395 W396 W397 W398 W399 W390 W391 W392 W393 W394 W395 W396 W397 W398 W399 W399 W400 W401 W402 W403 W404 W405 W406 W407 W408 W409 W400 W401 W402 W403 W404 W405 W406 W407 W408 W409 W410 W411 W412 W413 W414 W415 W416 W417 W418 W419 W410 W411 W412 W413 W414 W415 W416 W417 W418 W419 W420 W421 W422 W423 W424 W425 W426 W427 W428 W429 W420 W421 W422 W423 W424 W425 W426 W427 W428 W429 W430 W431 W432 W433 W434 W435 W436 W437 W438 W439 W430 W431 W432 W433 W434 W435 W436 W437 W438 W439 W440 W441 W442 W443 W444 W445 W446 W447 W448 W449 W440 W441 W442 W443 W444 W445 W446 W447 W448 W449 W450 W451 W452 W453 W454 W455 W456 W457 W458 W459 W450 W451 W452 W453 W454 W455 W456 W457 W458 W459 W460 W461 W462 W463 W464 W465 W466 W467 W468 W469 W460 W461 W462 W463 W464 W465 W466 W467 W468 W469 W470 W471 W472 W473 W474 W475 W476 W477 W478 W479 W470 W471 W472 W473 W474 W475 W476 W477 W478 W479 W480 W481 W482 W483 W484 W485 W486 W487 W488 W489 W480 W481 W482 W483 W484 W485 W486 W487 W488 W489 W489 W490 W491 W492 W493 W494 W495 W496 W497 W498 W499 W490 W491 W492 W493 W494 W495 W496 W497 W498 W499 W499 W500 W501 W502 W503 W504 W505 W506 W507 W508 W509 W500 W501 W502 W503 W504 W505 W506 W507 W508 W509 W510 W511 W512 W513 W514 W515 W516 W517 W518 W519 W510 W511 W512 W513 W514 W515 W516 W517 W518 W519 W520 W521 W522 W523 W524 W525 W526 W527 W528 W529 W520 W521 W522 W523 W524 W525 W526 W527 W528 W529 W530 W531 W532 W533 W534 W535 W536 W537 W538 W539 W530 W531 W532 W533 W534 W535 W536 W537 W538 W539 W539 W540 W541 W542 W543 W544 W545 W546 W547 W548 W549 W540 W541 W542 W543 W544 W545 W546 W547 W548 W549 W550 W551 W552 W553 W554 W555 W556 W557 W558 W559 W550 W551 W552 W553 W554 W555 W556 W557 W558 W559 W560 W561 W562 W563 W564 W565 W566 W567 W568 W569 W560 W561 W562 W563 W564 W565 W566 W567 W568 W569 W570 W571 W572 W573 W574 W575 W576 W577 W578 W579 W570 W571 W572 W573 W574 W575 W576 W577 W578 W579 W579 W580 W581 W582 W583 W584 W585 W586 W587 W588 W589 W580 W581 W582 W583 W584 W585 W586 W587 W588 W589 W589 W590 W591 W592 W593 W594 W595 W596 W597 W598 W599 W590 W591 W592 W593 W594 W595 W596 W597 W598 W599 W599 W600 W601 W602 W603 W604 W605 W606 W607 W608 W609 W600 W601 W602 W603 W604 W605 W606 W607 W608 W609 W610 W611 W612 W613 W614 W615 W616 W617 W618 W619 W610 W611 W612 W613 W614 W615 W616 W617 W618 W619 W620 W621 W622 W623 W624 W625 W626 W627 W628 W629 W620 W621 W622 W623 W624 W625 W626 W627 W628 W629 W630 W631 W632 W633 W634 W635 W636 W637 W638 W639 W630 W631 W632 W633 W634 W635 W636 W637 W638 W639 W639 W640 W641 W642 W643 W644 W645 W646 W647 W648 W649 W640 W641 W642 W643 W644 W645 W646 W647 W648 W649 W650 W651 W652 W653 W654 W655 W656 W657 W658 W659 W650 W651 W652 W653 W654 W655 W656 W657 W658 W659 W660 W661 W662 W663 W664 W665 W666 W667 W668 W669 W660 W661 W662 W663 W664 W665 W666 W667 W668 W669 W669 W670 W671 W672 W673 W674 W675 W676 W677 W678 W679 W670 W671 W672 W673 W674 W675 W676 W677 W678 W679 W680 W681 W682 W683 W684 W685 W686 W687 W688 W689 W680 W681 W682 W683 W684 W685 W686 W687 W688 W689 W689 W690 W691 W692 W693 W694 W695 W696 W697 W698 W699 W690 W691 W692 W693 W694 W695 W696 W697 W698 W699 W699 W700 W701 W702 W703 W704 W705 W706 W707 W708 W709 W700 W701 W702 W703 W704 W705 W706 W707 W708 W709 W710 W711 W712 W713 W714 W715 W716 W717 W718 W719 W710 W711 W712 W713 W714 W715 W716 W717 W718 W719 W720 W721 W722 W723 W724 W725 W726 W727 W728 W729 W720 W721 W722 W723 W724 W725 W726 W727 W728 W729 W729 W730 W731 W732 W733 W734 W735 W736 W737 W738 W739 W730 W731 W732 W733 W734 W735 W736 W737 W738 W739 W739 W740 W741 W742 W743 W744 W745 W746 W747 W748 W749 W740 W741 W742 W743 W744 W745 W746 W747 W748 W749 W749 W750 W751 W752 W753 W754 W755 W756 W757 W758 W759 W750 W751 W752 W753 W754 W755 W756 W757 W758 W759 W759 W760 W761 W762 W763 W764 W765 W766 W767 W768 W769 W760 W761 W762 W763 W764 W765 W766 W767 W768 W769 W769 W770 W771 W772 W773 W774 W775 W776 W777 W778 W779 W770 W771 W772 W773 W774 W775 W776 W777 W778 W779 W779 W780 W781 W782 W783 W784 W785 W786 W787 W788 W789 W780 W781 W782 W783 W784 W785 W786 W787 W788 W789 W789 W790 W791 W792 W793 W794 W795 W796 W797 W798 W799 W790 W791 W792 W793 W794 W795 W796 W797 W798 W799 W799 W800 W801 W802 W803 W804 W805 W806 W807 W808 W809 W800 W801 W802 W803 W804 W805 W806 W807 W808 W809 W810 W811 W812 W813 W814 W815 W816 W817 W818 W819 W810 W811 W812 W813 W814 W815 W816 W817 W818 W819 W819 W820 W821 W822 W823 W824 W825 W826 W827 W828 W829 W820 W821 W822 W823 W824 W825 W826 W827 W828 W829 W829 W830 W831 W832 W833 W834 W835 W836 W837 W838 W839 W830 W831 W832 W833 W834 W835 W836 W837 W838 W839 W839 W840 W841 W842 W843 W844 W845 W846 W847 W848 W849 W840 W841 W842 W843 W844 W845 W846 W847 W848 W849 W849 W850 W851 W852 W853 W854 W855 W856 W857 W858 W859 W850 W851 W852 W853 W854 W855 W856 W857 W858 W859 W859 W860 W861 W862 W863 W864 W865 W866 W867 W868 W869 W860 W861 W862 W863 W864 W865 W866 W867 W868 W869 W869 W870 W871 W872 W873 W874 W875 W876 W877 W878 W879 W870 W871 W872 W873 W874 W875 W876 W877 W878 W879 W879 W880 W881 W882 W883 W884 W885 W886 W887 W888 W889 W880 W881 W882 W883 W884 W885 W886 W887 W888 W889 W889 W890 W891 W892 W893 W894 W895 W896 W897 W898 W899 W890 W891 W892 W893 W894 W895 W896 W897 W898 W899 W899 W900 W901 W902 W903 W904 W905 W906 W907 W908 W909 W900 W901 W902 W903 W904 W905 W906 W907 W908 W909 W910 W911 W912 W913 W914 W915 W916 W917 W918 W919 W910 W911 W912 W913 W914 W915 W916 W917 W918 W919 W919 W920 W921 W922 W923 W924 W925 W926 W927 W928 W929 W920 W921 W922 W923 W924 W925 W926 W927 W928 W929 W929 W930 W931 W932 W933 W934 W935 W936 W937 W938 W939 W930 W931 W932 W933 W934 W935 W936 W937 W938 W939 W939 W940 W941 W942 W943 </p>	