

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [tectake](#) /

> [tectake Retractable Awning Instruction Manual - Model 404956](#)

tectake 404956

tectake Retractable Awning Instruction Manual

Model: 404956 - 150 x 180 cm, Black/Grey

1. INTRODUCTION

Thank you for choosing the tectake Retractable Awning. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your awning. Please read all instructions carefully before use and retain this manual for future reference.

This awning is designed to provide shade and privacy for your outdoor spaces such as balconies, terraces, and gardens. Its no-drill design offers flexible installation and easy adjustment.

2. SAFETY INFORMATION

WARNING: Please read the assembly and disassembly instructions carefully. Ensure the awning is properly anchored and stable before use. Do not leave the awning extended during bad weather or strong winds to avoid damage or accidents.

- Always ensure all components are securely fastened before and during use.
- Do not hang heavy objects from the awning structure.
- Keep children and pets away from the awning during assembly and operation.
- Regularly inspect the awning for any signs of wear or damage. Replace damaged parts immediately.
- Do not use abrasive cleaners or harsh chemicals on the fabric or frame.

3. PRODUCT FEATURES

- **Multifunctionality and Maneuverability:** Easy-to-use crank for adjusting shade. Can be used as a patio parasol or sunshade.


- **Elegant Design, Guaranteed Solidity:** Lacquered steel structure and aluminum arms. No drilling required for installation. Weather-resistant.
- **Easy Assembly, Unrivaled Flexibility:** Quick installation with screw-on feet and telescopic rods. Versatile for use as a retractable privacy screen or outdoor patio awning.
- **Ultimate Protection, Assured Privacy:** UV-resistant fabric protects against harmful rays and acts as an opaque privacy screen. Multiple configurations for garden or balcony privacy.
- **Easy Maintenance, Exceptional Adaptability:** Water-resistant fabric is easy to clean. Non-slip plastic end caps protect surfaces. Adjustable arms for perfect adaptation as a patio awning, outdoor garden awning, or no-drill balcony awning.

4. PARTS LIST

Before starting assembly, ensure all parts are present and undamaged. Refer to the diagrams for identification.

MONTAGE facile.

Le dispositif de serrage pratique permet un montage rapide, facile et ajustable, sans perçage ni chevillage.



USAGE polyvalent.

La manivelle facile à utiliser permet de déployer rapidement la protection solaire à la longueur souhaitée, s'adaptant ainsi à chaque situation.

Figure 1: All components of the tectake retractable awning laid out for inspection.



La **manivelle pratique** peut être installée des deux côtés pour une adaptation optimale.

Structure en acier robuste revêtu par poudre pour une stabilité et une longévité maximales.

Hauteur réglable de 211 à 304 cm grâce à la tige télescopique à plusieurs niveaux et aux pieds à vis.

Polyvalent, ce store s'incline en diagonale pour une **protection solaire** ou à la verticale en **brise-vue**.

tectake
jardin

Détails du produit

Figure 2: Detailed product diagram showing technical specifications and assembly components.

- Awning Fabric (Polyester)
- Main Roller Tube (Aluminum)
- Telescopic Support Poles (Steel)
- Adjustable Arms (Aluminum)
- Crank Handle
- Mounting Clamps/Brackets
- Screw-on Feet with Non-slip Caps
- Fasteners (Screws, Nuts)
- Instruction Manual

5. SETUP AND ASSEMBLY

Assembly requires two adults. Follow these steps carefully.

5.1. Prepare the Fabric and Roller Tube

1. Lay the awning fabric flat on a clean, soft surface.
2. Assemble the main roller tube sections by connecting them securely.
3. Slide the fabric onto the main roller tube, ensuring it is centered and aligned. Secure the fabric to the tube using the provided screws.

RÉSISTANT AUX intempéries




Figure 3: Attaching the awning fabric to the main roller tube.

5.2. Assemble the Support Poles and Arms

4. Assemble the telescopic support poles. Attach the adjustable arms to the main roller tube using the clamps and fasteners.
5. Connect the crank mechanism to the designated point on the roller tube.

DIMENSIONS

Dimensions totales

150 x 120 x 211 - 304 cm

Dimensions pliées

150 x 12 x 211 - 304 cm

Tissu

136 x 180 cm

Longueur des bras de projection

120 cm

Diamètre des embouts

7 cm

Les mesures sont approximatives

TECHNICITÉS

Protection UV 50

Épaisseur du tissu 180 g/m²

Poids env. 7,5 kg

Matériaux acier revêtu par poudre, aluminium, 100 % polyester, polyéthylène, polyuréthane

CONTENU

Store à pince

Matériel de montage

Instructions de montage



Figure 4: Connecting the adjustable arms to the main roller tube.

5.3. Final Installation

6. Position the assembled awning in the desired location. Ensure the top of the telescopic poles are securely pressed against a stable overhead surface (e.g., balcony ceiling, window frame).
7. Adjust the height of the telescopic poles by turning the screw-on feet until the awning is firmly secured and stable. The adjustable height range is 0-3 cm for fine-tuning.
8. Ensure the awning is level and the arms are correctly angled for optimal shade or privacy.



Montage rapide
grâce au mécanisme de serrage pratique



Angle d'inclinaison
ajustable de la diagonale à la verticale



Hauteur réglable
pour une adaptation flexible à chaque situation



Système à manivelle
pour une manipulation facile



Polyester robuste
hydrofuge et doté d'une protection UV 50



Stabilité optimale
grâce aux capuchons antidérapants en plastique

tectake
jardin

Figure 5: The tectake retractable awning installed on a patio, providing shade.

5.4. Assembly Video Guides

Canopée Store Banne Manuel Rétractable

Your browser does not support the video tag.

This video demonstrates the step-by-step assembly process for a manual retractable awning, including unboxing, connecting poles, attaching fabric, and final installation. (Duration: 2:44)

Yaheetech Store Banne Manuel

Your browser does not support the video tag.

This video provides a detailed guide on assembling a manual awning, covering component identification, pole assembly, fabric attachment, and securing the awning in place. (Duration: 4:13)

6. OPERATING INSTRUCTIONS

The tectake retractable awning is operated manually using the provided crank handle.

1. **To Extend the Awning:** Insert the crank handle into the designated loop on the side of the

awning. Turn the handle clockwise to extend the fabric.

2. **To Retract the Awning:** Turn the crank handle counter-clockwise to retract the fabric.

3. Adjust the angle of the arms as needed to achieve the desired shade or privacy.



Figure 6: The awning fully extended, creating a comfortable shaded area.

7. MAINTENANCE

- **Cleaning:** The water-resistant polyester fabric is easy to clean. Use a mild soap solution and a soft brush or cloth. Rinse thoroughly with water and allow to air dry completely before retracting.
- **Frame Care:** The lacquered steel and aluminum frame can be wiped clean with a damp cloth. Avoid abrasive materials that could scratch the finish.
- **Seasonal Storage:** For prolonged periods of non-use or during harsh weather conditions (e.g., winter, strong winds), it is recommended to retract the awning fully. If possible, disassemble and store in a dry, protected area to extend its lifespan.
- **Inspection:** Periodically check all screws, bolts, and connections to ensure they are tight. Retighten as necessary. Inspect the fabric for any tears or damage.

RÉSISTANT AUX intempéries




Figure 7: The awning's weather-resistant features, suitable for sun and light rain.

8. TROUBLESHOOTING

- **Awning not extending/retracting smoothly:** Check the crank mechanism for any obstructions or damage. Ensure the fabric is not caught or misaligned.
- **Awning feels unstable:** Verify that the telescopic poles are fully extended and securely locked in place. Ensure the screw-on feet are tightly adjusted against the top and bottom surfaces.
- **Fabric sagging:** Check the tension of the adjustable arms. Adjust them to provide adequate support to the fabric.
- **Water pooling on fabric:** Ensure the awning is installed with a sufficient slope to allow water runoff. Adjust the angle of the arms if necessary.

9. SPECIFICATIONS

Feature	Specification
Model Number	404956
Dimensions (L x W x H)	180 x 150 x 304 cm
Item Weight	7.4 Kilograms
Material Type	Alloy Steel (Frame), Polyester (Fabric)
Color	Black/Grey

Operation Mode	Manual (Hand-powered)
UV Protection	UV 50
Fabric Thickness	Approx. 180 g/m ²
Assembly Required	Yes

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the purchase documentation or contact tectake customer service directly. Details can usually be found on the retailer's website or your order confirmation.