

[Manuals.plus](#) /

> [Wahl](#) /

> Wahl Pro Animal KM Inspire Grooming Clippers Instruction Manual

Wahl 3025199

Wahl Pro Animal KM Inspire Grooming Clippers

MODEL: 3025199



Image: Wahl Pro Animal KM Inspire Grooming Clippers, mint green color, showing the main body and blade.

Introduction

The Wahl Pro Animal KM Inspire Grooming Clippers are designed for efficient and comfortable grooming of dogs, cats, and horses. This professional kit features a powerful brushless motor for extended use and a lightweight design to reduce hand and wrist fatigue. It includes four stainless steel guide combs for versatile grooming across various coat types.



Image: Diagram highlighting key features of the KM Inspire clipper, including easy-to-change blades, slim design, long-lasting motor, two speeds, simple storage, and continuous power.

Safety Information

Always unplug the clipper before changing blades or guide combs. Do not use on infants or children. Keep the clipper away from water sources. Always use blade oil regularly to maintain the clipper's performance and longevity. Always follow manufacturer care instructions. Always use guide combs for different coat types to avoid skin irritation or injury. Always supervise the use of the clipper around pets to prevent accidents.

Setup

- Unpacking:** Remove all components from the packaging. Verify contents: clipper, 4 stainless steel guide combs, cleaning brush, and blade oil.
- Blade Attachment:** The clipper comes with a detachable blade set. To attach or remove a blade, press the release button on the back of the clipper and gently slide the blade on or off. Ensure the blade is securely seated before operation.
- Initial Oiling:** Before first use, apply a few drops of the included blade oil to the teeth and sides of the blade. This ensures smooth operation, reduces friction, and extends blade life.
- Attaching Guide Combs:** Select the desired stainless steel guide comb. Align the comb with the clipper blade and snap it firmly into place. Ensure it is securely attached before beginning to clip.





Image: The KM Inspire clipper shown with its included accessories: four stainless steel guide combs, a cleaning brush,

and blade oil.

KM INSPIRE HORSES

IDEAL FOR: 

- Bridle path, ears, muzzle, and fetlocks on horses




Image: Close-up of the clipper demonstrating the detachable blade set, indicating compatibility with various blade sizes.

Operating Instructions

1. **Powering On/Off:** Connect the clipper to a suitable power outlet. Use the power switch located on the clipper body to turn the unit on or off.
2. **Speed Selection:** The KM Inspire offers two operational speeds: 3,000 SPM (strokes per minute) and 3,600 SPM. Select the lower speed for delicate areas, fine hair, or sensitive animals. Use the higher speed for thicker coats or faster grooming.
3. **Grooming Technique:** Always groom in the direction of hair growth. Use smooth, even strokes to ensure a consistent cut. For optimal results, ensure the animal's coat is clean, dry, and free of tangles or mats before clipping.
4. **Using Guide Combs:** Once a guide comb is attached, hold the clipper flat against the animal's coat and move it steadily. The comb will lift the hair to the desired cutting length, preventing accidental cuts to the skin.



Image: A dog with a thick coat being groomed by the KM Inspire clipper, illustrating its suitability for various coat types.



Image: A corgi dog, with text indicating the KM Inspire is ideal for feet, face, finish work, and light body clipping on small to medium-sized dogs.

Maintenance

1. **Cleaning:** After each use, turn off and unplug the clipper. Remove the blade and use the cleaning brush to thoroughly remove any trapped hair from the blade teeth, blade drive, and clipper housing.
2. **Oiling:** Regular oiling is crucial for optimal performance and longevity. Apply a few drops of blade oil to the blade teeth and sides before, during (for extended grooming sessions), and after each use. This lubricates the blades, reduces friction and heat, and prevents rust.
3. **Storage:** Store the clipper and its accessories in a clean, dry place away from moisture. The clipper features a convenient hanging loop for space-saving storage.

Troubleshooting

- **Clipper Not Cutting Effectively:**
 - Ensure the blade is clean and free of hair buildup.
 - Apply blade oil generously to lubricate the blades.
 - Verify the blade is correctly attached and securely seated on the clipper.
 - If the blade is dull, replacement may be necessary.
- **Clipper Overheating:**
 - Ensure proper ventilation around the clipper during use.
 - Apply blade oil to reduce friction and heat generation.
 - Clean the blade and clipper thoroughly to remove any hair buildup that could impede airflow or cause drag.
 - Take short breaks during extended grooming sessions to allow the clipper to cool.
- **Excessive Noise or Vibration:**
 - Ensure the blade is properly aligned and securely fastened.
 - Apply blade oil to ensure smooth operation.
 - Check for any loose parts on the clipper.

Specifications

Product Dimensions	7.4 x 1.6 x 1.65 inches
Item Weight	12.3 ounces
Model Number	3025199
Power Source	Corded Electric
Motor Type	Brushless
Speeds	3,000 SPM and 3,600 SPM
Blade Material	Stainless Steel
Included Accessories	4 Stainless Steel Guide Combs, Cleaning Brush, Blade Oil

Warranty

The Wahl Pro Animal KM Inspire Grooming Clippers are covered by a **2-year manufacturer's warranty**. Please retain your original proof of purchase for any warranty claims. This warranty covers defects in materials and workmanship under normal use.

Support

For product support, technical assistance, or warranty inquiries, please refer to the contact information provided in your product packaging. You may also visit the official Wahl website for frequently asked questions, instructional videos, and customer service contact details.