

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Barska](#) /
- › [Barska Trend Compact Binoculars 8x21 Instruction Manual](#)

Barska AB10124

Barska Trend Compact Binoculars 8x21 Instruction Manual

Model: AB10124

IMPORTANT SAFETY INFORMATION



This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, please visit www.P65Warnings.ca.gov.

PRODUCT OVERVIEW

The Barska Trend Compact Binoculars 8x21 (Model AB10124) are designed for portability and ease of use, suitable for various outdoor activities such as bird watching, hunting, and travel. These binoculars feature an 8x magnification and 21mm objective lenses, providing clear and vivid images. The ergonomic design includes non-slip rubber armor for a comfortable and secure grip.



Image: Barska Trend Compact Binoculars 8x21, showcasing their compact design and front view.



Image: Barska Trend Compact Binoculars 8x21, illustrating the side profile and ergonomic grip.

Key Features:

- **Compact Design:** Handy optic suitable for outdoor events, travel, and as a gift.
- **Quality Optics:** 8x magnification, 21mm objective lenses, and fully-coated premium optics for bright and clear views.
- **Comfort Handling:** Sleek, stylish, and ergonomic with non-slip rubber armor.
- **Convenience:** Compact folding dual-hinge bridge design and centered focus knob for a secure and comfortable hold.

- **Included Accessories:** Carrying case, lens cloth, and neck strap.

SETUP

1. **Unpacking:** Carefully remove the binoculars and all accessories from the packaging.
2. **Attaching the Neck Strap:** Thread the provided neck strap through the strap lugs on the sides of the binoculars. Ensure it is securely fastened to prevent accidental drops.
3. **Cleaning the Lenses:** Use the included lens cloth to gently wipe any dust or smudges from the objective and eyepiece lenses. Avoid using abrasive materials.
4. **Storing the Binoculars:** When not in use, store the binoculars in the provided carrying case to protect them from dust, moisture, and impacts.

OPERATING INSTRUCTIONS

1. **Adjusting Interpupillary Distance:** Hold the binoculars with both hands and look through the eyepieces. Bend the binoculars at the hinge until you see a single, clear circular field of view. This adjusts the distance between the eyepieces to match the distance between your eyes.
2. **Focusing:**
 - **Central Focus:** Look through the binoculars at a distant object. Rotate the central focus knob until the image in the left eyepiece is sharp.
 - **Diopter Adjustment (if applicable):** While keeping your left eye closed, look through the right eyepiece and rotate the diopter ring (usually on the right eyepiece) until the image is sharp. Once set, you will only need to use the central focus knob for future adjustments.
3. **Viewing:** Once focused, you can observe objects by simply using the central focus knob to adjust for different distances.

MAINTENANCE

- **Lens Cleaning:** Use only a soft, clean lens cloth (like the one provided) or a specialized lens cleaning solution and cloth. Gently wipe the lenses to remove dust, dirt, or fingerprints. Avoid harsh rubbing or using abrasive materials, which can scratch the lens coatings.
- **Body Cleaning:** The exterior of the binoculars can be wiped with a soft, damp cloth. Avoid using strong chemicals or solvents.
- **Storage:** Store the binoculars in their carrying case in a cool, dry place when not in use. Avoid extreme temperatures and high humidity.
- **Protection:** Keep lens caps on when not viewing to protect the lenses from dust and scratches.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Image is blurry or out of focus.	Incorrect focus adjustment.	Adjust the central focus knob. If applicable, also adjust the diopter setting for your right eye.

Problem	Possible Cause	Solution
Two overlapping images or eye strain.	Incorrect interpupillary distance.	Adjust the hinge of the binoculars until a single, clear circular field of view is achieved.
Dark spots or smudges visible in the view.	Dirty lenses.	Clean the objective and eyepiece lenses gently with the provided lens cloth.

SPECIFICATIONS

Feature	Detail
Magnification	8x
Objective Lens Diameter	21mm
Prism Type	Roof
Prism Glass	BK-7
Exit Pupil	2.6mm
Optical Coating	Fully Coated
Focus System	Center
Field of View (at 1,000 yards)	383 feet
Close Focus Distance	16 feet
Eye Relief	10.5mm
Weight	6.35 ounces
Product Dimensions	3.6 x 3.9 x 1.5 inches
Model Number	AB10124

WARRANTY INFORMATION

These Barska Trend Compact Binoculars come with a **Limited Lifetime Warranty**. Please refer to the official Barska website or contact customer support for full details regarding warranty coverage and terms.

SUPPORT AND CONTACT

For further assistance, replacement parts, or accessories, please visit the official Barska website or contact their customer support. You can find more information and contact details on their brand store page:

[Barska Official Brand Store](#)

For general inquiries, you may also refer to the FAQs section on the Barska brand story page, which can be accessed via the brand store link.



© 2026 Barska. All rights reserved.