

[Manuals.plus](#) /

› [jioeuinly](#) /

› jioeuinly Slim Flip Stand Case for Zdk T30a T30b 10.1-Inch Tablet User Manual

jioeuinly Zdk T30a T30b Tablet 10.1-Inch Tablet Case

jioeuinly Slim Flip Stand Case for Zdk T30a T30b 10.1-Inch Tablet User Manual

Model: Zdk T30a T30b Tablet 10.1-Inch Tablet Case

Brand: jioeuinly

INTRODUCTION

This manual provides instructions for the proper installation, use, and care of your jioeuinly Slim Flip Stand Case, designed for Zdk T30a and T30b 10.1-inch tablets.

The case offers robust protection and versatile viewing options for your device.

1. SETUP INSTRUCTIONS

1.1 Unpacking

Carefully remove the tablet case from its packaging. Ensure no components are missing.

1.2 Installing Your Tablet

1. Align your Zdk T30a or T30b 10.1-inch tablet with the case's interior frame.
2. Gently press the tablet into the case, ensuring all four protective corners are securely seated.
3. Verify that all tablet ports, buttons, and speakers are accessible and unobstructed by the case.



Image: A tablet securely fitted into the case, demonstrating proper installation and port alignment.

2. OPERATING INSTRUCTIONS

2.1 Using the Flip Cover

The case features a flip cover that protects the tablet screen when closed. Side magnets ensure the cover remains securely closed.

2.2 Utilizing the Stand Function

The case can be folded to create a stand, allowing for hands-free viewing or typing.

1. Open the flip cover completely.
2. Fold the cover back to form a triangular support structure.
3. Position the tablet in the desired viewing or typing angle.

Ergonomic Structure



Built-in magnets bolster different positions.



Image: The tablet case configured into a stand, illustrating both a viewing angle and a typing angle for user convenience.

3. MAINTENANCE

3.1 Cleaning

To clean the case, gently wipe it with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the material or the inkjet pattern.

3.2 Storage

When not in use, store the case in a cool, dry place away from direct sunlight to preserve its material and color.

4. TROUBLESHOOTING

4.1 Case Does Not Fit

Ensure your tablet is a Zdk T30a or T30b 10.1-inch model. This case is specifically designed for these dimensions. While compatible with other models of similar size, an exact fit is guaranteed for the specified models.

4.2 Cover Does Not Stay Closed

Check if any debris is preventing the side magnets from engaging properly. Ensure the tablet is correctly seated within the case.

4.3 Stand Function Instability

Ensure the folded cover is forming a stable triangular support. Adjust the angle until the tablet rests securely.

5. PRODUCT SPECIFICATIONS

- **Model Compatibility:** Zdk T30a, Zdk T30b 10.1-inch tablets
- **Material:** Durable synthetic material with inkjet pattern
- **Form Factor:** Flip Case
- **Special Features:** Four protective corners, side magnetic closure, folding stand function, thickened anti-drop corner protector.
- **Product Dimensions:** Approximately 0.39 x 0.39 x 0.39 inches (L x W x H)
- **Item Weight:** Approximately 2.46 ounces
- **Color:** PKHD (Patterned)
- **Contents:** 1 x Tablet Case

ALL-OVER PROTECTION

Goes into every side & corner



Device ports, speakers, buttons all work fine



Slim & Lightweight



Image: Detailed view of the case highlighting its protective corners, precise cutouts for device ports, and overall slim design.

6. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the retailer's return policy or contact the manufacturer, jioeuinly, directly through their official channels. Specific warranty details may vary by region and retailer.

Manufacturer: jioeuinly

Date First Available: October 26, 2023

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CLXMB3N6>

More documents and user manuals: <https://manuals.plus/>