

[Manuals.plus](#) /

› [Lomiluskr](#) /

› Lomiluskr AK40 Compact Wired Mechanical Keyboard User Manual

Lomiluskr AK40

Lomiluskr AK40 Compact Wired Mechanical Keyboard User Manual

Model: AK40

INTRODUCTION

The Lomiluskr AK40 is a compact 87-key wired mechanical keyboard designed for gaming and typing. It features anti-ghosting capabilities, tactile mechanical switches, and mixed-color backlighting. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your keyboard.



Image: The Lomiluskr AK40 keyboard in pink and white, showcasing its compact 87-key layout and mixed-color backlighting. A single brown mechanical switch is displayed below the keyboard.

PACKAGE CONTENTS

Please verify that all items are present in the package:

- 1 x Lomiluskr AK40 Mechanical Keyboard
- 1 x USB Cable
- 1 x Keycap Puller

SETUP

Follow these steps to set up your Lomiluskr AK40 keyboard:

1. Unpack the keyboard and its accessories from the box.
2. Locate the USB cable provided.
3. Connect the smaller end of the USB cable to the USB port on the keyboard.
4. Connect the larger end of the USB cable to an available USB 1.1, 2.0, or 3.0 port on your computer (PC or Laptop).
5. The keyboard should be automatically recognized by your operating system (Window98SE/ME/2000/XP/Vista/Win7/Win8/Win10/MAC OS).
6. The backlight will illuminate upon successful connection.




Image: The Lomilusk AK40 keyboard positioned on a pink desk, connected to a computer monitor, illustrating a typical setup.

OPERATING INSTRUCTIONS

Key Features:

- **Full Anti-Ghosting 87 Keys:** All 87 keys support N-key rollover, ensuring every keystroke is registered accurately, even during rapid input.
- **Mechanical Switches:** Equipped with tactile mechanical switches (Brown Switch for this model) for responsive feedback and durability (rated for 50 million keystrokes).
- **Durable Construction:** Made from top-grade ABS and aluminum panels, providing a matte texture, durability, and resistance to dust and water.
- **Ergonomic Design:** Features a suspension body and ergonomic keycap slope for comfortable typing and reduced fatigue.

Backlight Modes:

The keyboard features 9 different backlight modes. You can cycle through these modes using the **FN + F8** key combination. The double-shot injection molded keycaps ensure clear backlighting.



Image: The Lomilusk AK40 keyboard displaying its vibrant mixed-color backlighting, enhancing visibility and aesthetics.

Multimedia Key Combinations:

Utilize the **FN** key in combination with the F1-F12 keys for quick access to various functions:

Key Combination	Function
FN + F1	Media Player
FN + F2	Volume Down
FN + F3	Volume Up
FN + F4	Mute
FN + F5	Stop
FN + F6	Previous Track
FN + F7	Play/Pause
FN + F8	Next Track / Backlight Mode Cycle

Key Combination	Function
FN + F9	Email
FN + F10	Web Browser
FN + F11	My Computer
FN + F12	Calculator
FN + WIN	Win Lock (disables Windows key)
FN + Insert	Adjust backlight brightness
FN + Pause	Adjust backlight brightness
FN + Prtsc	Adjust backlight brightness

MAINTENANCE

To ensure the longevity and optimal performance of your Lomilusk AK40 keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the keyboard surface. For deeper cleaning, use the included keycap puller to remove keycaps and clean underneath with compressed air or a small brush. Keycaps can be cleaned with mild soap and water, then thoroughly dried before reattaching.
- **Spills:** While the keyboard is designed to be water-resistant, avoid direct exposure to liquids. In case of a spill, immediately disconnect the keyboard from your computer, wipe off excess liquid, and allow it to air dry completely before reconnecting.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or twisting the USB cable excessively to prevent damage.



Image: A close-up view of the Lomilusk AK40 keyboard, highlighting the texture and arrangement of the pink and white keycaps, which can be removed for cleaning.

TROUBLESHOOTING

If you encounter issues with your Lomilusk AK40 keyboard, please refer to the following common solutions:

- **Keyboard Not Responding:**

- Ensure the USB cable is securely connected to both the keyboard and the computer.
- Try connecting the keyboard to a different USB port on your computer.
- Restart your computer.
- Test the keyboard on another computer to determine if the issue is with the keyboard or your system.

- **Backlight Not Working:**

- Check if the keyboard is properly connected.
- Press **FN + F8** to cycle through backlight modes.
- Press **FN + Insert/Pause/Prtsc** to adjust backlight brightness.

- **Keys Not Registering / Ghosting:**

- The keyboard features full anti-ghosting. If specific keys are not registering, ensure no debris is lodged under the keycap. Use the keycap puller to inspect.
- Ensure your operating system drivers are up to date (though typically plug-and-play).

- **Multimedia Keys Not Functioning:**

- Ensure you are pressing the **FN** key simultaneously with the desired F-key.
- Note: There is no specific driver program for Mac OS, some functions might behave differently.

SPECIFICATIONS

Feature	Detail
Keyboard Type	87 keys Mechanical keyboard
Switch Type	Brown Switch (45g actuation force, 2.0mm distance)
Keystroke Life	50 million times
Anti-Ghosting	Full N-key rollover
Backlight	Mixed Color Backlit (9 modes)
Connectivity	Wired USB (Anti-interference shielding professional five core wire)
USB Interface	Gold-plated interference, USB 1.1/2.0/3.0 compatible
Cable Length	1.6m
Material	ABS, Metal
Keyboard Dimensions	356 mm x 130 mm x 35 mm (14.02 x 5.12 x 1.38 inches)
Keyboard Weight	870g (1.87 pounds)
System Requirements	Window98SE/ME/2000/XP/Vista/Win7/Win8/Win10/MAC OS

WARRANTY AND SUPPORT

Lomiluskkr stands behind the quality of its products. All Lomiluskkr products undergo quality inspection before shipping.

- **Product Guarantee:** If there are quality issues with the product within one year of purchase, we offer a refund or a free replacement.
- **Contact Support:** For any questions or support needs, please feel free to contact us. Refer to your purchase platform for specific contact details.

© 2024 Lomiluskkr. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CLXQL48X>

More documents and user manuals: <https://manuals.plus/>