

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [RL LIVE YOUR LIGHT](#) /
- › [Reality Leuchten LED Desk Lamp Francy R52691102 User Manual](#)

RL LIVE YOUR LIGHT R52691102

Reality Leuchten LED Desk Lamp Francy

Model: R52691102

Brand: RL LIVE YOUR LIGHT

1. INTRODUCTION AND OVERVIEW

The Reality Leuchten Francy LED Desk Lamp (Model R52691102) is designed to provide versatile illumination and practical features for your workspace. This lamp integrates a digital display that shows the current time, date, day of the week, and room temperature. It features a 4-step touch dimmer for adjustable brightness and a flexible lamp arm to direct light precisely where needed. Equipped with modern LED technology, the Francy lamp offers high light quality, energy efficiency, and a long lifespan. Additionally, it includes a convenient alarm function.





Image 1.1: The Francy LED Desk Lamp, showcasing its sleek design and integrated digital display.




Image 1.2: Icons representing key features: 4-step touch dimmer, 5000K color temperature, adjustable brightness, alarm function, temperature display, and date display.

2. SAFETY INSTRUCTIONS

- Read all instructions carefully before using the lamp.
- Do not disassemble or modify the lamp. There are no user-serviceable parts inside, and tampering may void the warranty and pose a safety risk.
- This product contains an integrated LED light source that is not replaceable. Do not attempt to replace the LEDs.
- Use only the power adapter supplied with the lamp. Using an incorrect adapter may damage the lamp or cause a fire hazard.
- Keep the lamp away from water, moisture, and high temperatures.
- Ensure the lamp is placed on a stable, flat surface to prevent tipping.
- Do not look directly into the LED light source for extended periods, as it may cause eye strain.
- Unplug the lamp from the power outlet before cleaning or if it will not be used for an extended period.

3. PACKAGE CONTENTS

Please check the package contents upon unpacking to ensure all items are present and undamaged:

- Francy LED Desk Lamp (Model R52691102)
- Power Adapter
- User Manual (this document)

4. SETUP

1. **Unpacking:** Carefully remove the lamp and all components from the packaging. Retain the packaging for future storage or transport.
2. **Placement:** Place the lamp on a stable, flat, and dry surface, such as a desk or table. Ensure there is adequate space around the lamp for ventilation and adjustment of the flexible arm.
3. **Connect Power:** Insert the small plug of the power adapter into the DC input port located at the back or base of the lamp. Then, plug the power adapter into a standard electrical outlet.
4. **Initial Power On:** Once connected to power, the digital display should illuminate. The lamp is now ready for use.
5. **Install Backup Battery (Optional/If applicable):** The lamp's digital display may require a CR2032 button cell battery (not always included, but often pre-installed or required for memory retention during power outages). Locate the battery compartment, typically on the underside or back of the lamp's base. Insert a CR2032 battery with the positive (+) side facing up. This battery helps maintain time and date settings when the lamp is unplugged.



Image 4.1: The Francy LED Desk Lamp positioned on a desk, ready for use.



Image 4.2: Detail of the lamp's base showing the CR2032 battery compartment and control buttons (S, M, V, ^).

5. OPERATING INSTRUCTIONS

5.1. Power On/Off and Brightness Adjustment

The lamp features a touch-sensitive power button and a 4-step dimmer integrated into its base.

- **Power On:** Lightly touch the power symbol () on the lamp's base. The lamp will turn on at the lowest brightness setting.
- **Adjust Brightness:** Continue to touch the power symbol repeatedly to cycle through the 4 brightness levels. Each touch will increase the brightness.
- **Power Off:** After the highest brightness level, touching the power symbol one more time will turn the lamp off.

5.2. Flexible Arm Adjustment

The lamp head is connected to the base via a flexible arm, allowing you to direct the light as needed.

- Gently bend the flexible arm to position the light source. Avoid excessive force or bending the arm beyond its natural range of motion to prevent damage.



Image 5.2.1: The flexible arm of the Francy lamp allows for various lighting angles.

5.3. Digital Display Functions

The integrated digital display shows time, date, day of the week, and room temperature.



Image 5.3.1: A detailed view of the digital display, showing temperature, time, date, and day of the week.

The control buttons (S, M, V, ^) located on the back or side of the lamp's base are used to set these functions.

- **S (Set):** Enters setting mode and confirms selections.
- **M (Mode):** Switches between display modes or setting parameters.
- **V (Down/Decrease):** Decreases values or navigates down.
- **^ (Up/Increase):** Increases values or navigates up.

5.3.1. Setting Time and Date

1. Press the **S** button once to enter time setting mode. The hour digits will flash.
2. Use the **^** or **V** buttons to adjust the hour.
3. Press **S** again to move to the minute setting. Use **^** or **V** to adjust minutes.
4. Continue pressing **S** to cycle through setting the year, month, and day. Use **^** or **V** to adjust each value.
5. After setting the day, press **S** one last time to exit setting mode and save your changes.

5.3.2. Alarm Function

The lamp includes an alarm clock feature.

1. Press the **M** button repeatedly until the alarm time is displayed (often indicated by an alarm icon).
2. Press the **S** button to enter alarm setting mode. The alarm hour digits will flash.
3. Use the **^** or **V** buttons to adjust the alarm hour.
4. Press **S** again to move to the alarm minute setting. Use **^** or **V** to adjust minutes.
5. Press **S** one more time to confirm the alarm time and exit setting mode.
6. To activate/deactivate the alarm, press the **^** button while the alarm time is displayed (not in setting mode). An alarm icon will appear/disappear on the display.
7. **Snooze Function:** When the alarm sounds, touch the power symbol on the lamp's base to activate snooze. The alarm will sound again after a few minutes (typically 5-10 minutes).
8. **Stop Alarm:** To turn off the alarm completely, press any of the **S**, **M**, **V**, or **^** buttons (not the power symbol) when the alarm is sounding.

5.3.3. Temperature Display

The lamp displays the ambient room temperature. This feature is automatic and does not require manual setting.

- The temperature is typically shown in Celsius (°C). There might be an option to switch to Fahrenheit (°F) by pressing a specific button (e.g., **V** or **^**) while in time display mode, but this varies by model. Refer to the display for any indicators.

6. MAINTENANCE

- **Cleaning:** Before cleaning, ensure the lamp is unplugged from the power outlet. Use a soft, dry cloth to wipe the lamp's surface. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **LED Light Source:** The LED light source in this lamp is integrated and cannot be replaced. If the LEDs fail, the entire lamp unit may need to be replaced.
- **Battery Replacement:** If the time and date settings are lost when the lamp is unplugged, the CR2032 backup battery may need replacement. Follow the instructions in Section 4. Setup for battery installation.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in; power outlet not working; faulty adapter.	Ensure the power adapter is securely plugged into both the lamp and a working electrical outlet. Test the outlet with another device.
Digital display is blank or flickering.	Power issue; backup battery low/missing.	Check power connection. If the lamp is plugged in but the display is off, replace the CR2032 backup battery.
Time/Date resets when unplugged.	Backup battery is dead or missing.	Install or replace the CR2032 backup battery (see Section 4. Setup).

Problem	Possible Cause	Solution
Alarm does not sound.	Alarm not activated; volume too low (if adjustable).	Ensure the alarm function is activated (alarm icon visible on display). Check if there's a volume setting (though typically not on these lamps).

8. SPECIFICATIONS

Model Number: R52691102

Brand: RL LIVE YOUR LIGHT

Product Dimensions: 7D x 24W x 35H cm (7 x 24 x 35 cm; 625 g)

Base Material: Plastic

Shade Material: Plastic

Color: Black (with leather-look elements)

Finish Type: Brushed

Light Source: Integrated LED

Power Consumption: 4.8 Watt

Luminous Flux: Max 430 Lumen

Color Temperature: 5000 Kelvin (Cold White)

Average Lifespan: 25,000 hours

Dimming: 4-step touch dimmer

Switch Type: Touch

Special Features: Dimmable, Energy-Efficient, Flexible Arm, Digital Display (Time, Date, Day, Temperature), Alarm Function

Power Source: Corded Electric

Batteries Required: No (for main operation), CR2032 button cell for display memory (not always included/pre-installed)




Image 8.1: Technical drawing illustrating the dimensions and components of the Francy LED Desk Lamp.

9. WARRANTY AND SUPPORT

This product is covered by a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or contact the retailer where you purchased the product.

For technical support, troubleshooting assistance beyond what is provided in this manual, or inquiries regarding parts and service, please contact RL LIVE YOUR LIGHT customer service or your local distributor. Contact information can typically be found on the product packaging or the brand's official website.



Please have your product model number (R52691102) and purchase date ready when contacting support.

© 2023 RL LIVE YOUR LIGHT. All rights reserved.

This manual is subject to change without notice.

Related Documents - R52691102

 Product Training/Guidance Manual	<p>Gingko Design Product Catalog & Guidance Manual</p> <p>Explore the Gingko Design collection of innovative and stylish lighting, audio devices, and alarm clocks. This guide provides detailed product information, features, and care instructions for their unique products.</p>
--	--

	<p><u>MAULabby 820 07 LED Desk Lamp</u></p> <p>Information about the MAULabby 820 07 LED desk lamp, featuring a flexible arm, 15 LEDs, ON/OFF switch, and 1.6m cable. Includes specifications, energy efficiency class, and spare parts information.</p>
	<p><u>VIDEX VLE-TF05W-RGB LED Dimmable Desk Lamp with Clock and Alarm</u></p> <p>User manual for the VIDEX VLE-TF05W-RGB LED Dimmable Desk Lamp. Features include adjustable color temperature, brightness control, clock, alarm, and RGB lighting. Provides installation, operation, and safety guidelines.</p>
	<p><u>RL LED Rechargeable Table Lamp R521761XX - Safety & Specifications</u></p> <p>Concise guide to the RL LED rechargeable table lamp (Art.Nr. R521761XX), detailing essential safety warnings in multiple languages, product specifications, charging information, and manufacturer details.</p>
	<p><u>Desk Lamp with Pen Holder Manual - Model BQ-01</u></p> <p>User manual for the YOUKOYI LED Desk Lamp with Pen Holder, Model BQ-01. This guide details features such as multi-angle adjustment, pen holder, RGB atmosphere modes, brightness and color adjustments, smart clock functions, and timing settings.</p>
	<p><u>10W Wireless Charging Desk Lamp with Multi-Functional Features - User Guide</u></p> <p>Comprehensive user guide for the 10W Wireless Charging Desk Lamp, detailing its features like high-speed wireless charging, USB charging, adjustable lighting, LCD display, alarm, timer, and safety information.</p>