

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Intex](#) /
- › [Intex Explorer K2 Inflatable Kayak User Manual](#)

Intex 68307EP

Intex Explorer K2 Inflatable Kayak User Manual

Model: 68307EP

INTRODUCTION

The Intex Explorer K2 Inflatable Kayak Set is a lightweight, compact, and sporty 2-person kayak designed for lakes and mild rivers. Constructed from rugged SuperStrong PVC with an I-beam floor and high-buoyancy side chambers for stability, it offers a streamlined design for easy paddling and bright yellow graphics for high visibility. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure a safe and enjoyable experience.

PACKAGE CONTENTS

Your Intex Explorer K2 Kayak Set includes the following components:

- Intex Explorer K2 Inflatable Kayak
- Two 86-inch Aluminum Kayak Paddles
- Two Inflatable Seats with Backrests
- High-Output Hand Pump
- Heavy-Duty Grab Handles with Grab Lines
- Two Quick-Fill Boston Valves
- Removable Skeg
- Repair Patch
- Carrying Bag



Image: The complete Intex Explorer K2 Inflatable Kayak Set, including the yellow and gray kayak, two paddles, and a hand pump.

SETUP AND INFLATION

Initial Setup

Unfold the kayak on a clean, flat surface free of sharp objects. Ensure all valves are easily accessible.

Step-by-Step Inflation

The kayak features multiple air chambers for safety and stability. Inflate the chambers in the recommended numerical order using the provided high-output hand pump. The Boston valves allow for quick inflation and deflation.

1. Locate the main air chambers (typically marked 1 and 2 on the kayak body). Open the Boston valves and insert the pump hose.
2. Inflate the main chambers until they are firm to the touch but not hard. Avoid over-inflation.
3. Inflate the I-beam floor chamber (typically marked 3).
4. Inflate the bow and stern chambers (if applicable, typically marked 4 and 5).
5. Close all Boston valves securely by pushing the cap down and twisting.

EXPLORER K2



Inflated Size

123 x 36 x 20 in



Capacity

2-Person



Max Weight Capacity

400 lbs lbs., 199 kg.

Image: Diagram highlighting key features of the Explorer K2 Kayak, including inflation points and accessories.

Seat Installation

Inflate the two adjustable seats. Position them inside the kayak and secure them using the integrated straps and Velcro strips on the kayak floor. Adjust the straps to achieve desired backrest support.

Paddle Assembly

Assemble the two 86-inch aluminum paddles by connecting the sections. Ensure the paddle blades are oriented correctly for efficient paddling. The paddles can be disassembled for compact storage.



Image: Two aluminum paddles, which can be assembled from multiple sections for use and disassembled for storage.

Skeg Attachment

Attach the removable skeg to the bottom of the kayak at the rear. The skeg helps with directional stability and tracking in the water.



Image: A close-up view of the black removable skeg, designed to improve the kayak's directional stability.

OPERATION

Launching and Paddling

Carefully carry the inflated kayak to the water using the heavy-duty grab handles. Ensure both occupants are seated comfortably and securely. The streamlined design and included paddles facilitate easy navigation on lakes and mild rivers.



Image: Two individuals enjoying paddling the yellow and gray Intex Explorer K2 Kayak on a calm body of water.

Capacity and Weight Limit

The Explorer K2 is designed for two persons with a maximum weight capacity of 400 pounds (180 kg). Do not exceed the stated weight limit to ensure safety and optimal performance.

MAINTENANCE AND STORAGE

Cleaning and Care

After each use, rinse the kayak with fresh water to remove any dirt, sand, or salt. Allow the kayak to air dry completely before deflating and storing. Avoid prolonged exposure to direct sunlight when not in use.

Deflation and Storage

To deflate, open all Boston valves. You can use the pump in reverse mode (if applicable) or simply allow the air to escape naturally. Once deflated, fold the kayak neatly and place it in the included carrying bag. Store in a cool, dry place away from extreme temperatures and direct sunlight.



Image: The Intex Explorer K2 Kayak and its accessories neatly packed into the provided carrying bag for easy transport and storage.

TROUBLESHOOTING

Common Issues

- **Kayak losing air:** Check all valve caps to ensure they are securely closed. Inspect the kayak body for any punctures or leaks.
- **Small punctures:** Use the included repair patch kit to fix minor holes. Clean the area around the puncture, apply the patch, and allow it to dry completely before re-inflating.
- **Difficulty inflating:** Ensure the pump hose is properly connected to the valve. Check for any blockages in the pump or hose.

SPECIFICATIONS

Attribute	Value
Brand	Intex
Model Name	2-person
Part Number	68307EP
Item Weight	35.02 Pounds
Material	Vinyl
Color	Yellow
Style	2-person
Seating Capacity	2
Weight Limit	400 Pounds (180 kg)
Product Dimensions (L x W x H)	123" x 36" x 20" (10.3 ft x 3 ft x 1.8 ft)
Included Components	Kayak, 2 Paddles, 2 Seats, Pump, Skeg, Repair Patch, Carry Bag

WARRANTY AND SUPPORT

Warranty Information

The Intex Explorer K2 Kayak comes with a 90-Day Limited Manufacturer Warranty. Please refer to the warranty documentation included with your product for full details and terms.

Customer Support

For additional support, troubleshooting, or warranty claims, please visit the official Intex website or refer to the comprehensive user manual PDF available online. A digital copy of the user manual can be found [here](#).