

[Manuals.plus](#) /

› [Adtech](#) /

› AdTech Pro 75 Hot Glue Gun Kit Instruction Manual

## Adtech Pro 75

# AdTech Pro 75 Hot Glue Gun Kit Instruction Manual

Model: Pro 75

## PRODUCT OVERVIEW

The AdTech Pro 75 Hot Glue Gun Kit is designed for various crafting and bonding tasks, featuring a powerful 75-watt heater for quick heating and consistent glue flow. Its ergonomic design ensures comfort and control during use, making it suitable for both intricate details and larger projects. The kit includes three interchangeable nozzles and Artistick stringless glue sticks for versatile application.



Image: The AdTech Pro 75 Hot Glue Gun Kit, showcasing the gun and its three distinct nozzles.

## SETUP INSTRUCTIONS

1. **Insert Glue Stick:** Ensure the glue gun is unplugged. Insert a full-size (0.44 inch / 11.2 mm diameter) AdTech Artistick glue stick into the back of the gun. Push it gently until it stops.
2. **Select Nozzle:** Choose the appropriate nozzle for your project. The kit includes nozzles for general bonding, fine details, and gap filling. Screw the desired nozzle securely onto the gun's tip.
3. **Plug In:** Plug the glue gun into a standard 120-volt electrical outlet.
4. **Power On:** Locate the On/Off switch, typically on the side of the gun, and switch it to the 'On' position.
5. **Preheat:** Allow the glue gun to preheat for approximately 3-5 minutes. The 75-watt heater ensures rapid heating.



Image: A front view of the AdTech Pro 75 Hot Glue Gun, showing a glue stick properly inserted into the rear chamber.



Image: Full-size AdTech glue sticks, measuring 0.44 inches (11.2 mm) in diameter, suitable for the Pro 75 model.

## OPERATING INSTRUCTIONS

---

Once the glue gun is preheated, it is ready for use. The ergonomic trigger is designed for comfortable and precise glue application.

- **Applying Glue:** Gently squeeze the trigger to dispense hot glue. The amount of glue dispensed is proportional to the pressure applied to the trigger.
- **Continuous Flow:** The 75-watt heater ensures a steady and dependable glue flow, ideal for projects requiring continuous application.
- **Replacing Glue Sticks:** When a glue stick is nearly depleted, insert a new one into the back of the gun and push it forward to engage with the feeding mechanism.



Image: A user demonstrating the application of hot glue with the AdTech Pro 75 gun on a craft item.



Image: Close-up of the AdTech Pro 75 Hot Glue Gun utilizing a precision nozzle for detailed glue application.

## Nozzle Selection

---

The AdTech Pro 75 kit includes three interchangeable nozzles to customize your gluing experience:

- **Standard Nozzle:** For general bonding and everyday crafting.
- **Precision Nozzle:** Ideal for fine details, intricate work, and reaching small areas.
- **Spreader Nozzle:** Useful for covering larger surfaces or filling gaps efficiently.

To change nozzles, ensure the glue gun is unplugged and cooled. Carefully unscrew the current nozzle and screw on the desired one. Always ensure the nozzle is securely fastened before use.



Image: The three distinct interchangeable nozzles provided with the AdTech Pro 75 Hot Glue Gun Kit.

## FLEXIBLE DUAL-POSITIONING

The AdTech Pro 75 features an innovative design for convenient placement during and after use:

- **Stand-less Design:** The glue gun can rest on its side without dripping, helping to maintain a tidy workspace.
- **Foldable Stand:** A built-in foldable stand allows for upright stability when needed, providing flexibility in how you position the tool.

## MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your AdTech Pro 75 Hot Glue Gun:

- **Cleaning the Nozzle:** After use, while the gun is still warm (but unplugged), carefully wipe any excess glue from the nozzle with a heat-resistant cloth. Do not attempt to clean the nozzle when the gun is hot.

- **Storage:** Always unplug the glue gun and allow it to cool completely before storing. Store in a dry, safe place away from children.
- **Avoid Forcing Glue Sticks:** Do not force glue sticks into the gun. If a stick is jammed, allow the gun to heat up, then gently try to push it through or remove it.

## TROUBLESHOOTING

If you encounter issues with your AdTech Pro 75 Hot Glue Gun, refer to the following common solutions:

- **Gun Not Heating:** Ensure the glue gun is securely plugged into a working electrical outlet and the On/Off switch is in the 'On' position. Allow sufficient time for preheating (3-5 minutes).
- **No Glue Dispensing:** Check if a glue stick is properly inserted and engaged with the feeding mechanism. Ensure the gun is fully heated. If the nozzle is clogged, allow the gun to heat, then gently try to clear it with a small, non-flammable tool (e.g., a toothpick, carefully).
- **Excessive Dripping:** A small amount of dripping is normal for hot glue guns. Ensure the gun is fully heated before use, as underheated glue can drip more. Use the foldable stand or lay the gun on its side to minimize mess.

## SPECIFICATIONS

|                     |                                              |
|---------------------|----------------------------------------------|
| Brand               | Adtech                                       |
| Model               | Pro 75                                       |
| Power Source        | Corded Electric                              |
| Wattage             | 75 watts                                     |
| Voltage             | 120 Volts                                    |
| Compatible Material | Cardboard (and other common craft materials) |
| Included Components | Glue gun, 3 nozzles, glue sticks             |
| UPC                 | 026438548846                                 |

## WARRANTY AND SUPPORT

For warranty information, product support, or to purchase additional accessories and glue sticks, please visit the official AdTech website or contact AdTech customer service directly. Keep your purchase receipt for any warranty claims.

**AdTech Store:** [Visit the AdTech Store on Amazon](#)

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**