Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Aroepurt /
- › Aroepurt Slim Protective Case Compatible with Tibuta W100 8.9-inch Tablet Flip Stand Cover LXH User Manual

Aroepurt LXH

Aroepurt Slim Protective Case User Manual

Model: LXH | Compatible with Tibuta W100 8.9-inch Tablet

1. Introduction

Thank you for choosing the Aroepurt Slim Protective Case. This case is specifically designed to provide comprehensive protection and enhanced usability for your Tibuta W100 8.9-inch tablet. It features a durable polyurethane material, a stylish inkjet pattern, and practical functionalities like a foldable stand and magnetic closure.




Image 1.1: The Aroepurt Slim Protective Case in its closed position, showcasing its unique floral pattern and slim profile.

2. KEY FEATURES

- Enhanced Drop Protection: Features four reinforced corners designed to minimize damage from accidental drops.
- Magnetic Closure: Side magnets ensure the case remains securely closed for easier portability and protection.
- Slim and Lightweight Design: Engineered with a tension process to maintain a thin and light profile, adding minimal bulk to your tablet.
- Vibrant Inkjet Pattern: Adorned with an exquisite inkjet pattern that retains its brightness and color over time without fading.
- Foldable Stand Functionality: Allows the tablet to be positioned upright for comfortable viewing or typing.
- Precise Cutouts: Ensures full access to all device ports, speakers, and buttons.



Image 2.1: Visual representation of the case's all-over protection, slim design, and precise cutouts for ports and buttons.

3. SETUP AND INSTALLATION

Installing your tablet into the Aroepurt Protective Case is a straightforward process. Follow these steps to ensure a secure fit:

- 1. **Prepare Your Tablet:** Ensure your Tibuta W100 8.9-inch tablet is clean and free of dust or debris.
- 2. **Align the Tablet:** Gently align the tablet with the case, ensuring that the camera, ports, and buttons match the corresponding cutouts on the case.
- 3. **Insert the Tablet:** Carefully push the tablet into the case, starting with one side or corner, until all edges are securely seated within the protective frame. The flexible corners are designed to accommodate the tablet snugly.
- 4. **Check Fit:** Once inserted, gently press around the edges of the tablet to ensure it is fully seated and all corners are protected. Verify that all ports and buttons are accessible and functional.



Image 3.1: The case opened, illustrating the interior design and the designated slot for tablet insertion.

4. OPERATING THE CASE FEATURES

The Aroepurt Protective Case offers convenient features to enhance your tablet experience:

- **Using the Foldable Stand:** To use the stand function, simply fold the front cover back along the designated creases. The case is designed to create a stable triangular support, allowing for multiple viewing angles (e.g., upright for watching videos, or lower for typing).
- Securing the Case: When not in use, close the front cover. The integrated side magnets will automatically engage, keeping the case securely shut and protecting your tablet's screen.



Image 4.1: The case demonstrating its ergonomic structure, allowing for both viewing and typing angles.

5. CARE AND MAINTENANCE

To ensure the longevity and appearance of your Aroepurt Protective Case, follow these simple maintenance guidelines:

- Cleaning: Wipe the exterior of the case with a soft, damp cloth. For stubborn stains, a mild soap solution can be used, but avoid harsh chemicals or abrasive cleaners.
- Drying: Allow the case to air dry completely after cleaning. Do not expose it to direct sunlight or high heat, as

this may damage the material or pattern.

- **Storage:** Store the case in a cool, dry place when not in use. Avoid prolonged exposure to extreme temperatures.
- Avoid Sharp Objects: Keep the case away from sharp objects that could scratch or puncture the material.

6. TROUBLESHOOTING

While the Aroepurt Protective Case is designed for durability and ease of use, here are some common inquiries and their solutions:

- **Tablet Does Not Fit:** Ensure you have the correct model (Tibuta W100 8.9-inch tablet). If it is the correct model, gently re-align and apply even pressure to seat the tablet. Do not force it.
- Case Does Not Close Securely: Check for any obstructions between the tablet and the case cover. Ensure the tablet is fully seated within the case. The magnets should engage automatically.
- Stand Functionality Issues: Ensure the creases are properly folded to form a stable triangle. The stand may be less stable on very smooth or uneven surfaces.

7. PRODUCT SPECIFICATIONS

Brand	Aroepurt
Color	LXH
Compatible Devices	Tibuta W100 8.9-inch Tablet
Form Factor	Case
Material	Polyurethane
Special Feature	Thick anti-drop corner protection + foldable stand, Compatible with other similar sized models
Pattern	Fashion Personality
Theme	Colorful
Item Dimensions L x W x H	10 x 10 x 10 millimeters (approximate)

8. WARRANTY AND SUPPORT

This product is covered by the standard return policy of the retailer from which it was purchased. For specific warranty details or support inquiries, please refer to your purchase documentation or contact the seller directly.

For general product information or assistance, please visit the Aroepurt brand page or contact their customer service through the platform where you made your purchase.

Related Documents - LXH



Brinly-Hardy STS-42 LXH Lawn Sweeper Owner's Manual

Comprehensive owner's manual for the Brinly-Hardy STS-42 LXH Lawn Sweeper, covering assembly, operation, safety, maintenance, specifications, and troubleshooting. Learn how to properly use and care for your lawn sweeper.



Especificaciones de la Batería para Portátil XÜE BAT-LXH-1520 RX03XL

Detalles técnicos y especificaciones de la batería XÜE modelo BAT-LXH-1520 (RX03XL) para portátiles HP ProBook 440 G11, 460 G11 y 640 G11. Incluye voltaje, capacidad, tiempo de operación, protecciones y dimensiones.