

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Chongker](#) /

› [Chongker Interactive Robot Cat matecat 1.1 Instruction Manual](#)

Chongker matecat 1.1 (BPAI-C0001)

Chongker Interactive Robot Cat matecat 1.1 Instruction Manual

Model: matecat 1.1 (BPAI-C0001)

INTRODUCTION

The Chongker Interactive Robot Cat matecat 1.1 is a lifelike plush companion designed to provide emotional support and interactive engagement. Crafted with realistic features and bionic motion, it mimics the sounds and movements of a real cat, offering comfort and companionship without the responsibilities of a live pet. This manual provides essential information for setup, operation, maintenance, and safety to ensure optimal enjoyment of your interactive robot cat.

WHAT'S IN THE BOX

- 1 x Chongker Interactive Robot Cat (matecat 1.1)
- 1 x USB-C Charging Cable
- 1 x Grooming Comb
- 1 x Instruction Manual

REAL CAT SIZE & PACKAGE BONUS



Image: The Chongker Interactive Robot Cat alongside its packaging, USB-C charging cable, grooming comb, and instruction manual.

SETUP

- 1. Unpacking and Grooming:** Carefully remove the robot cat from its packaging. Use the included comb to gently fluff its fur, removing any loose hairs and restoring its lifelike appearance.
- 2. Locate Controls:** On the underside of the cat, locate the small button enclosure. Open it to reveal the power switch and charging port.
- 3. Charging:** Connect the provided USB-C charging cable to the charging port. Plug the other end into a compatible USB power source (not included). Allow the cat to fully charge before first use. The 4000mAh battery provides long standby time, typically over 18 hours of interactive play.
- 4. Power On/Off:** Slide the switch to the 'ON' position to activate the robot cat. To conserve battery, slide the switch to 'OFF' when not in use.
- 5. Volume Control/Mute:** The switch also allows you to adjust the volume or mute the cat's sounds.



Image: Detail of the hidden power switch and USB-C charging port on the robot cat's belly.

OPERATING INSTRUCTIONS

The Chongker Interactive Robot Cat is designed to respond to touch and environmental sounds, mimicking the behavior of a real cat.

- **Touch Interaction:** The cat features multiple touch-sensitive areas that trigger different responses.
 - **Head Sensor:** Petting the head may elicit meows or head movements.
 - **Back Sensor:** Stroking the back can activate purring sounds and gentle vibrations.
 - **Throat Sensor:** Touching the throat area may trigger purring or soft meows.
 - **Paw Activation:** Pressing a paw can activate various sounds and movements.
- **Bionic Motion:** The cat features realistic head and tail movements, enhancing its lifelike quality.
- **Purr and Heartbeat Sounds:** Experience soothing purring and a simulated heartbeat when interacting with the cat, providing a comforting presence.
- **Mimics Cat Meows:** The robot cat produces a variety of realistic cat meows, responding to its environment and interactions.
- **Automatic Sleep Mode:** If there is no interaction or touch for approximately three minutes, the cat will enter an automatic sleep mode to conserve battery. Simply interact with it again to wake it up.



Image: Touch contact points on the robot cat's head, back, and throat for interactive responses.



Image: Overview of sensor locations for interactive features.

Your browser does not support the video tag.

Video: A user demonstrates the unboxing and interactive features of the Chongker Interactive Robot Cat, highlighting its realistic appearance, soft fur, and responsive movements and sounds.

CARE AND MAINTENANCE

- **Grooming:** Regularly brush the cat's fur with the included comb to maintain its soft texture and lifelike appearance. This also helps remove any dust or debris.
- **Cleaning:** For surface cleaning, gently wipe with a damp cloth. Do not immerse the cat in water or use harsh cleaning agents, as this may damage the internal electronic components.
- **Battery Care:** Ensure the cat is fully charged before extended periods of non-use. Turn off the power switch when not in use to prolong battery life.
- **Storage:** Store the robot cat in a clean, dry place away from direct sunlight and extreme temperatures.

SAFETY INFORMATION

- **Avoid High-Temperature Environments:** Keep the toy away from extreme heat conditions such as direct sunlight or proximity to heating appliances. High temperatures can lead to overheating or fire hazards in the lithium battery.
- **Fire Safety Alert:** Please keep the toy away from flammable materials and objects. When not in use, remember to turn off the power switch promptly to reduce the risk of fire.
- **Handle with Care to Prevent Falls:** Avoid dropping the toy on hard surfaces, especially the part containing the lithium battery. Drops can cause battery damage or internal malfunctions.
- **Supervision of Children:** The use of the toy should be supervised by an adult, especially for younger children. Ensure that children understand how to play safely and supervise their activities at all times.

SPECIFICATIONS

Product Dimensions	12 x 6 x 16 inches
Item Weight	1.8 pounds
Item Model Number	BPAI-C0001
Recommended Age	6 years and up
Battery Type	1 Lithium Polymer battery (included)
Battery Capacity	4000mAh
Playtime on Full Charge	Over 18 hours

TROUBLESHOOTING

- **Cat is not responding:**

- Ensure the power switch on the underside is in the 'ON' position.
- Check if the battery is charged. Connect the USB-C cable and charge for a few hours.
- If in automatic sleep mode, gently pet the cat to wake it up.

- **Sounds are too loud/quiet or not audible:**

- Adjust the volume using the switch on the underside.
- Ensure the mute function is not activated.

- **Cat is not charging:**

- Verify the USB-C cable is securely connected to both the cat and the power source.
- Try a different USB power source or cable to rule out a faulty component.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Chongker website. Keep your purchase receipt as proof of purchase for any warranty claims.