

## Nesugar G2 Pro

# Nesugar G2 Pro Global Travel Steamer User Manual

Model: G2 Pro | Brand: Nesugar

## 1. INTRODUCTION

Thank you for choosing the Nesugar G2 Pro Global Travel Steamer. This compact and lightweight garment steamer is designed for efficient wrinkle removal, offering convenience for both travel and home use. Please read this manual thoroughly before operating the device to ensure safe and optimal performance.

## 2. IMPORTANT SAFETY INSTRUCTIONS

- Always unplug the steamer from the electrical outlet immediately after use and before cleaning or maintenance.
- Do not immerse the steamer, power cord, or plug in water or other liquids.
- Use only distilled or de-mineralized water in the water tank to prevent mineral buildup and extend the life of the steamer.
- Keep the steamer out of reach of children and pets.
- Do not touch the hot steam head during operation or immediately after use. Steam is hot and can cause burns.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting. The G2 Pro supports dual voltage (100V-240V).
- Never direct steam at people, animals, or electrical appliances.
- Do not operate the steamer with a damaged cord or plug, or if the appliance malfunctions or has been dropped or damaged.
- Always place the steamer on a stable, heat-resistant surface when not in use.

## 3. PRODUCT FEATURES

The Nesugar G2 Pro is engineered for convenience and performance:

- **Compact and Lightweight Design:** Weighing approximately 0.8 lbs, it is ideal for travel and easy handling.
- **Quick Heat-Up:** Reaches steaming temperature in approximately 15 seconds.
- **Dual Voltage Support:** Compatible with 100V to 240V, making it suitable for global travel.
- **Rotating Head:** Allows for both vertical steaming and flat ironing.

- **Non-Leaking Design:** Engineered to prevent water leakage during use.
- **Automatic Shut-Off:** For enhanced safety, the steamer includes an auto shut-off feature.
- **High Power Output:** 900W for effective steam generation.
- **Continuous Steaming:** Provides up to 10 minutes of continuous steam.
- **Three-Layer Vaporization:** Features an exclusive patented design for efficient steam production.




Image: Key features of the Nesugar G2 Pro Steamer, including its rapid heat-up time and continuous steam capability.



Image: Detailed view of the steamer's steam output, showcasing its advanced three-layer heating technology.

## 4. SETUP

---

1. **Unpack:** Carefully remove the steamer and all accessories from the packaging.
2. **Fill Water Tank:** Locate the water tank cap. Open it and fill the tank with distilled or de-mineralized water. Do not overfill. Close the cap securely.
3. **Connect Power:** Plug the power cord into a suitable electrical outlet. The steamer is designed for global voltage compatibility (100V-240V).




Image: The Nesugar G2 Pro Steamer demonstrating its global voltage compatibility for international use.


## 5. OPERATING INSTRUCTIONS

### 5.1 Power On and Pre-heat

- Once plugged in, press the power button. The indicator light will illuminate.
- Allow approximately 15 seconds for the steamer to heat up and begin producing steam.

## 5.2 Steaming Garments

- **Vertical Steaming:** Hang the garment on a hanger. Hold the steamer upright and gently glide the steam head over the fabric, moving from top to bottom. The rotating head allows for comfortable handling.
- **Flat Ironing:** For a crisper finish, place the garment on a flat, heat-resistant surface. Rotate the steam head to the flat position and press it against the fabric, moving slowly.
- **Fabric Compatibility:** The steamer is suitable for various fabrics. Always test on an inconspicuous area first.



**15 seconds**  
Steam faster

**10 minutes**  
Continuously steaming

**900W**  
High power

**Smart Control**  
2 gear steam

**Auto-off**  
Safety control

**Ultra performance.**

Image: Vertical steaming in progress, showing the steamer's effectiveness on hanging garments.

# Ultra Steam.

Exclusive patented design of  
three-layer heating element




Image: Flat ironing a garment, illustrating the steamer's ability to function as a compact iron.

Your browser does not support the video tag.

Video: Official Nesugar demonstration of the G2 Pro steamer in use, highlighting its features and ease of operation.

## 6. MAINTENANCE

### 6.1 After Each Use

- Unplug the steamer and allow it to cool completely.
- Empty any remaining water from the tank.
- Wipe the exterior with a soft, damp cloth.

## 6.2 Storage

- Store the steamer in a cool, dry place.
- Utilize the provided accessories for convenient hanging and cord winding storage.



**Flat ironing  
&  
Hanging ironing.**



7. TROUBLESHOOTING

| Problem                | Possible Cause                                                           | Solution                                                                                         |
|------------------------|--------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
| No steam or weak steam | Water tank empty; Not heated sufficiently; Mineral buildup.              | Refill water tank; Allow 15 seconds for pre-heating; Descale the steamer (refer to maintenance). |
| Water leakage          | Water tank cap not secured; Overfilled tank; Steamer tilted excessively. | Ensure cap is tight; Do not overfill; Keep steamer upright during use.                           |
| Steamer not turning on | Not plugged in; Power outlet issue; Auto shut-off activated.             | Check power connection; Try a different outlet; Unplug and replug to reset.                      |

8. SPECIFICATIONS

- **Brand:** Nesugar
- **Model Number:** G2 Pro
- **Color:** Pink
- **Item Weight:** 12.8 ounces
- **Voltage:** 100-240 volts (Dual Voltage)
- **Heat Time:** Approximately 15 seconds
- **Product Benefits:** Remove Wrinkle
- **Style:** Modern, Compact

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official Nesugar website. Keep your purchase receipt as proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**