



[Manuals.plus](#) /

> [Leebein](#) /

> Leebein Electric Spin Scrubber User Manual

Leebein YMG-820

Leebein Electric Spin Scrubber User Manual

Model: YMG-820 | Brand: Leebein

INTRODUCTION

The Leebein Electric Spin Scrubber (Model YMG-820) is designed to simplify your cleaning tasks, offering powerful scrubbing action for various surfaces. This manual provides essential information for safe and effective use, setup, operation, maintenance, and troubleshooting.

SAFETY INFORMATION

Read all instructions before use to prevent injury or damage to the product.

- Keep the device away from children and pets.
- Do not immerse the main unit in water unless specified (this model is IPX7 waterproof, allowing for submersion, but avoid prolonged immersion).
- Use only the provided USB-C charging cable.
- Ensure the device is fully charged before first use.
- Do not operate the scrubber if it appears damaged or is not functioning correctly.
- Avoid applying excessive pressure, which can slow down the motor or damage surfaces.

PACKAGE CONTENTS

Verify all components are present in your package:

Item	Quantity
Remote Handle	1
YMG-820 Scrubber Main Unit	1
Extended Rod	1

Item	Quantity
Large Flat Brush	1
Pointed Brush	1
Small Flat Brush	1
Dome Brush	1
Wool Brush	1
Fiber Brush	1
Sponge Brush	1
Cloth Brush	1
User Manual	1
Charging Cable	1
Wall Hook	1



Cloth Brush

Sponge Brush

Image: Overview of the Leebein Electric Spin Scrubber components, including the main unit, handle, extension rod, and various brush heads.

SETUP

1. Assembly:

Attach the desired brush head to the main scrubber unit by aligning the tabs and twisting until it locks into place. For extended reach, connect the extended rod between the main scrubber unit and the remote handle. Ensure all connections are secure and click into position.

2. Charging:

Before first use, fully charge the scrubber. Connect the USB-C charging cable to the charging port on the main unit and plug the other end into a compatible USB power adapter (not included). The LED indicator lights will show charging status. A full charge takes approximately 2.5 hours and provides 60-90 minutes of runtime.



Image: The Leebein Electric Spin Scrubber shown in its assembled form with different brush heads, illustrating its modular design.

OPERATING INSTRUCTIONS

1. Power On/Off:

Press the power button on the handle to turn the scrubber on or off.

2. Adjusting Spin Speed:

The scrubber features two adjustable spin speeds: 350 RPM (revolutions per minute) and 450 RPM. Press the mode button (M) to switch between speeds, selecting the appropriate power for your cleaning task.

3. Adjusting Angles:

The scrubber head can be adjusted to four different angles: 90°, 120°, 150°, and 180°. This allows for versatile cleaning in various hard-to-reach areas, such as corners, high walls, or low floors.

4. Remote Control Operation:

The included remote control allows you to adjust the speed or turn the machine on/off without bending or kneeling. This feature enhances convenience, especially when using the extended handle for distant cleaning.

Powerful Scrubber for Deep Cleaning

350-450
RPM

Stubborn
Stains

2500*2
mAh

90Min
Runtime



Image: Diagram illustrating the adjustable length (15in, 42in, 52in) and four adjustable angles (90°, 120°, 150°, 180°) of the Leebein Electric Spin Scrubber.

BRUSH HEAD APPLICATIONS

The Leebein YMG-820 includes 8 durable and recoverable brush heads, each designed for specific cleaning tasks:

- **Dome Brush:** Ideal for cleaning bathtubs, toilets, and sinks. Its rounded shape allows it to reach curved surfaces effectively.

- **Large Flat Brush:** Suitable for large flat surfaces such as tile floors, walls, and pools. Can also be used on carpets.
- **Small Flat Brush:** Perfect for smaller flat areas, kitchen sinks, and countertops.
- **Corner Brush:** Designed for cleaning grout lines, faucets, and tight edges.
- **Cloth Brush:** Gentle brush for wooden floors and furniture cleaning.
- **Sponge Brush:** Excellent for cleaning windows, glass, and car surfaces.
- **Wool Brush:** Soft brush for delicate surfaces like leather sofas and car interiors.
- **Fiber Brush (Scouring Pad):** For tougher stains on surfaces like stovetops and oven grates.



Image: Visual guide to the different brush heads included with the Leebein Electric Spin Scrubber and their recommended applications.

MAINTENANCE

1. **Cleaning Brush Heads:**

After each use, remove the brush head and rinse it thoroughly under running water. If bristles are bent, sprinkle hot water on them to help them recover their shape.

2. **Cleaning the Main Unit:**

Wipe the main unit with a damp cloth. Do not use abrasive cleaners. The YMG-820 model is IPX7 waterproof, meaning the whole unit can be submerged for cleaning, but avoid prolonged immersion.

3. **Storage:**

Store the scrubber and its accessories in a dry place, away from direct sunlight. Use the provided wall hook for convenient storage.

Best Gift for Beloved One



Image: The Leebein Electric Spin Scrubber shown with its included wall hook for easy storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Scrubber does not turn on	Low battery; Power button not pressed correctly	Charge the battery; Ensure power button is pressed firmly
Brush head stops spinning or spins slowly	Low battery; Excessive pressure applied; Obstruction	Recharge the battery; Reduce pressure; Check for and remove any obstructions
Bristles are bent	Normal wear and tear; Improper storage	Sprinkle hot water on bristles to help them recover; Store properly
Remote control not working	Remote battery low; Interference	Check remote battery (if applicable); Ensure no obstructions between remote and unit

SPECIFICATIONS

Feature	Detail
Model	YMG-820
Brand	Leebein
Color	Black
Handle Material	Plastic
Product Dimensions	10"L x 4"W x 10"H
Material	Stainless Steel
Special Features	2-Year Warranty, 8 Replaceable Head, Extendable Handle, Remote Control, Adjustable Angle
Item Weight	2.7 Pounds
Batteries	2 Lithium Ion batteries (included)
UPC	791126557744
Country of Origin	China

WARRANTY AND SUPPORT

Leebein provides a 90-day worry-free refund and a 2-Year extended protection plan for the YMG-820 Electric Spin Scrubber. We choose high-end materials and high-quality internal components to ensure our products have a long service life.

For any issues, questions, or support needs, please do not hesitate to contact the Leebein support team. We are dedicated to providing high-quality products and customer service.

You can find more information and contact details on the official Leebein store page: [Leebein Store](#).



The Brand You Can Trust



Millions of Families' Choice



150+ Countries on Sell



2 Years Extended Protection Plan



Image: Leebein's brand message emphasizing trust, millions of families' choice, 150+ countries on sale, and a 2-year extended protection plan.