

GENGQIANSI NIU25

GENGQIANSI NIU25 Replacement Remote Control User Manual

For Clarion FZ-709, M-309, M-109, FZ-709E, CZ702A, CZ702E, CZ703A, CZ703E Car Receiver Audio Systems

1. INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your GENGQIANSI NIU25 replacement remote control. This remote is designed to function as a direct replacement for various Clarion car receiver audio systems without requiring any programming.

1.1. Compatibility

The GENGQIANSI NIU25 remote control is compatible with the following Clarion car receiver audio system models:

- Clarion FZ-709
- Clarion M-309
- Clarion M-109
- Clarion FZ-709E
- Clarion CZ702A
- Clarion CZ702E
- Clarion CZ703A
- Clarion CZ703E

Replacement for following models:



Figure 1: Examples of original remote controls compatible with this replacement unit.

2. PACKAGE CONTENTS

Please check the package contents upon receipt to ensure all items are present:

- 1x GENQIANSI NIU25 Replacement Remote Control
- 1x Wall Mounting Bracket

Note: AAA 1.5V batteries (x2) are not included and must be purchased separately.



Figure 2: Remote control and wall mounting bracket included in the package.

3. SETUP

3.1. Battery Installation

The remote control requires two AAA 1.5V batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA 1.5V batteries, ensuring the positive (+) and negative (-) terminals match the indicators inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Battery type:

AAA1.5V



Figure 3: Required battery type: AAA 1.5V.







Figure 4: Rear view of the remote control, highlighting the battery compartment.

NEW
Good design
with 1.5V AAA
battery

Long durable years: over 5 years



OLD
Bad design
with coin battery

Short durable years: 1~2 years



Figure 5: The remote uses standard AAA batteries for extended life.

3.2. Wall Mounting Bracket Installation

The included wall mounting bracket allows for convenient storage of your remote control. To install:

1. Choose a suitable location near your car receiver audio system.
2. Use screws (not included) to secure the bracket to the wall or a flat surface.
3. Slide the remote control into the bracket for storage.





Figure 6: Remote control inserted into the wall mounting bracket.



Figure 7: Example of the remote control and bracket installed in a living space.

4. OPERATING INSTRUCTIONS

This replacement remote control operates identically to your original Clarion remote. No programming is required; simply insert batteries and point the remote towards your car receiver audio system.

- Not Easy Broken**
- Easy Hold**
- Not Easy Lost**
- Easy Operating**
- Cheap Battery**
- Reliable Quality**
- Long Life**




Figure 8: Layout of the GENGQIAN SI NIU25 remote control buttons.

4.1. Button Functions

Button	Function
POWER	Turns the audio system on or off.
FUNC / SRC	Selects the audio source (e.g., Radio, CD, USB, AUX).
DSP	Activates or adjusts Digital Sound Processing modes.
BAND	Switches between radio bands (e.g., FM1, FM2, AM).
DISC UP / PROG TOP	For CD changers, selects the next disc. For programming, navigates to the top level.
VOLUME Up/Down	Adjusts the audio volume level.
SEARCH Left/Right	Searches for radio stations or navigates tracks/chapters.
Play/Pause	Plays or pauses current audio playback.

Button	Function
Skip Forward/Backward	Skips to the next or previous track/chapter.
MUTE	Mutes or unmutes the audio output.
ISR / TA	Activates or deactivates Traffic Announcement (TA) or other Intelligent Sound Retrieval functions.
DISP	Changes the display information on the audio system.
EQ	Accesses or adjusts equalizer settings.
SCN	Initiates a scan function (e.g., radio station scan).
RDM	Activates or deactivates random/shuffle playback.
RPT	Activates or deactivates repeat playback.

5. MAINTENANCE

5.1. Battery Replacement

When the remote control's performance degrades or it stops responding, it is likely time to replace the batteries. Refer to Section 3.1 for detailed battery installation instructions. Always use two fresh AAA 1.5V batteries.

5.2. Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Avoid using liquid cleaners, abrasive materials, or solvents, as these can damage the remote's finish or internal components.

6. TROUBLESHOOTING

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote not responding:**
 - Check if the batteries are installed correctly with the correct polarity (+/-).
 - Replace old batteries with new AAA 1.5V batteries.
 - Ensure there are no obstructions between the remote control and the car receiver's infrared sensor.
 - Make sure you are within the effective operating range of the receiver.
- **Specific buttons not working:**
 - Clean the remote control surface, especially around the unresponsive buttons, to remove any dirt or debris that might be interfering.
 - If only certain buttons fail, and battery replacement does not help, the remote may be faulty.
- **Intermittent operation:**
 - This often indicates low battery power. Replace the batteries.
 - Ensure a clear line of sight to the receiver.

If troubleshooting steps do not resolve the issue, please contact customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Model	NIU25
Brand	GENGQIANSI
Compatibility	Clarion FZ-709, M-309, M-109, FZ-709E, CZ702A, CZ702E, CZ703A, CZ703E Car Receiver Audio Systems
Battery Type	2 x AAA 1.5V (not included)
Item Weight	1.06 ounces (approximately 30 grams)
Package Dimensions	5 x 2 x 1 inches (approximately 12.7 x 5.1 x 2.5 cm)
Special Feature	No programming required

8. WARRANTY AND SUPPORT

For any questions, concerns, or technical support regarding your GENGQIANSI NIU25 replacement remote control, please contact the seller or manufacturer through your purchase platform. Please retain your proof of purchase for warranty claims, if applicable.