## GAOMON VC4-dresser11

# GAOMON Chest with 6 Drawers Instruction Manual

Model: VC4-dresser11

### 1. Important Safety Information

Please read and understand all instructions before assembling and using this product. Failure to follow these instructions may result in injury or damage to the product.

- Keep all packaging materials away from children and pets.
- Assemble the chest on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not allow children to climb on or play with the chest.
- Always use the included anti-tip kit to secure the chest to a wall. This is crucial to prevent serious injury from tipping furniture.
- Do not overload drawers. Distribute weight evenly.

### 2. Package Contents

Before beginning assembly, verify that all parts and hardware are present. If any items are missing or damaged, please contact customer service.



*Image 2.1: GAOMON Chest with 6 Drawers. This image displays the fully assembled chest, featuring six drawers with gold handles and a gold-finished metal base.*

### Expected Components:

- Chest panels (top, bottom, sides, back)
- Drawer panels and bases (for 6 drawers)
- Drawer slides (left and right)
- Metal frame/legs
- Hardware pack (screws, dowels, cam locks, handles, anti-tip kit)
- Assembly instructions sheet

## 3. Assembly Instructions (Setup)

Assembly is required for this product. Follow the steps carefully to ensure proper construction and stability.

### Tools Required (Not Included):

- Phillips head screwdriver
- Hammer (optional, for dowels)
- Drill (for anti-tip kit installation, if needed)

### Assembly Steps:

1. **Unpack and Identify Parts:** Lay out all components and hardware. Compare them with the parts list in the separate assembly guide to ensure everything is present.
2. **Assemble the Main Frame:** Attach the side panels to the bottom panel using the provided hardware (e.g., cam locks and dowels). Secure the back panel.
3. **Install Drawer Slides:** Attach the drawer slides to the interior side panels of the chest frame according to the markings. Ensure they are level and aligned.
4. **Assemble Drawers:** Construct each of the six drawers by attaching the side, front, and back panels to

the drawer base. Install the remaining drawer slides onto the assembled drawers. Attach the golden handles to the drawer fronts.

5. **Insert Drawers:** Carefully slide each assembled drawer into its corresponding slot in the chest frame. Ensure smooth operation.
6. **Attach Metal Base:** Secure the golden metal base to the bottom of the chest frame using the designated screws.
7. **Install Anti-Tip Kit:** Following the instructions provided with the anti-tip kit, secure the chest to a wall stud. This step is critical for safety.

## 4. Usage (Operating)

The GAOMON Chest with 6 Drawers is designed for storing clothing, linens, and other personal items.

- **Drawer Operation:** To open a drawer, gently pull the handle. To close, push the drawer firmly until it is fully seated. Avoid forcing drawers.
- **Weight Distribution:** Distribute items evenly within the drawers. Avoid placing excessively heavy items in a single drawer or on the top surface of the chest to maintain stability and prevent damage.
- **Placement:** Place the chest on a level, stable surface. Ensure it is secured to the wall using the anti-tip kit.

## 5. Maintenance and Care

Proper care will extend the life and appearance of your GAOMON Chest.

- **Cleaning:** Wipe the surface with a dry, soft cloth. Avoid using abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the finish.
- **Hardware Check:** Periodically check all screws, bolts, and fasteners to ensure they remain tight. Re-tighten as needed to maintain structural integrity.
- **Drawer Slides:** If drawers become stiff, a small amount of silicone-based lubricant can be applied to the drawer slides.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the finish.

## 6. Troubleshooting

If you encounter issues with your chest, refer to the following common problems and solutions.

| Problem | Possible Cause | Solution |
|---|---|---|
| Chest wobbles or is unstable. | Uneven floor; loose hardware; anti-tip kit not installed. | Ensure chest is on a level surface. Tighten all assembly screws. Install the anti-tip kit securely to a wall stud. |
| Drawers do not slide smoothly. | Drawer slides misaligned; debris in slides; overloaded drawer. | Check that drawer slides are correctly installed and aligned. Clean any debris from the slides. Reduce the weight in the drawer. Apply silicone lubricant if necessary. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Drawer does not close completely. | Obstruction; misaligned drawer; items blocking closure. | Remove any items blocking the drawer. Check drawer alignment. Ensure drawer slides are not bent or damaged. |

## 7. Specifications

Detailed specifications for the GAOMON Chest with 6 Drawers.





*Image 7.1: GAOMON Chest with 6 Drawers, illustrating its dimensions: 47.2 inches (width), 15.7 inches (depth), and 24.8 inches (height).*

| Feature | Detail |
|---|---|
| Model Number | VC4-dresser11 |
| Dimensions (Overall) | 47.2" W x 15.7" D x 24.8" H |
| Number of Drawers | 6 |
| Color | White & Grey |
| Material | Engineered Wood with Metal Frame and Gold Finish Accents |
| Item Weight | Approximately 86 lbs |
| Assembly Required | Yes |
| Product Care Instructions | Wipe with Dry Cloth |

## 8. Warranty and Support

GAOMON is committed to providing quality products and customer satisfaction.

If you have any questions regarding the assembly, parts, or operation of your GAOMON Chest with 6 Drawers, please do not hesitate to contact our customer service. We are dedicated to providing effective and responsive after-sale support to address any concerns you may have.

Please refer to your purchase documentation for specific warranty details and contact information.

© 2023 GAOMON. All rights reserved.