Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YESHOMY YH-CT0247-88

YESHOMY Round Coffee Table User Manual

Model: YH-CT0247-88

Product Overview

The YESHOMY Round Coffee Table is a versatile and functional piece of furniture designed for living spaces. It features a two-tier design, providing ample storage and display area. Crafted from high-quality wood, this table offers durability and a rustic aesthetic, making it suitable for various room layouts, including living rooms, bedrooms, or hallways.



Image: The YESHOMY Round Coffee Table, showcasing its two-tier design and light oak brown finish, positioned on a rug in a living room.

Safety Information

Please read and adhere to the following safety guidelines to ensure safe use of your coffee table:

- Do not exceed the weight limit of 40 pounds on any part of the table.
- Follow all assembly instructions carefully using only the included tools.
- Be cautious of pinch points, especially when assembling or moving the shelves.
- Keep small children and pets away from the assembly area.
- Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten if necessary.

Package Contents

Before beginning assembly, please verify that all components listed below are present and undamaged:

- Coffee Table Components (Top, Bottom Shelf, Legs)
- Tool Kit (Includes necessary wrenches/screwdrivers)
- Assembly Guide

If any parts are missing or damaged, please contact customer support immediately.

Assembly Instructions

The YESHOMY Round Coffee Table is designed for straightforward assembly. Please follow the steps outlined in the included Assembly Guide for detailed instructions. A general overview is provided below:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Legs to Top:** Securely fasten the table legs to the underside of the top circular panel using the provided hardware.
3. **Install Bottom Shelf:** Position the bottom circular shelf between the legs and secure it in place. The X-shaped base provides enhanced stability.
4. **Tighten All Fasteners:** Once all components are in place, ensure all screws and bolts are fully tightened for stability.



Image: An illustration highlighting the stable X-shaped structure of the coffee table's base, indicating a weight capacity of 300 lbs for the top surface.



Image: Detailed views of the table's features, including its sleek rounded edges, the accessible open shelf for storage, and the robust, high-strength right-angle feet.

Usage and Placement

This coffee table is designed for indoor use and can be placed in various settings:

- **Living Room:** Ideal as a central coffee table, providing surface area for drinks, books, and decorative items.
- **Bedroom:** Can function as a spacious side table or a display table.
- **Hallway:** Suitable as an accent or display table in larger entryways.

The two-tier design allows for efficient organization, with the lower shelf perfect for magazines, remote controls, or small storage baskets.

Care and Maintenance

To maintain the appearance and longevity of your YESHOMY coffee table, follow these simple care instructions:

- **Cleaning:** Wipe the surface with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the wood finish.
- **Spills:** Promptly wipe up any spills to prevent staining or water damage.
- **Heat and Moisture:** Use coasters under hot items and drinks to protect the surface from heat marks and moisture rings.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.
- **Movement:** When moving the table, lift it rather than dragging it to prevent damage to the legs and floor.



Image: A visual representation of the high-quality natural wood material used in the construction of the coffee table, emphasizing its environmental friendliness.

Troubleshooting

If you encounter any issues with your coffee table, please refer to the following common solutions:

Problem	Possible Cause	Solution
Table is wobbly	Loose fasteners or uneven floor.	Check and tighten all screws. If the floor is uneven, consider using furniture pads or shims under the legs.
Color appears different from product images	Variations in lighting during photography or differences in display screen settings. Natural wood grain variations.	This is often due to natural variations in wood and photographic conditions. The actual product color is Light Oak Brown.
Missing or defective parts upon arrival	Manufacturing or packaging error.	Do not attempt to force assembly. Contact YESHOMY customer service immediately for replacement parts.

Specifications

Attribute	Detail
Brand	YESHOMY
Model Name	Round Coffee Table
Model Number	YH-CT0247-88
Color	Light Oak Brown
Material	Wood
Product Dimensions (D x W x H)	35.5"D x 38.5"W x 18"H
Item Weight	40 Pounds
Max Weight Capacity (Top)	Approximately 300 lbs (as indicated in product images)
Shape	Round
Included Components	Assembly Guide, Installation Tool
Care Instructions	Wipe with Damp Cloth



Image: A detailed diagram illustrating the dimensions of the YESHOMY Round Coffee Table, including its diameter, height, and shelf spacing.

Warranty and Support

For any questions regarding your YESHOMY Round Coffee Table, including warranty information, missing parts, or assembly assistance, please contact YESHOMY customer support directly. Refer to the contact information provided with your purchase or visit the official YESHOMY website for support details.

Note: Specific warranty terms and conditions may vary. Please retain your proof of purchase for warranty claims.

© 2024 YESHOMY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CM19R3BC

More documents and user manuals: **https://manuals.plus/**