Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ULTIMEA U3600

ULTIMEA Apollo S50 4.1ch Detachable Sound Bar User Manual

Model: U3600

1. Introduction

The ULTIMEA Apollo S50 is a versatile 4.1ch sound bar system designed to enhance your home audio experience. Featuring a unique 2-in-1 detachable design, it offers flexible placement options to suit your living space. With a powerful 200W peak output and a dedicated wired subwoofer, it delivers rich, immersive sound for movies, music, and games. Advanced DSP technology ensures clear dialogue and balanced audio. Seamless connectivity options including ARC, Optical, AUX, and Bluetooth 5.3 provide broad compatibility with various devices.

2. What's in the Box

- 1 x Soundbar Unit
- 1 x Wired Subwoofer
- 1 x Power Adaptor
- 1 x Remote Control
- 1 x ARC Cable
- 1 x Digital Optical Cable
- 1 x Stereo RCA to 3.5mm Audio Cable
- 1 x Stereo RCA to RCA Audio Cable (3.9 inches)
- 1 x Stereo RCA to RCA Audio Cable (98 inches)
- 2 x Wall Mounting Sets
- 2 x Wall Bracket
- 2 x Base
- 1 x Quick Start Guide



Image: Complete package contents of the ULTIMEA Apollo S50 sound bar system.

3. Setup

3.1 Assembly

The Apollo S50 sound bar features a detachable design, allowing for flexible placement as a single sound bar or two separate tower speakers.

Single Sound Bar Assembly:

1. Align and merge the two sound bar parts.
2. Twist the parts into place to secure them.
3. Plug in the Stereo RCA to RCA Audio Cable (100mm) to connect the internal channels between the two merged sound bar sections.

Two Tower Speakers Setup:

1. Detach the two sound bar units.
2. Set each sound bar unit onto its respective base, aligning the joints and twisting to connect.
3. Plug in the Stereo RCA to RCA Audio Cable (2.5m) to connect the two tower speakers.



Image: Visual guide for assembling the sound bar as a single unit or two tower speakers.

3.2 Connections

Connect the wired subwoofer to the "SUB OUT" port on the sound bar. Then, connect the sound bar to your TV using one of the following methods:




Image: Rear view of the sound bar showing DC IN, ARC, Optical, AUX, USB, and Subwoofer ports.

HDMI ARC Connection (Preferred):

Insert one end of the ARC cable into your TV's HDMI ARC/eARC OUTPUT port. Insert the other end into the sound bar's ARC port. Connect the power supply to the sound bar and a wall outlet. Press the "ARC" button on the remote control to select "ARC" input. Ensure your TV's sound output settings are configured to output audio to the connected HDMI (Receiver) device.



Image: Step-by-step guide for connecting via HDMI ARC.

Optical Connection:

Remove the protective caps from both ends of the Digital Optical Cable. Insert one end into your TV's Optical OUT port. Insert the other end into the sound bar's Optical port. Connect the power supply. Press the "OPT" button on the remote control to select "OPT" input. Configure your TV's sound output to Optical.



Image: Step-by-step guide for connecting via Optical cable.

AUX Connection:

Plug the straight end of the AUX cable into the AUX OUT port of your TV. Insert the angled end into the AUX port on the back of the sound bar. Connect the power supply. Select the AUX mode via the "AUX" button on the remote control.

Bluetooth Connection:

Press the "BT" button on the remote control. The sound bar's LED will display "bt" and a voice prompt will say "Pairing". Turn on Bluetooth on your smartphone or TV and select "ULTIMEA Apollo S50" from the list of available devices. Once connected, the sound bar will announce "Connected".



Image: Demonstrates connecting a smartphone to the sound bar via Bluetooth 5.3.

Video: Instructions - ULTIMEA Apollo S50 Detachable Soundbar. This video provides a comprehensive guide to unboxing, assembling, and connecting the sound bar via ARC, Optical, AUX, and Bluetooth, including troubleshooting for no sound issues.

4. Operating Instructions

Use the included remote control to manage your sound bar. The remote allows you to power on/off, adjust volume, switch input modes (ARC, BT, AUX, OPT, USB), and select preset EQ modes.

4.1 EQ Modes

The Apollo S50 offers three preset EQ modes for optimized audio:

- **Movie Mode:** Enhances dialogue clarity and cinematic effects.
- **Game Mode:** Provides immersive soundscapes for gaming.
- **Music Mode:** Delivers balanced audio for music playback.

4.2 BassMX Technology

ULTIMEA's exclusive BassMX technology enriches low frequencies, allowing for adjustable bass levels to suit your preference. Use the BassMX button on the remote to cycle through bass settings.

4.3 CEC Synchronization

When connected via ARC, the sound bar supports CEC synchronization, allowing you to control both your TV and the sound bar simultaneously using your TV's remote control for power on/off and volume adjustments.

5. Maintenance

To ensure the longevity and optimal performance of your ULTIMEA Apollo S50 sound bar, follow these general maintenance guidelines:

- Keep the sound bar and subwoofer clean by wiping them with a soft, dry cloth.
- Avoid using liquid cleaners or abrasive materials, as they may damage the finish.
- Ensure proper ventilation around the units to prevent overheating.
- Protect the units from direct sunlight, extreme temperatures, and high humidity.
- When not in use for extended periods, unplug the power adapter from the wall outlet.

6. Troubleshooting

No Sound After Connection:

If you have connected the sound bar but hear no sound, ensure your TV's digital audio output format is set to PCM. Different TVs may have different setup steps, but typically you can find this setting under: **Settings → Sound → Digital Audio Format → PCM**.




Image: Example of TV settings to change Digital Output Audio Format to PCM.

Remote Control Issues:

Ensure there are no obstructions between the remote control and the sound bar. Check and replace the remote control batteries if necessary.

Bluetooth Pairing Issues:

Make sure the sound bar is in Bluetooth pairing mode. Ensure your device's Bluetooth is enabled and within range. Try unpairing and re-pairing the device.

7. Specifications

Feature	Description
Model Name	Apollo S50
Speaker Type	Soundbar with Subwoofer
Peak Power	200W
Surround Sound Channel Configuration	4.1
Connectivity Technology	ARC/Optical/AUX/USB, Bluetooth 5.3
Product Dimensions	31.93"D x 2.76"W x 3.86"H
Item Weight	14.97 pounds
Special Features	Wired Subwoofer, Detachable Design, BassMX Technology

8. Warranty & Support

The ULTIMEA Apollo S50 comes with a Limited Warranty. For detailed warranty information, product support, or technical assistance, please contact ULTIMEA Direct, the official seller. You can typically find support contact information on the ULTIMEA official website or through your purchase platform.

© 2024 ULTIMEA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CM2WP5N2

More documents and user manuals: **https://manuals.plus/**