

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [SnapFresh](#) /

> [SnapFresh Cordless Electric Scissor Charger \(Model ECC0601\) Instruction Manual](#)

## SnapFresh ECC0601

# SnapFresh Cordless Electric Scissor Charger (Model ECC0601) Instruction Manual

Comprehensive guide for the safe and efficient use of your SnapFresh 4V Electric Mini Cutter Charger.

## 1. PRODUCT OVERVIEW

The SnapFresh Cordless Electric Scissor Charger (Model ECC0601) is designed exclusively for charging the SnapFresh 4V Electric Mini Cutter (Model EC0601). This compact and lightweight charger ensures your electric mini cutter is always ready for use, providing efficient and safe power delivery.




Image 1.1: The SnapFresh Cordless Electric Scissor Charger (Model ECC0601).

**Compatibility:** This charger is specifically designed for the SnapFresh 4V Electric Mini Cutter (EC0601). Using it with other devices may cause damage to the charger or the device.

## 2. SAFETY INFORMATION

Please read and understand all safety instructions before using the charger. Failure to follow these

instructions may result in electric shock, fire, or serious injury.

- Use the charger only with the specified SnapFresh 4V Electric Mini Cutter (EC0601).
- Do not expose the charger to rain or wet conditions. Water entering the charger will increase the risk of electric shock.
- Do not abuse the cord. Never use the cord for carrying, pulling, or unplugging the charger. Keep cord away from heat, oil, sharp edges, or moving parts.
- Do not operate the charger if it has received a sharp blow, been dropped, or otherwise damaged. Take it to an authorized service center for inspection.
- Unplug the charger from the power source when not in use or before cleaning.
- Do not disassemble the charger. Refer all servicing to qualified service personnel.

### **3. SETUP AND CHARGING INSTRUCTIONS**

---

Follow these steps to properly set up and charge your SnapFresh 4V Electric Mini Cutter:

1. Ensure the SnapFresh 4V Electric Mini Cutter (EC0601) is turned off before connecting the charger.
2. Locate the charging port on the electric mini cutter.
3. Insert the charger's output plug into the charging port of the electric mini cutter.
4. Plug the charger's power adapter into a standard electrical outlet.



**FAST CHARGING  
LONGER RUNTIME**



## QUICK & SAFE CHARGING

Image 3.1: The charger connected to the SnapFresh 4V Electric Mini Cutter, illustrating the charging process.

**Indicator Light:** The charger features a clear indicator light. When the battery is charging, the indicator light will illuminate **red**. Once the battery is fully charged, the light will typically change color or turn off (refer to the electric mini cutter's manual for specific full charge indication).



**FOR SNAPFRESH ONLY**

**FIT FOR EC0601**

Image 3.2: Close-up of the charger connected to the SnapFresh EC0601, emphasizing exclusive compatibility.

The charger is designed for quick and safe charging, ensuring optimal performance and longevity of your electric mini cutter's battery.

#### **4. OPERATING THE ELECTRIC MINI CUTTER (EC0601)**

While this manual focuses on the charger, understanding the basic operation of the compatible tool is essential for proper use.

- Ensure the battery is fully charged before operation.
- The electric mini cutter is designed for cutting various materials up to 1/4 inch thick, including cardboard, carpet, rope, leather, and paper.
- Always engage the safety switch before operating the tool.
- Hold the tool firmly and guide it smoothly through the material.



✔ **CARPET**



✔ **CARDBOARD**



✔ **PACKAGES**



✔ **ROPE**



✔ **LEATHER**



✔ **PAPER**

Image 4.1: The SnapFresh 4V Electric Mini Cutter demonstrating its versatility in cutting different materials.

For detailed operating instructions, refer to the specific user manual for the SnapFresh 4V Electric Mini Cutter (EC0601).

## 5. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your charger.

- Keep the charger clean and dry. Wipe with a soft, damp cloth if necessary. Do not use harsh chemicals or abrasive cleaners.
- Store the charger in a cool, dry place away from direct sunlight and extreme temperatures.
- Regularly inspect the power cord and plug for any signs of damage. If damaged, discontinue use and replace the charger.

## 6. TROUBLESHOOTING

If you encounter issues with your charger, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Charger indicator light does not turn on.	No power from outlet. Charger not properly plugged in. Charger or cable is damaged.	Check the power outlet with another device. Ensure both ends of the charger are securely connected. Inspect charger and cable for damage. If damaged, replace the charger.
Battery not charging.	Charger not compatible with the tool. Tool's battery is faulty. Charger is faulty.	Confirm the charger is for SnapFresh 4V Electric Mini Cutter (EC0601). Consult the electric mini cutter's manual for battery troubleshooting. If other solutions fail, the charger may need replacement.

If the problem persists after attempting these solutions, please contact SnapFresh customer support for further assistance.

## 7. SPECIFICATIONS

Feature	Detail
Brand	SnapFresh
Model Number	ECC0601
Product Dimensions	3.07 x 3.35 x 1.85 inches
Item Weight	2.39 ounces
Connector Type	2-Pin
Compatible Devices	SnapFresh 4V Electric Mini Cutter (EC0601)
Included Components	Cordless Electric Scissors Charger
Special Feature	Lightweight Design
Color	Black
Total USB Ports	1 (Note: This refers to the charger's internal design, not an external USB port for user access)
Wattage	20 watts
Output Current	0.5 Amps

## 8. WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please visit the official SnapFresh

website or contact their customer service department. Keep your purchase receipt as proof of purchase for any warranty claims.

**SnapFresh Official Store:** [Visit the SnapFresh Store on Amazon](#)

---

© 2024 SnapFresh. All rights reserved.