

PEUTIER 05036

PEUTIER Quick Turn Fabric Set Instruction Manual

Model: 05036

INTRODUCTION

The PEUTIER Quick Turn Fabric Set is designed to simplify the process of turning fabric tubes right side out for various sewing and craft projects. This set includes three different sizes of fabric tube turners, making it suitable for a range of fabric widths. Crafted from durable wood, plastic, and metal, these tools provide an efficient solution for creating straps, loops, and other tubular fabric components with ease.

PACKAGE CONTENTS

- 1 x Quick Turn Fabric Set, including:
- 1 x 1.27cm (1/2 inch) cylinder fabric tube turner
- 1 x 0.95cm (3/8 inch) cylinder fabric tube turner
- 1 x 0.48cm (3/16 inch) cylinder fabric tube turner

PRODUCT SPECIFICATIONS

Specification	Detail
Manufacturer	PEUTIER
Model Number	05036
Materials	Wood, Plastic, Metal Tube
Package Dimensions	11.77 x 2.83 x 0.71 inches
Item Weight	2.29 ounces (0.07 Kilograms)
Color	Clear (referring to the plastic tubes)

Turner Sizes and Recommended Fabric Tube Widths:

- **1.27cm (1/2 inch) cylinder:** For 2.54cm (1 inch) or larger fabric tubes.
- **0.95cm (3/8 inch) cylinder:** For 1.90cm (3/4 inch) to 2.54cm (1 inch) fabric tubes.
- **0.48cm (3/16 inch) cylinder:** For 0.95cm (3/8 inch) to 1.58cm (5/8 inch) fabric tubes.



Figure 1: Overview of the Quick Turn Fabric Set components, illustrating their respective lengths and diameters for proper size selection.

SETUP

Before beginning your project, select the appropriate fabric tube turner size based on the width of your fabric tube. Refer to the 'Product Specifications' section for guidance on matching turner size to fabric tube width. Ensure your fabric tube is sewn and trimmed, leaving a small seam allowance.




Figure 2: A close-up view of the three fabric tube turners, highlighting their distinct sizes and the pointed wooden sticks used for pushing the fabric.

OPERATING INSTRUCTIONS


Follow these steps to efficiently turn your fabric tubes:

1. **Step 1: Insert the PVC Tube.** Take the selected PVC tube (the plastic part of the turner) and carefully insert it into the fabric tube. Push it through until the end of the fabric tube is near the end of the PVC tube.
2. **Step 2: Press with the Stick.** Use the corresponding bamboo or metal stick. Insert the pointed end of the stick into the PVC tube from the opposite end, pressing it against the sewn end of the fabric tube.
3. **Step 3: Turn the Fabric.** Continue to push the stick. As you push, the flipped fabric end will emerge from the other end of the PVC tube, effectively turning the fabric tube right side out.
4. **Step 4: Complete.** Once the entire fabric tube is turned, gently remove the PVC tube and the stick. Your fabric tube is now ready for your project.


How to use



Step 1: Put the PVC tube into the fabric tube;



Step 2: Use a bamboo stick (metal stick) to press into the sewn end of the fabric tube;



Step 3: then the flipped fabric end will come out from the other end of the PVC tube



Step 4: complete

Figure 3: Step-by-step visual guide for using the Quick Turn Fabric Set.

Demonstration Videos:

Your browser does not support the video tag.

Video 1: A demonstration of the fabric turning process using the Quick Turn Fabric Set. This video shows the tool in action, making the steps clear and easy to follow.

Your browser does not support the video tag.

Video 2: A short clip showcasing the efficiency of the fabric turner for small projects. This video highlights the speed and ease of use.

Your browser does not support the video tag.

Video 3: Another brief demonstration of the fabric turning tool, providing an alternative perspective on its application.

Project Examples:



Figure 4: Example of scrunchies created using the fabric turners, demonstrating the tool's application in accessory making.



Figure 5: Another example of finished scrunchies, highlighting the versatility of the tool for different fabric types and patterns.



Figure 6: A collage showcasing a variety of finished fabric projects, illustrating the broad utility of the Quick Turn Fabric Set.

MAINTENANCE

To ensure the longevity and optimal performance of your Quick Turn Fabric Set, follow these care instructions:

- **Cleaning:** The fabric turners should be hand washed only. Use mild soap and water if necessary.
- **Drying:** After washing, allow the tools to air dry completely before storing to prevent any damage to the wood or metal components.
- **Storage:** Store the set in a dry place, away from direct sunlight or extreme temperatures, to maintain material integrity.

TROUBLESHOOTING

If you encounter any difficulties while using your fabric turners, consider the following:

- **Fabric Getting Stuck:** Ensure you are using the correct size turner for your fabric tube. A turner that is too large for the fabric tube can cause it to bunch up, while one that is too small may not provide enough leverage.

- **Difficulty Pushing:** If the fabric is very thick or has a tight weave, it may require more force. Try gently wiggling the stick as you push, or apply a small amount of fabric-safe lubricant (if appropriate for your fabric) to the inside of the tube.
- **Uneven Turning:** Make sure the sewn end of your fabric tube is neatly trimmed and that the stick is pressing evenly against it.

WARRANTY AND SUPPORT

Specific warranty information for the PEUTIER Quick Turn Fabric Set is not provided within this manual. For any product support, warranty inquiries, or further assistance, please contact the manufacturer directly through their official channels or the retailer from whom the product was purchased.