

One For All URC1281

One For All URC1281 Essence 8 TV Universal Remote Control User Manual

INTRODUCTION

Welcome to the user manual for your One For All URC1281 Essence 8 Universal Remote Control. This remote is designed to simplify your home entertainment experience by allowing you to control up to eight different audio and video devices with a single remote.

The URC1281 Essence 8 features a clear, uncluttered design with large, well-labeled buttons for ease of use. It is compatible with a wide range of devices, including televisions, streaming devices, soundbars, and more. This manual provides detailed instructions on how to set up, operate, and maintain your remote control.

Key Features:

- Controls up to 8 devices.
- Simple and intuitive setup process.
- Compatible with various device types.
- Ready to use after battery insertion for many TV brands.
- Ergonomic design for comfortable handling.

PRODUCT OVERVIEW

The One For All URC1281 Essence 8 remote control is designed for ease of use, featuring a logical button layout. Below is an image of the remote with a description of its main components.



Image: Front view of the One For All URC1281 Essence 8 Universal Remote Control. The remote is black with various gray and colored buttons, including power, device selection (TV, AUX, OTT, STB, AUD, BLU, DVD, BAR), navigation, volume, channel, and number keys. A Netflix button is prominently featured.

Device Buttons:

- **TV:** Controls your television.
- **AUX:** Auxiliary device.
- **OTT:** Over-The-Top streaming device.

- **STB:** Set-Top Box.
- **AUD:** Audio device (e.g., soundbar, receiver).
- **BLU:** Blu-ray player.
- **DVD:** DVD player.
- **BAR:** Soundbar.

Other Key Buttons:

- **Power (Red):** Turns the selected device on or off.
- **Setup:** Used for programming the remote.
- **Volume (+/-):** Adjusts the volume.
- **Channel (Ch +/-):** Changes channels.
- **Navigation Pad (Up/Down/Left/Right/OK):** For menu navigation.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** For media playback.
- **Netflix:** Direct access to Netflix (if supported by the device).
- **Number Keys (0-9):** For direct channel entry or inputting codes.

SETUP

1. Battery Installation

Your remote requires two AAA alkaline batteries (not included). Ensure correct polarity when inserting.

1. Open the battery compartment cover on the back of the remote.
2. Insert two AAA alkaline batteries, matching the (+) and (-) terminals as indicated inside the compartment.
3. Close the battery compartment cover securely.

For many TV brands, the remote will be immediately ready to use after battery insertion.

2. Programming Your Devices

The URC1281 Essence 8 offers several methods to program your devices:

a. SimpleSet (Recommended for quick setup)

SimpleSet allows you to program your remote in just a few steps for popular brands.

1. Turn on the device you wish to control (e.g., your TV).
2. Press and hold the **SETUP** button until the LED under the selected device button (e.g., TV) blinks twice and stays lit.
3. Press the device button you want to set up (e.g., **TV**). The LED will remain lit.
4. Point the remote at your device and press and hold the **POWER** button. The remote will send a power signal every 3 seconds.
5. As soon as your device turns off, release the **POWER** button immediately. The LED will blink twice to confirm.
6. Test other functions like Volume and Channel. If they work, your device is programmed. If not, repeat the process, releasing the **POWER** button at the next power-off signal.

b. Code Entry (Using a 4-digit code)

If SimpleSet does not work, or for less common brands, you can enter a 4-digit code from the code list provided with your remote or available online.

1. Turn on the device you wish to control.

2. Press and hold the **SETUP** button until the LED under the selected device button blinks twice and stays lit.
3. Press the device button you want to set up (e.g., **DVD**). The LED will remain lit.
4. Enter the 4-digit code for your device brand using the number keys.
5. If the code is valid, the LED will blink twice and turn off. If the code is invalid, the LED will blink once for a long time.
6. Point the remote at your device and press the **POWER** button. If the device turns off, the code is correct.
7. Test other functions. If they do not work, try the next code for your brand from the list.

c. Learning Mode (Copying functions from your original remote)

The learning function allows you to copy any function from your original remote control to the Essence 8.

1. Place the Essence 8 and your original remote on a flat surface, pointing their infrared eyes towards each other, about 2-5 cm apart.
2. Press and hold the **SETUP** button until the LED blinks twice and stays lit.
3. Press the device button you want to learn functions onto (e.g., **AUX**). The LED will remain lit.
4. Press the button on the Essence 8 where you want to store the learned function (e.g., **VOL+**). The LED will blink rapidly.
5. Press the corresponding button on your original remote (e.g., **VOL+**). The LED on the Essence 8 will blink twice to confirm successful learning.
6. Repeat steps 4 and 5 for all other functions you wish to learn.
7. To exit learning mode, press the **SETUP** button. The LED will blink twice.

Note: You cannot learn functions onto device selection buttons (TV, AUX, etc.) or the SETUP button. Ensure your original remote has fresh batteries for optimal learning.

OPERATING YOUR REMOTE

Once programmed, using your Essence 8 remote is straightforward.

1. Selecting a Device

To control a specific device, you must first select it. Press the corresponding device button (e.g., **TV**, **DVD**, **AUD**). The LED under the selected device button will light up briefly to indicate it is active. All subsequent button presses will control that device until another device button is pressed.

2. Basic Functions

- **Power:** Press the **POWER** button to turn the selected device on or off.
- **Volume:** Use **VOL+** and **VOL-** to adjust the volume.
- **Mute:** Press the **MUTE** button to silence the audio.
- **Channel:** Use **CH+** and **CH-** to change channels.
- **Number Keys:** Use the **0-9** keys for direct channel entry or other numerical inputs.

3. Advanced Functions

- **Navigation:** Use the directional arrows and **OK** button for menu navigation on smart TVs, streaming devices, etc.
- **Playback:** The dedicated playback buttons (Play, Pause, Stop, Rewind, Fast Forward) control media on DVD/Blu-ray players or streaming devices.

- **Netflix:** Press the **NETFLIX** button for direct access to the Netflix application on compatible smart TVs or streaming devices.
- **Apps:** The **APPS** button may provide access to smart TV application menus.

MAINTENANCE

1. Cleaning Your Remote

To keep your remote in optimal condition, clean it regularly:

- Use a soft, slightly damp cloth to wipe the surface of the remote.
- Do not use abrasive cleaners, solvents, or alcohol, as these can damage the finish or internal components.
- Ensure no liquid enters the remote's casing.

2. Battery Replacement

Replace batteries when the remote's range decreases, or buttons become unresponsive. The remote uses two AAA alkaline batteries.

1. Open the battery compartment cover.
2. Remove the old batteries.
3. Insert new AAA alkaline batteries, observing the correct (+) and (-) polarity.
4. Close the battery compartment cover.

Note: Dispose of old batteries responsibly according to local regulations.

TROUBLESHOOTING

If you encounter issues with your One For All URC1281 Essence 8 remote, refer to the following common solutions:

- **Remote not responding:**
 - Check if the batteries are inserted correctly and have sufficient charge. Replace if necessary.
 - Ensure you have selected the correct device button (e.g., TV for your television).
 - Make sure there are no obstructions between the remote and the device.
 - Verify that the remote's infrared emitter is clean and unobstructed.
- **Device not responding after programming:**
 - Repeat the programming steps (SimpleSet or Code Entry) carefully.
 - If using Code Entry, try the next code listed for your brand.
 - Ensure the device is turned on before attempting to program.
 - If SimpleSet or Code Entry fails, try using Learning Mode with your original remote.
- **Some buttons not working after programming:**
 - This can happen if the code is not a perfect match. Try another code for your brand.
 - Use Learning Mode to copy specific missing functions from your original remote.
- **Learning Mode issues:**

- Ensure both remotes are placed correctly, infrared eyes facing each other, and close enough.
- Check that the original remote has fresh batteries.
- Press the buttons firmly and briefly during the learning process.

For further assistance, consult the full manual (if provided separately) or visit the One For All support website.

SPECIFICATIONS

Brand	One For All
Model Name	URC1281 Essence 8
Item Model Number	CON000207
Color	Black
Connectivity Technology	Infrared (IR)
Max Number of Supported Devices	8 (TV, AUX, OTT, STB, AUD, BLU, DVD, BAR)
Compatible Devices	Televisions, Streaming Devices, Soundbars, DVD/Blu-ray Players, Set-Top Boxes, Audio Devices
Number of Buttons	25
Controller Type	Button Control
Special Feature	Ergonomic Design
Battery Type	2 x AAA Alkaline (not rechargeable)
Maximum Range	15 Meters

WARRANTY AND SUPPORT

1. Manufacturer's Warranty

The One For All URC1281 Essence 8 Universal Remote Control comes with a **12-month manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

2. Customer Support

For technical assistance, troubleshooting tips, or to access the latest code lists, please visit the official One For All website. You may also find frequently asked questions (FAQs) and additional support resources there.

When contacting support, please have your product model (URC1281 Essence 8) and any relevant purchase information ready.

Related Documents - URC1281


	<p>One For All URC1281 Universal Remote Codelist</p> <p>Find the correct code for your TV, STB, Blu-ray player, or audio device with the One For All URC1281 universal remote codelist. Comprehensive list of brands and device codes.</p>
	<p>One For All Essence 8 Universal Remote Control URC1281 User Manual</p> <p>User manual for the One For All Essence 8 Universal Remote Control (URC1281). Learn how to set up and use the remote to control up to 8 audio-video devices with features like SimpleSet, code entry, and learning functions.</p>
	<p>One For All Essence 8 Universal Remote Control User Manual</p> <p>User manual for the One For All Essence 8 Universal Remote Control. Learn how to set up and control up to 8 audio-video devices like TVs, set-top boxes, Blu-ray players, and soundbars.</p>
	<p>One For All Essence 8 Universal Remote Control URC1281 Setup Guide</p> <p>Comprehensive guide for setting up and using the One For All Essence 8 Universal Remote Control (URC1281) to manage up to 8 audio-video devices. Learn about button functions, battery installation, simple setup, code setup, learning functions, and volume lock.</p>



[One For All Essence 8 Universal Remote Control URC1281 Setup Guide](#)

Comprehensive guide for setting up and using the One For All Essence 8 Universal Remote Control (URC1281) to manage up to 8 audio-video devices. Learn about button functions, battery installation, simple setup, code setup, learning functions, and volume lock.

lang:en score:28 filesize: 80.86 M page_count: 196 document date: 2023-03-23



[\[pdf\]](#)

One for all afstandsbediening URC1281 Download Exellent Artikelcode OAURC1281 € 19,99 Kenmerken 1 2 Page Number of devices supported one urc1281 exellent be nl pr product sheet |||

One for all afstandsbediening **URC1281** Artikelcode : **OAURC1281** 19,99 Kenmerken Number of devices supported: 8 Powered by TCPDF www.tcpdf.org ...

lang:en score:27 filesize: 373.4 K page_count: 2 document date: 2025-07-29



[One For All Essence 8 Universal Remote Control User Manual](#)

User manual for the One For All Essence 8 Universal Remote Control. Learn how to set up and control up to 8 audio-video devices like TVs, set-top boxes, Blu-ray players, and soundbars.


lang:en score:26 filesize: 81.07 M page_count: 196 document date: 2024-10-31



[One For All Essence 8 Universal Remote Control URC1281 User Manual](#)

User manual for the One For All Essence 8 Universal Remote Control (URC1281). Learn how to set up and use the remote to control up to 8 audio-video devices with features like SimpleSet, code entry, and learning functions.


lang:af score:25 filesize: 22.6 M page_count: 76 document date: 2024-09-12



[\[pdf\]](#) User Manual

URC1281 Manual All Languages Essence 8 One For 713430 manual urc1281 essence 13 21t printfile rdn1150323 1 oneforall sites default files 2023 06 |||

Essence 8 Device Universal Remote Control **URC1281** ENGLISH 2 DEUTSCH 8 FRANAIS 13 ESPAOL 18 ITALIANO 23 PORTUGUS 28 NEDERLANDS 31 DANSK 34 NORSK 37 SVERIGE 40 SUOMI 43 46 49 TRKE 52 POLSKI 55 CESKY 58 MAGYAR 61 64 ROMN 67 SLOVENSKY 70 HRVATSKI 73 SIMPLESET IN...
lang:af **score:25** filesize: 22.71 M page_count: 76 document date: 2023-03-22



[\[pdf\]](#) Specifications Dimension Guide

Document Download Spec Sheet One For All URC1281 Essence 8 TV Remote Connoisseur SA OFA Universal remote control Leaflet en US v 1738159723 cdn shopify s files 1 0881 0810 6035 |||

URC1281 Universal remote control Essence 8 Combines 8 remotes into 1 This handy Universal remote gives you easy control of all your devices as on your original remotes Television Sound bar Sat / Cable DVD / Blu-ray Game Audio Media Aux Consumer benefits Full control of 8 devices Learning featur...
lang:en **score:23** filesize: 319.83 K page_count: 2 document date: 2025-01-29



[One For All URC1281 Universal Remote Codelist](#)

Find the correct code for your TV, STB, Blu-ray player, or audio device with the One For All URC1281 universal remote codelist. Comprehensive list of brands and device codes.

lang:tl **score:21** filesize: 232.69 K page_count: 2 document date: 2023-03-22


[\[pdf\]](#)

URC1281 Codelist One For All Documents 713816 codelist urc1281 essence 8 22 simpleset and
rdn1120924 zp universal utomo pim s3 eu west 1 amazonaws 66f268219f7ae |||



Essence 8 Device **URC1281** SIMPLESET P. 2 - 3 CODELIST P. 4 - 15 1 SIMPLESET
SETUP SIMPLESET TV OTT STB AUD AUX BLU DVD BAR Bush Grundig JVC LG
Panasonic Philips Samsung Sharp Sony Toshiba Samsung TV Roku Streaming Box
Sky Q Box Onkyo Receiver Vestel TV Samsung Blu-ray Player Sony DVD Player
Samsun...

lang:de **score:20** filesize: 2.09 M page_count: 2 document date: 2024-09-12



[\[pdf\]](#) User Manual

URC1281 Manual All Languagesoneforall sites default files 2023 09 Languages 713430 manual urc1281
essence 8 13 21t printfile rdn1150323 1URC1281 2024 02 1oneforall ||| ||| Essence 8 Device Universal
Remote Control URC1281 ENGLISH 2 DEUTSCH 8 FRANAIS 13 ESPAOL 18 ITALIANO 23
PORTUGUS 28 NEDERLANDS 31 DANSK 34 NORSK 37 SVERIGE 40 SUOMI 43 46 49 TRKE 52
POLSKI 55 CESKY 58 MAGYAR 61 64 ROMN 67 SLOVENSKY 70 HRVATS

Essence 8 Device Universal Remote Control **URC1281** ENGLISH 2 DEUTSCH 8
FRANAIS 13 ESPAOL 18 ITALIANO 23 PORTUGUS 28 NEDERLANDS 31 DANSK
34 NORSK 37 SVERIGE 40 SUOMI 43 46 49 TRKE 52 POLSKI 55 CESKY 58
MAGYAR 61 64 ROMN 67 SLOVENSKY 70 HRVATSKI 73 SIMPLESET IN...

lang:af **score:19** filesize: 22.71 M page_count: 76 document date: 2023-03-22

[\[pdf\]](#)

CODELIST OneForAll oneforall â° default files 713430 cover urc1281 essence 8 33 codelist rdn1150323
1 2 sites 2024 02 |||



Essence 8 Device **URC1281** CODELIST TV / AUX A.R. Systems Acer Acoustic
Solutions Acronn Adcom AEG Agfaphoto Airis Aiwa Akai Akira Akura Alba Allview
Altius Altus Amoi AmTRAN Andersson Ankaro Antarion AOC Arcelik Arelik Ardem
Arena Arielli Arise Aristona Art Mito AS Asano Audiosonic Audio-Technica A...

lang:tl **score:13** filesize: 232.68 K page_count: 2 document date: 2023-03-22



[pdf] Documentation Declaration of Conformity

4 Belle Vallejos URC1281 Declaration of Conformity One For All Documents urc 1281 r00 eu uk doc
universal utomo pim s3 west 1 amazonaws 64ca39ced5de6 |||

Universal Electronics BV Colosseum 2 7521 PT Enschede The Netherlands EU
DECLARATION OF CONFORMITY We, Universal Electronics BV, Colosseum 2,
7521 PT Enschede, Netherlands, hereby under sole responsibility that the products to
which this declaration relates is in conformity with the stated directive...

lang:de score:13 filesize: 785.17 K page_count: 5 document date: 2023-07-27