

[Manuals.plus](#) /

> [JINJUNYE](#) /

> JINJUNYE 6 Bottle Wine Cooler User Manual

## JINJUNYE JC-16C1P

# JINJUNYE 6 Bottle Wine Cooler User Manual

Model: JC-16C1P

## PRODUCT OVERVIEW

The JINJUNYE 6 Bottle Wine Cooler is a compact and stylish appliance designed to provide an ideal and stable storage environment for your wine collection. Featuring digital temperature control, energy-efficient operation, and a quiet cooling system, it's perfect for small spaces like kitchens, dormitories, or offices.



Image: The JINJUNYE 6 Bottle Wine Cooler, a compact black unit with a glass door displaying six wine bottles on wavy chrome shelves. A wine glass with red wine is placed next to it.

## KEY FEATURES

- **Stable Performance:** Equipped with a built-in fan for even temperature distribution and odor prevention. Double-glazed doors block UV rays and maintain internal temperature stability.
- **Precise Temperature Control:** Adjustable temperature range from 46-66°F (8-18°C) to ensure optimal wine preservation.
- **User-Friendly Operation:** Digital display for easy temperature adjustment and an internal soft LED light for visibility, which can be turned on or off.
- **Compact & Versatile Design:** Measuring 19.49"D x 10.31"W x 14.76"H, it's ideal for countertops and small spaces. Includes two adjustable stainless steel shelves to accommodate various bottle sizes.
- **Energy-Efficient & Quiet:** Designed for low power consumption and operates at less than 38dB, ensuring minimal disturbance.



## Door Seal

Isolate external odor, maintain  
stable temperature



## Adjustable Feet

Make the wine cooler more stable



## Soft LED Light

Illuminate your wine collection  
in the dark



## Removable Shelves

Flexible adjustment of internal space

Image: A collage showcasing various features of the wine cooler, including a close-up of the door seal, adjustable feet, the soft LED interior light, and removable wavy chrome shelves.

## SETUP AND INSTALLATION

1. **Unpacking:** Carefully remove the wine cooler from its packaging. Retain all packaging materials for future transport or service.
2. **Placement:** Choose a stable, level surface away from direct sunlight, heat sources (like ovens or radiators), and excessive moisture. Ensure adequate ventilation around the unit. This appliance is designed for freestanding or countertop use.
3. **Leveling:** Use the adjustable feet at the bottom of the unit to ensure it is perfectly level. This is crucial for proper operation and door alignment.
4. **Power Connection:** Plug the wine cooler into a dedicated 110V AC outlet. Avoid using extension cords or multi-outlet adapters.
5. **Initial Operation:** Allow the unit to stand upright for at least 2 hours before plugging it in. After plugging in, let it run

empty for 24 hours to stabilize the internal temperature before loading bottles.

# 6 Bottle Wine Cooler



**Note: Please make sure the dimensions fit your space**

Image: A diagram showing the dimensions of the JINJUNYE 6 Bottle Wine Cooler: 19.49 inches deep, 10.31 inches wide, and 14.76 inches high. Also shown are the dimensions of a single shelf.

## OPERATING INSTRUCTIONS

### Control Panel

The control panel is located on the top front of the unit, featuring a digital temperature display and touch-sensitive buttons for easy operation.




Image: A close-up of the wine cooler's digital control panel, showing buttons for temperature adjustment (up/down arrows), light control, and temperature unit conversion (°F/°C), with the current temperature displayed.

### Temperature Adjustment

- Press the **Up Arrow** button to increase the desired temperature.
- Press the **Down Arrow** button to decrease the desired temperature.
- The temperature range is 46-66°F (8-18°C). The display will show the set temperature for a few seconds, then revert to the actual internal temperature.

### Internal Light Control

- Press the **Light Bulb** button to turn the internal LED light on or off.

### Temperature Unit Conversion

- Press the **°F/°C** button to switch the temperature display between Fahrenheit and Celsius.

### Loading Bottles

- The wine cooler can hold up to 6 standard wine bottles.
- The shelves are removable and adjustable to accommodate different bottle sizes. Gently pull the shelves out to remove or reposition them.
- For optimal cooling, ensure bottles are not tightly packed, allowing for proper air circulation.

Your browser does not support the video tag.

Video: An official product video demonstrating the JINJUNYE 6 Bottle Wine Fridge, showcasing its wavy chrome shelf design, 6-bottle capacity, touch screen control panel, LED temperature display, bright interior light, recessed door handle, and overall stable, elegant, and compact design. It highlights its suitability for wine storage.

## MAINTENANCE AND CARE

- **Cleaning:**
  - Unplug the unit before cleaning.
  - Clean the interior with a soft cloth and a mild detergent solution. Avoid abrasive cleaners or solvents.
  - Wipe down the exterior with a soft, damp cloth.
  - The shelves can be removed for easier cleaning.
- **Defrosting:** The unit features an automatic defrost system, minimizing the need for manual defrosting.
- **Door Seal:** Regularly check the door seal for any signs of damage or wear to ensure optimal temperature retention and energy efficiency.
- **Power Outage:** In case of a power outage, keep the door closed to maintain the internal temperature for as long as possible.
- **Long-Term Storage:** If the unit will not be used for an extended period, unplug it, clean the interior, and leave the door slightly ajar to prevent odors and mold growth.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Wine cooler does not operate.	No power; Power cord not plugged in; Circuit breaker tripped.	Check power supply; Ensure cord is securely plugged in; Reset circuit breaker.
Temperature is not cold enough.	Door not closed properly; Excessive door opening; Unit placed near heat source; Poor ventilation; Temperature setting too high.	Ensure door is sealed; Minimize door openings; Relocate unit; Ensure proper clearance; Adjust temperature setting lower.
Unit is making unusual noises.	Unit not level; Objects touching the unit; Normal operating sounds.	Adjust leveling feet; Ensure nothing is touching the unit; Gurgling or vibrating sounds are normal for refrigeration systems.
Internal light not working.	Light switch off; LED bulb issue.	Press the light button on the control panel; Contact customer support if the issue persists.

## SPECIFICATIONS

Feature	Detail
Brand	JINJUNYE
Model Number	JC-16C1P
Capacity	6 Bottles / 16 Liters
Temperature Range	46-66°F (8-18°C)
Dimensions (DxWxH)	19.49" x 10.31" x 14.76"
Item Weight	18.9 pounds
Installation Type	Freestanding, Countertop
Door Material	Glass + Stainless Steel
Shelves	2, Stainless Steel, Adjustable
Voltage	110 Volts
Defrost System	Automatic
Noise Level	<38dB

## WARRANTY AND SUPPORT

The JINJUNYE 6 Bottle Wine Cooler comes with a 1-year warranty and lifetime technical support. For any questions, concerns, or technical assistance, please contact JINJUNYE customer service.

Refer to the included "1\*Instruction Manual" for detailed warranty information and contact methods.