MEUBLE COSY ASCOLI OAK 2023

MEUBLE COSY Small Foldable Laptop Desk User Manual

Model: ASCOLI OAK 2023

Overview Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Product Overview

The MEUBLE COSY ASCOLI OAK 2023 is a versatile and space-saving foldable laptop desk designed for various activities, including work, study, and hobbies. Its minimalist Scandinavian design blends seamlessly into any home or office environment.

Key Features:

- **Foldable Design:** This desk can be easily folded and stored in a corner, making it ideal for small spaces and convenient for transport.
- **High-Quality Materials:** The tabletop is crafted from durable, waterproof, and easy-to-clean E1 grade wood. The robust steel frame ensures long-lasting stability.
- **Space-Saving:** With dimensions of 80 x 40 x 74 cm, this compact desk is perfect for apartments, dormitories, and home offices.
- **Modern Scandinavian Design:** A blend of minimalist aesthetics and meticulous craftsmanship, serving as a stylish centerpiece.
- **Easy Assembly:** Comes with detailed instructions and clearly labeled parts for quick and effortless setup.

Safety Warning:

Do not place excessively heavy objects on the desk, especially if it is not secured against a wall. Keep liquids away from the tabletop surface and clean spills immediately with a dry cloth to prevent damage.



Image: The MEUBLE COSY ASCOLI OAK 2023 desk shown in its open, ready-to-use configuration on the left, and its compact, folded configuration on the right, highlighting its space-saving design.

---

2. Setup and Assembly

The MEUBLE COSY ASCOLI OAK 2023 desk is designed for easy and quick assembly. Follow these steps to set up your desk.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the packing list are present.
2. **Unfold the Frame:** Gently pull the desk frame upwards from its folded position until the legs are fully extended and locked into place.
3. **Position the Tabletop:** Ensure the tabletop is aligned correctly with the frame.
4. **Secure the Tabletop:** If applicable, secure the tabletop to the frame using the provided fasteners.
5. **Final Check:** Confirm that all parts are securely in place and the desk is stable before use.



Image: A visual guide illustrating the four simple steps to unfold and set up the MEUBLE COSY desk. Step 1 shows the desk partially unfolded, Step 2 shows the legs extending, Step 3 shows the tabletop being lowered, and Step 4 shows the desk fully assembled and ready for use.

---

3. Operating Instructions

The MEUBLE COSY ASCOLI OAK 2023 desk is designed for straightforward use. Here are guidelines for optimal operation and folding.

Using the Desk:

- **Placement:** Place the desk on a flat, stable surface to ensure balance and prevent wobbling.
- **Load Capacity:** While sturdy, avoid placing excessive weight on the desk.
- **Surface Protection:** Although the tabletop is waterproof, it is recommended to use coasters for drinks and placemats for hot items to prolong its lifespan.

Folding the Desk for Storage:

1. **Clear the Surface:** Remove all items from the desk surface.
2. **Unlock Mechanism:** Locate any locking mechanisms that secure the legs in the open position and disengage them.
3. **Fold Legs Inward:** Gently push the legs inward until they collapse against the tabletop.
4. **Fold Tabletop:** If the tabletop has a hinge, fold it down to achieve the most compact form.
5. **Store:** Once folded, the desk can be easily stored in a corner or narrow space.



Image: The MEUBLE COSY desk positioned in a modern home office, showcasing its functionality with a laptop, plant, and decorative items, illustrating its suitability for various work environments.



Image: Two children engaged in activities at the MEUBLE COSY desk, demonstrating its versatility and suitability for various age groups and uses, such as homework or creative play.

---

4. Care and Maintenance

Proper care will ensure the longevity and appearance of your MEUBLE COSY desk.

Cleaning:

- **Tabletop:** Wipe the tabletop with a soft, damp cloth. For stubborn stains, use a mild soap solution and immediately dry with a clean, dry cloth. Avoid abrasive cleaners or harsh chemicals.
- **Frame:** Clean the metal frame with a soft, dry or slightly damp cloth.

General Care:

- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or discoloration of the tabletop.

- **Temperature and Humidity:** Maintain a stable room temperature and humidity level to prevent warping or cracking of the wood.
- **Inspect Periodically:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.



Image: A composite image highlighting key features for maintenance and stability: water droplets on the tabletop demonstrating its waterproof quality, the desk neatly folded against a wall for storage, and a close-up of the stable, non-slip feet.

---

5. Troubleshooting

This section addresses common issues you might encounter with your MEUBLE COSY desk.

Problem	Possible Cause	Solution
Desk wobbles after assembly.	Uneven floor surface or loose connections.	Ensure the desk is on a flat surface. Check and tighten all screws and connections.

Problem	Possible Cause	Solution
Difficulty folding/unfolding the desk.	Mechanism obstructed or not aligned correctly.	Ensure no objects are blocking the folding mechanism. Gently guide the parts into alignment. Do not force.
Surface stains or marks.	Spills not cleaned promptly or use of harsh cleaners.	Clean with a soft, damp cloth and mild soap. Avoid abrasive materials. For persistent marks, consult a furniture care specialist.

---

6. Product Specifications

Detailed specifications for the MEUBLE COSY ASCOLI OAK 2023 desk.

Attribute	Detail
Brand	MEUBLE COSY
Model Number	ASCOLI OAK 2023
Color	Oak
Dimensions (L x W x H)	80 x 40 x 74 cm (31.5 x 15.7 x 29.1 inches)
Weight	7 Kilograms (15.4 lbs)
Material (Tabletop)	E1 Grade Wood (Oak finish, Laminated)
Material (Frame)	Metal
Special Feature	Foldable
Style	Scandinavian
Manufacturer	Furnish 1



Image: A detailed diagram illustrating the dimensions of the MEUBLE COSY desk in both its open (80 cm length, 40 cm width, 74 cm height) and folded (80 cm length, 32.5 cm width, 9.5 cm thickness) configurations.

---

7. Warranty and Support

For warranty information and customer support, please refer to the following:

- **Warranty:** Specific warranty details are typically provided with your purchase documentation. Please retain your proof of purchase for any warranty claims.
- **Customer Support:** For assistance with assembly, parts, or any other inquiries, please contact MEUBLE COSY customer service through the retailer where you purchased the product or visit the official MEUBLE COSY brand store on Amazon: MEUBLE COSY Brand Store.
- **Spare Parts:** Information regarding spare parts availability is currently unavailable.

© 2023 MEUBLE COSY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question